EDCM V600R022C00

**User Manual** 

Date 2022-02-25

# **Contents**

1 Getting Started	1
1.1 Logging In to or Logging Out of the NetEco	1
1.1.1 Operating Environment Requirements	1
1.1.2 Logging In to the NetEco (Through HUAWEI CLOUD)	4
1.1.3 Logging In to the NetEco (Through the WebUI)	
1.1.4 Logging Out of the NetEco	6
1.2 Setting NetEco Communications Parameters on the ECC800-Pro	6
1.3 Connecting a Device (Through the App, Recommended)	7
1.3.1 Installing the NetEco App	7
1.3.2 (Optional) Replacing the App Certificate on a Mobile Device	8
1.3.3 Logging In to the NetEco App	10
1.3.4 Connecting to a Site	13
1.4 Connecting a Device (Through the WebUI)	14
1.4.1 Adding a Management Domain	14
1.4.2 Adding a Device Through Automatic Discovery	15
1.4.3 Planning Configuration Interface Reference	17
1.4.3.1 Basic Parameters of a Management Domain	17
1.4.3.2 Basic Device Parameters	25
2 Device Management	33
2.1 Device View	33
2.1.1 Device View	33
2.1.1.1 Managing Views	33
2.1.1.2 Adding Control Elements	43
2.1.1.3 Configuring a Monitoring View	45
2.1.1.3.1 Managing the Service Layer	45
2.1.1.3.2 Setting the Quick Navigation Bar	47
2.1.1.3.3 Setting View Display Parameters	48
2.1.1.3.4 Device Page Settings	48
2.1.2 Battery Management	48
2.2 Configuration	50
2.2.1 Planning Configuration	50
2.2.1.1 Relocating Management Domains or Devices	50
2.2.1.2 Synchronizing Device Configuration Data to the NetEco	51

2.2.2 Managing Device Signals	52
2.3 Alarm Management	56
2.3.1 Viewing and Handling Current Alarms	56
2.3.1.1 Viewing Current Alarms	56
2.3.1.2 Handling Alarms	69
2.3.2 Historical Alarms	75
2.3.3 Masked Alarms	76
2.3.4 Sync Alarm	77
2.3.5 Alarm Setting	78
2.3.5.1 Setting Colors for Alarms	78
2.3.5.2 Setting Alarm Display Modes	78
2.3.5.3 Setting Alarm Sounds	79
2.3.5.4 Setting Alarm Font Colors	80
2.3.5.5 Highlighting Alarms	80
2.3.5.6 Monitoring Alarms Based on Emergency Maintenance Notification	81
2.3.5.7 Setting Global Alarm Indicators	82
2.3.5.8 Configuring Masking Rules	82
2.3.5.9 Configuring Intermittent/Toggling Rules	86
2.3.5.10 Configuring Aggregation Rules	88
2.3.5.11 Configuring Correlation Rules	92
2.3.5.12 Configuring Auto Acknowledgement Rules	95
2.3.5.13 Configuring Identification Rules	97
2.3.5.14 Setting Alarm Name Groups	99
2.3.5.15 Configuring Unhandled Alarm Severity Rules	99
2.3.5.16 Configuring Notification Rules	100
2.3.5.17 Configuring Notification Templates	103
2.3.5.18 Managing Handling Experience	104
2.3.5.19 Setting the Current Alarm Threshold Warning	105
2.3.5.20 Redefine Alarm	106
2.3.5.21 Threshold Alarm	110
2.4 Predefined Big Screen	114
2.4.1 Predefined Big Screen	114
3 O&M Management	117
3.1 Availability Management	117
3.1.1 Viewing a DC Report	117
3.2 Security	118
3.2.1 Access Control Management	118
3.2.1.1 Managing Access Control Devices	118
3.2.1.2 Managing Access Control Events	119
3.2.2 Video Management	120
3.2.2.1 Managing Cameras	120
3.2.2.2 Viewing live videos	123

4 System4	125
4.1 System Settings	125
4.1.1 System Configuration	125
4.1.1.1 Refreshing System Time	125
4.1.1.2 Modifying the FTP Password	126
4.1.2 Notifications	127
4.1.2.1 Third-Party App Notification Settings	127
4.1.2.1.1 Setting the WeChat Notification Server	127
4.1.2.1.2 Configuring WeChat Notification Users	128
4.1.2.1.3 Configuring WeChat Notification Rules	128
4.1.2.1.4 Configuring WeChat Notification User Groups	129
4.2 System Management	130
4.2.1 User Management	130
4.2.1.1 User Authorization	130
4.2.1.1.1 Authorization Process	130
4.2.1.1.2 Planning Authorization	131
4.2.1.1.3 (Optional) Creating a Device Set	132
4.2.1.1.4 (Optional) Creating a User-defined Operation Set	132
4.2.1.1.5 Creating a Role and Granting Permissions	133
4.2.1.1.6 (Optional) Configuring User Policies	135
4.2.1.1.7 Creating a User and Attaching the User to a Role	135
4.2.1.2 Permission Adjustment	141
4.2.1.2.1 Permission Adjustment After Subnets Are Added	141
4.2.1.2.2 Permission Adjustment After Devices Are Added	142
4.2.1.2.3 Permission Adjustment After Networking Modification	143
4.2.1.2.4 Permission Adjustment After the Objects Managed by Users Are Changed	144
4.2.1.2.5 Permission Adjustment After Operation Rights of Users Are Changed	144
4.2.1.2.6 Permission Adjustment After a User's Role Is Changed	145
4.2.1.3 Regional User Permission Management	146
4.2.1.3.1 Planning Authentication in a Region	146
4.2.1.3.2 Creating a Region Management Process	147
4.2.1.3.3 Creating a Region	148
4.2.1.3.4 Creating a Region Administrator Role	149
4.2.1.3.5 Creating a Region Administrator	150
4.2.1.3.6 Creating Operation Sets in a Region As Planned	151
4.2.1.3.7 Creating a Role in a Region and Granting Permissions	152
4.2.1.3.8 Creating a User in a Region and Attaching the User to a Role	155
4.2.1.3.9 Modifying User Information in a Region in Batches	157
4.2.1.3.10 Moving Roles from the Default Region to Another Region	159
4.2.1.3.11 Moving Users from the Default Region to Another Region	160
4.2.1.3.12 Moving Roles Out of a Region	161
4.2.1.3.13 Moving Users Out of a Region	162

4.2.1.3.14 Monitoring Users in a Region	163
4.2.1.4 User Maintenance	
4.2.1.4.1 Common Operations for User Information Maintenance	164
4.2.1.4.2 Common Operations for Role Information Maintenance	166
4.2.1.4.3 Common Operations for Operation Set Information Maintenance	168
4.2.1.4.4 Viewing Authorization Details	169
4.2.1.4.5 Modifying User Information in Batches	170
4.2.1.4.6 Changing Personal Password	172
4.2.1.4.7 Modifying Personal Information	172
4.2.1.4.8 Resetting a User Password	174
4.2.1.5 User Monitoring	175
4.2.2 Personal Settings	176
4.2.2.1 Changing Personal Password	176
4.2.2.2 Modifying Personal Information	177
4.2.2.3 Modifying Personal Client IP Address Control Policies	180
4.2.2.4 Home Settings	180
4.2.3 Log Management	180
4.2.3.1 Querying Logs	181
4.2.4 User Policy Management	182
4.2.4.1 Setting the Account Policy	182
4.2.4.2 Setting the Password Policy	183
4.2.4.3 Setting a Client IP Address Policy	185
4.2.4.4 Setting a Login Time Policy	186
4.2.5 Security Configuration	186
4.2.5.1 Overview of Security Configuration	186
4.2.5.1.1 Definition	187
4.2.5.1.2 Benefits	187
4.2.5.1.3 Scenarios	187
4.2.5.1.4 Functions	187
4.2.5.1.5 Principles	187
4.2.5.2 Viewing Security Baselines	188
4.2.5.3 Checking Security Configurations	188
4.3 About	189
4.3.1 Certificate Management	189
4.3.1.1 Managing Service Certificates	190
4.3.1.2 Restoring Historical Certificates	191
4.3.1.3 Importing Global Shared Certificates	192
4.3.1.4 Configuring CA Interconnection Parameters	
4.3.1.5 Configuring CRL Server Parameters	
4.3.1.6 Creating Certificate Application Templates	195
4.3.1.7 Certificate Update Tasks	
4.3.1.8 General Settings of Certificate Management	202

4.3.2 Certificate Authority Service	203
4.3.2.1 Certificate Authority Service Overview	203
4.3.2.1.1 Definition	203
4.3.2.1.2 Benefits	204
4.3.2.1.3 Scenario	204
4.3.2.1.4 Functions	206
4.3.2.1.5 Principles	208
4.3.2.2 Certificate Authority Service Configuration Procedure	208
4.3.2.3 Configuring a Certificate Profile	227
4.3.2.4 Configuring a CA	237
4.3.2.5 Applying for a Certificate	244
4.3.2.5.1 Application Method 1: Entering Basic Information	244
4.3.2.5.2 Application Method 2: Uploading a File	246
4.3.2.5.3 Application Method 3: Applying Through Dual Certificates	248
4.3.2.6 Configuring a CRL Server	251
4.3.2.7 Configuring a Whitelist	256
4.3.2.8 Configuring CMP	257
4.3.2.8.1 Configuring CMP Information	257
4.3.2.8.2 Configuring Request Verification	263
4.3.2.8.3 Configuring Response Protection	267
4.3.2.9 Configuring the Privacy CA Protocol	269
4.3.2.9.1 Configuring Privacy CA Protocol Information	269
4.3.2.9.2 Configuring the EK Trust Certificate	272
4.3.2.9.3 Configuring a Pre-Shared Password	274
4.3.2.10 Global Configuration	276
4.3.2.10.1 Configuring a Port	276
4.3.2.10.2 Configuring TLS	277
5 Operations on the App Client	281
5.1 Viewing Device Alarms	281
5.2 Viewing Site Monitoring Details	282
5.3 Custom Settings	284
6 FAQs	285
6.1 How Do I Handle the Problem of Certificate Error or Security Alarm Displayed in the We	
6.2 How Do I Rectify a NetEco-NE Intermittent Disconnection Alarm?	
6.3 How Do I Install the Video Surveillance Subsystem Client?	
6.4 How Do I Add a Camera on the Video Surveillance Subsystem?	
6.5 How Do I Set Video Playback Parameters on the Video Surveillance Subsystem?	
6.6 How Do I Enable or Disable the Message Push Function	295

2022-02-25 vi

# **1** Getting Started

This section describes how to use the NetEco.

### 1.1 Logging In to or Logging Out of the NetEco

This section describes the operating environment requirements of the NetEco client and provides guidance for users to log in to or log out of the NetEco client.

#### 1.2 Setting NetEco Communications Parameters on the ECC800-Pro

The ECC800-Pro can connect to the NetEco only after communications parameters are set on the ECC800-Pro WebUI.

### 1.3 Connecting a Device (Through the App, Recommended)

You can use an app to connect a site to the NetEco for management. This method is recommended because it is more convenient.

### 1.4 Connecting a Device (Through the WebUI)

You can use a WebUI to connect a site to the NetEco for management.

# 1.1 Logging In to or Logging Out of the NetEco

This section describes the operating environment requirements of the NetEco client and provides guidance for users to log in to or log out of the NetEco client.

# 1.1.1 Operating Environment Requirements

To ensure that users can browse and perform operations on the NetEco client, the PC must meet certain requirements.

**Table 1-1** lists the requirements for the operating environment.

**Table 1-1** Operating environment requirements

Confi gurat ion Item	Basic Configuration Requirement
CPU	15-7500 or later

Confi gurat ion Item	Basic Configuration Requirement
Mem ory	8 GB
Oper ating syste m	Windows 10 Professional 64-bit

Confi gurat ion Item	Basic Configuration Requirement
Browser	You are advised to use the Chrome browser (stable channel edition) or Firefox browser (ESR edition) of the latest version.  If the user accesses the NetEco server through a proxy server, configure the proxy server as follows: For Chrome:  1. Click in the upper right corner of the browser and choose Settings.  2. On the Settings page, click Advanced, and then click Open proxy settings under System.  3. In the Internet Properties dialog box, click LAN settings. In the Proxy server dialog box, select Use a proxy server for your LAN, set Address and Port, and click OK.  4. Close the Settings tab page. For Firefox:  1. Click in the upper right corner of the browser and choose Options.  2. On the Options page, click Advanced, and then click Settings under Network.  3. In the displayed Connection Settings dialog box, select Manual proxy configuration, set HTTP proxy and Port, and click OK.  4. Close the Options tab page.  NOTE  To ensure that the proxy server can access the NetEco server, the network bandwidth must meet the following requirements:  Uplink (from the browser to the NetEco server) data rate: ≥ 100 kbit/s; downlink (from the NetEco server to the browser) data rate: ≥ 100 kbit/s; downlink (from the NetEco server to the browser) data rate: ≥ 100 kbit/s; for Chrome:  1. Click in the upper right corner of the browser, perform the following steps: For Chrome:  1. Click in the upper right corner of the browser and choose Settings.  2. On the Settings page, click Privacy and security under Advanced, and click Pop-ups and redirects under Site settings in sequence.  3. In the Pop-ups and redirects dialog box, click Add.  4. In the Add a site dialog box, enter https://server IP address:server port number (https://10.10.10.1:31943 for
	<b>example)</b> , and click <b>Add</b> .  5. Close the <b>Settings</b> tab page.  For Firefox:

Confi gurat ion Item	Basic Configuration Requirement
	<ol> <li>Click in the upper right corner of the browser and choose Options.</li> <li>On the Options page, click Content and Exceptions under Pop-</li> </ol>
	ups in sequence.
	<ol> <li>In the Allowed Sites dialog box, set Address of website to https://server IP address:server port number (https:// 10.10.10.1:31943 for example), click Allow, and then click Save Changes.</li> </ol>
	4. Close the <b>Options</b> tab page.

# 1.1.2 Logging In to the NetEco (Through HUAWEI CLOUD)

Log in to the NetEco through HUAWEI CLOUD.


# **Prerequisites**

- You have created a trial use order.
- The mobile number entered by the tenant has received the NetEco organization, password, and address.

### **Procedure**

**Step 1** Click **Enter Edge Data Center Managment** to enter the NetEco.

Figure 1-1 Entering the Enter Edge Data Center Managment page



Step 2 Enter Organization, User Name, and Password, and click Log In.

### □ NOTE

- When you log in to the system for the first time, Organization is the same as User
  Name and is the tenant name entered during tenant creation, that is, the initial
  username of HUAWEI CLOUD. This user is the administrator of the tenant and has the
  highest operation rights. After the first login, you need to change the password to
  ensure access security.
- If the number of online users reaches the maximum number supported by the system, a message is displayed indicating that you cannot log in. In this case, contact the administrator.
- If you enter incorrect passwords for three consecutive times, a verification code is required at the fourth time. If you enter incorrect passwords for five consecutive times, the account or IP address will be locked for 10 minutes.

----End

# 1.1.3 Logging In to the NetEco (Through the WebUI)

Log in to the NetEco through the WebUI.

# **Prerequisites**

- You have created a trial use order.
- The mobile number entered by the tenant has received the NetEco organization, password, and address.

### **Procedure**

**Step 1** In the address bar of a browser, enter <a href="https://edcm2.hwocloud.com">https://edcm2.hwocloud.com</a> and press <a href="https://edcm2.hwocloud.com">Enter</a>.

#### ∩ NOTE

- You are advised to use the Chrome browser (stable channel edition) or Firefox browser (ESR edition) of the latest version.
- You are advised to set the resolution of a PC screen to 1920 x 1080 or higher.
- When you log in to the NetEco for the first time, the web browser displays a certificate error. For details, see 6.1 How Do I Handle the Problem of Certificate Error or Security Alarm Displayed in the Web Browser.

### Step 2 Enter Organization, User Name, and Password, and click Log In.

### ■ NOTE

- When you log in to the system for the first time, Organization is the same as User Name and is the tenant name entered during tenant creation, that is, the initial username of HUAWEI CLOUD. This user is the administrator of the tenant and has the highest operation rights. After the first login, you need to change the password to ensure access security. If the number of online users reaches the maximum number supported by the system, a message is displayed indicating that you cannot log in. In this case, contact the administrator.
- If you enter incorrect passwords for three consecutive times, a verification code is required at the fourth time. If you enter incorrect passwords for five consecutive times, the account or IP address will be locked for 10 minutes.

----End

# 1.1.4 Logging Out of the NetEco

This section describes how to log out of the NetEco.

# **Prerequisites**

You have logged in to the NetEco.

### **Procedure**

- **Step 1** Move the cursor to the icon in the upper right corner of the home page and click **Log Out**.
- Step 2 In the displayed Log Out dialog box, click Yes.

The account is logged out, and the login page is displayed.

----End

# 1.2 Setting NetEco Communications Parameters on the ECC800-Pro

The ECC800-Pro can connect to the NetEco only after communications parameters are set on the ECC800-Pro WebUI.

# **Prerequisites**

- You have obtained the IP address of the ECC800-Pro as well as the user name and password used for WebUI login.
- You have obtained the IP address of the NetEco server.

### **Procedure**

- **Step 1** Enter https://monitoring IP address (such as https://192.168.1.10) in the address box of the browser, and then press **Enter** to enter the Web login page.
- **Step 2** On the login page, enter the user name and password, select a language, and click **Log In**.

- If you do not perform any operation within 10 minutes after logging in to the system, you will be logged out due to timeout.
- A maximum of three users can log in to the ECC800-Pro WebUI at the same time.
- **Step 3** Choose **System Settings** > **NMS Application**.
- **Step 4** Click the **NetEco** tab. In the **Communication Parameters** area, set parameters such as **Server IP**, **Port number**, and **Network port for link setup**, and click **Submit**.

### **Ⅲ** NOTE

The parameters to be set for the ECC800-Pro vary according to the software version. Set the parameters based on the actual version.

Table 1-2 NetEco parameters

Parameter Name	Value	
Server IP	Set this parameter to the IP address of the NetEco server.  NOTE  The NetEco IP address and the ECC800-Pro IP address must be configured in the same network to ensure normal connection between the NetEco and the ECC800-Pro.	
Port number	31220	
Network port for link setup	WAN_1	

#### ----End

# 1.3 Connecting a Device (Through the App, Recommended)

You can use an app to connect a site to the NetEco for management. This method is recommended because it is more convenient.

# 1.3.1 Installing the NetEco App

This section describes the requirements for the NetEco app running environment and how to download and install the NetEco app.

# **App Running Environment Requirements**

- Device: Only Android mobile phones are supported.
- Operating system: Android 8.0 or later. The system cannot be rooted. The system memory is 1 GB or above/larger.
- The device supports a web browser and can connect to the Internet at a rate of 500 kbit/s or higher.
- Enough space is available for installing new applications.
- The battery power is sufficient.

### **◯** NOTE

The device supports display at mainstream resolutions, such as  $1920 \times 1080$  and  $2340 \times 1080$ . To ensure the stability of each function,  $1920 \times 1080$  is recommended. It is strongly recommended that Android mobile phones provided by global mainstream vendors, such as SAMSUNG and HUAWEI, be used.

# Installing the App

### □ NOTE

Currently, the NetEco app supports only the Android version.

- Obtaining the software installation package from the Huawei AppGallery and installing the app
  - a. Go to **Huawei AppGallery** (website: https://appgallery.huawei.com) and search for NetEco.
  - b. Tap **Download** to obtain the app installation package.
    - Install the app as prompted.
      After the installation is complete, the NetEco app icon is displayed on the home screen of the mobile phone.
- Installing the NetEco app by scanning the QR Code

On the NetEco screen, tap in the upper left corner and use your mobile phone to scan the QR code in the lower right corner.

Figure 1-2 NetEco app QR code

# 1.3.2 (Optional) Replacing the App Certificate on a Mobile Device

This section describes how to replace the preset security certificate in the NetEco app on a mobile device. Preset Huawei certificates apply only to commissioning scenarios. For security purposes, apply for certificates from the certification authority (CA) and use them to replace the preset certificates. Using the same certificate for a long time increases the probability of being cracked. Replace the current certificate periodically.

# **Prerequisites**

• The NetEco app has been installed.

You have applied for a new certificate file server.cer from the CA.
 NOTE
 server indicates the name of the certificate file, which can be renamed.

, and the second se

### **Procedure**

- **Step 1** Import the obtained digital certificate to the **cer** directory in the NetEco folder of the mobile client.
- **Step 2** At the first login, select **EDCM** in the **System Service** area on the **Select Application** screen.
- **Step 3** On the **Server Settings** screen, set server information such as the tenant name, login address, and port number, and tap **Next**.

**Tenant Name** is the tenant name registered on HUAWEI CLOUD.

Figure 1-3 NetEco Server Settings





- **Step 4** On the **Login** screen, tap in the upper right corner.
- **Step 5** In the lower part of the **Login** screen, tap **Replace Certificate**.
- **Step 6** On the **Select File** screen, select the new certificate and tap **ALLOW** in the displayed dialog box.

----End

# 1.3.3 Logging In to the NetEco App

After the app is correctly installed on the mobile device, you can log in to the NetEco server through the app.

# **Prerequisites**

- The device has connected to a WiFi or mobile network.
- The NetEco app has been installed. For details, see 1.3.1 Installing the NetEco App.
- You have obtained the tenant name, user name, and password for logging in to the NetEco app, and have changed the initial password.
- You have obtained the IP address and port number of the NetEco server.

### **Procedure**

- **Step 1** On the mobile device, click the NetEco app icon.
- **Step 2** At the first login, select **EDCM** in the **System Service** area on the **Select Application** screen.
- **Step 3** On the **Server Settings** screen, set server information such as the tenant name, login address, and port number, and tap **Next**.

**Tenant Name** is the tenant name registered on HUAWEI CLOUD.

Figure 1-4 NetEco Server Settings



**Step 4** On the **Login** screen, enter **User Name** and **Password**.

### ■ NOTE

- User Name is the tenant name registered on HUAWEI CLOUD.
- If you fail to log in to the system for three consecutive times, the system automatically displays Verification Code.

### Step 5 Tap Log In.

After logging in to the NetEco app, enable or disable the **Push notifications** function as prompted. For details, see 6.6 How Do I Enable or Disable the **Message Push Function.** 

### **□** NOTE

During the operation, if no data is displayed on the screen or a message is displayed indicating that the network is abnormal, check whether the WiFi or mobile network connection of the mobile terminal is normal. If the network connection is normal, check whether the user is forcibly logged out on the NMS.

If a Huawei mobile phone is used, the **Push notifications** function is enabled by default in the NetEco app.

### ----End

# 1.3.4 Connecting to a Site

You can connect the site to the NetEco through the NetEco app.

# **Prerequisites**

- You have logged in to the NetEco.
- NetEco communications parameters have been set on the ECC800-Pro.

### **Procedure**

- **Step 1** On the NetEco app screen, tap + in the upper right corner.
- **Step 2** On the site creation screen, enter the DC information as prompted.

Figure 1-5 Creating a site




Table 1-3 Parameter description

Parameter	Description
Site name	Name of a site
ESN	ESN of the ECC controller  NOTE  Tap and scan the QR code on the ECC controller to obtain its ESN.
Customer information	Name of a customer
Site address	Address of a site
Longitude	Longitude of a site. You can manually enter the value or use the GPS to locate the site.
Latitude	Latitude of a site. You can manually enter the value or use the GPS to locate the site.
Detailed address	Detailed address of a site

Step 3 Tap OK.

----End

# 1.4 Connecting a Device (Through the WebUI)

You can use a WebUI to connect a site to the NetEco for management.

# 1.4.1 Adding a Management Domain

Before adding a device, you need to create a management domain based on the planned relationship between the management domain and the device.

### **Context**

The NetEco presets management domains such as parks, equipment rooms, subnets, cabinets, buildings, and floors.

- If the managed device is FusionModule800 or FusionModule2000, the management domain to be added is **Modular**.
- If the managed device is FusionModule500, the management domain to be added is **FusionModule500**.
- If the managed device is the FusionDC1000A, the management domain to be added is **Container**.

### **Procedure**

- **Step 1** Choose **Device Management > Configuration > Planning Configuration**.
- **Step 2** In the navigation tree, select the node to which you want to add a management domain.
- **Step 3** In the **Domain** area under the navigation tree, drag the management domain to be added to the configuration area.
- Step 4 On the right of the Planning Configuration page, set Management Info of the management domain by referring to 1.4.3.1 Basic Parameters of a Management
   Domain, and click in the upper right corner of the page.

When creating a management domain, you need to enter **Location**, **Longitude**, and **Latitude** in the **Management Info** area. Otherwise, the specific location of the device cannot be displayed on the **View** page.

----End

# 1.4.2 Adding a Device Through Automatic Discovery

You can add the ECC800-Pro to the smart module, AIO container, and FusionModule500 management domain through automatic discovery.

# **Prerequisites**

- A management domain has been created. For details, see 1.4.1 Adding a Management Domain.
- You have obtained device parameters.
- The ECC800-Pro is properly connected.

### **Procedure**


- **Step 1** Choose **Device Management > Configuration > Planning Configuration**.
- **Step 2** On the **Planning Configuration** page, click bin the upper left corner.
- **Step 3** On the **Uncreated Device Information** page, click **Access** in the **Operation** column.
- **Step 4** In the **Device Integration** dialog box, set parameters for the ECC800-Pro device by referring to **Figure 1-6**, and click **OK**.

You can view the task information, including **Type**, **Device Name**, **Region**, **Progress**, **Status**, **Start Time**, **End Time**, and **Information** in the displayed **Progress** page. You can view the operation details in **Information**.

#### 

- After the management domain is successfully bound to the ECC800-Pro, all devices under the ECC800-Pro will be displayed on the **Planning Configuration** page and their names can be manually modified. However, devices under the ECC800-Pro cannot be moved or deleted. You can only delete all devices under the ECC800-Pro by deleting the ECC800-Pro.
- The following lists the management domains that can be bound to different types of ECC800-Pro systems:
  - The ECC800-Pro whose system type is FusionModule500 can be bound to a FusionModule500 management domain.
  - The ECC800-Pro whose system type is FusionModule800, FusionModule2000, or FusionModule5000 can be bound to a smart module.
  - The ECC800-Pro whose system type is **FusionModule1000A** (the layout mode is available for the FusionModule1000A) can be bound to an AIO container.
- After in-room monitoring is set on the ECC800-Pro, the access actuators and cameras synchronized to the NetEco will be displayed in the smart modules (smart modules created in the equipment room, outlet, subnet, or container cluster) in the same positions as where they are deployed on the ECC800-Pro. After the access actuator and camera are deleted from the ECC800-Pro, the access actuators and cameras synchronized to the NetEco are displayed only in the list of devices that are not deployed in the smart module.

Figure 1-6 Adding the ECC800-Pro through automatic discovery



### □ NOTE

- If you do not specify Authenticate Password, the site is created using the default password.
   If you correctly specify Authenticate Password, the site is created using the specified password.
- During ECC800-Pro device synchronization, all opened NetEco pages are locked. In this
  period, you cannot perform any operations on these pages, and Loading device profile.
   Please try it later. is displayed. The locking duration varies. Perform operations based on the
  actual operation result.
- After ECC800-Pro device synchronization, you can check or configure Management Info, Assets Info, device information, and layout information of the device in the corresponding smart module in the Planning Configuration page as required.
- When modifying the switch states of air conditioners that use the BIN4 protocol on the **Planning Configuration** page, you need to enter the password on the NetEco.

----End

# Follow-up Procedure

After adding an ECC800-Pro device, you can perform operations on the device on the **Planning Configuration** page. The operations are as follows:

Modifying device parameters
 Select the added device and configure parameters in the right pane as required. Click in the upper right corner.

### □ NOTE

Names of the devices accessed through the ECC800-Pro comply with the following rules:

- For devices that are synchronized to the NetEco through the ECC800-Pro for the first time, if the names of the devices are not changed on the NetEco or ECC800-Pro WebUI, their default names are displayed.
- Device names modification on the ECC800-Pro WebUI will be synchronized to the NetEco. However, device names modification on the NetEco will be synchronized to the ECC800-Pro WebUI.
- Deleting a device
   Click a device and click **Delete** under **∑** to delete the device.
- Viewing the device view
   Click the device and choose Manage under ≥ to go to the device Overview page and view the device view.

# 1.4.3 Planning Configuration Interface Reference

This section describes the parameters in the **Planning Configuration** page.

# 1.4.3.1 Basic Parameters of a Management Domain

This section describes the basic parameters to be set when you create a management domain on the NetEco client.

Configure parameters as required. The parameter marked with an asterisk (\*) is mandatory.

**Table 1-4** Park, building, container, subnet, and FusionModule500 parameter configuration

Parame ter Name	Description	Setting Requirement
Parent Object	Upper-level management domain name	The system automatically identifies this name.
Туре	Management domain type	The system automatically identifies this type.
Name	Management domain name	The value is a string of 1 to 128 characters.
Manufa cturer	Manufacturer of the device	The value is a string of 0 to 64 characters.  NOTE  This parameter needs to be set when the domain is FusionModule500.
SN	Serial number of the created management domain	The value is a string of 0 to 128 characters.
Location	Physical location of the created management domain	The value is a string of 0 to 64 characters.
Plan Power (kW)	Total power for the created management domain	The value is a floating number ranging from 1 to 10,000,000 (three decimal places).  NOTE  This parameter needs to be set when the domain is Park or Building.
Descript ion	Description of the created management domain	The value is a string of 0 to 512 characters.
Longitu de	Longitude of the position where the created management domain is located	Value range: -180 to +180. A maximum of 10 decimal places are allowed.
Latitude	Latitude of the position where the created management domain is located	Value range: -90 to +90. A maximum of 10 decimal places are allowed.

**Table 1-5** Parameters for the Room and Site

Table 1-5 Parameters for the Room and Site		
Parame ter Name	Description	Setting Requirement
Parent Object	Upper-level management domain name	The system automatically identifies this name.
Туре	Management domain type	The system automatically identifies this type.
Room Type	Equipment room type, including DG Plant, High Volt. Distribution Plant, Low Volt. Distribution Room, Power Transformer Plant, UPS & Battery Room, Service Room, and Cooling Plant.	Select the room type as required.
Design Type	Site design type. You can set this parameter to floor planning or background planning.	Select the site design type as required.  NOTE  This parameter needs to be set when the domain is Site.
Name	Management domain name	The value is a string of 1 to 128 characters.
Planned Rack Position	Planned number of cabinet places in the created management domain. The number of cabinets in the equipment room cannot exceed the planned number of cabinet places.	The value is an integer ranging from 1 to 2000.  NOTE  The value of Planned Rack Position can be modified after it is set. The number of cabinets cannot exceed its planned number. Therefore, you should set enough number of planned cabinets to meet requirements in cabinet creation.

Parame ter Name	Description	Setting Requirement
Wire Laying	Cabling of the created management domain	Select <b>UpLine</b> or <b>Downline</b> from the down-down list box.
SN	Serial number of the created management domain	The value is a string of 0 to 128 characters.
Address	Address of the created management domain	The value is a string of 0 to 128 characters.
Depart ment	Department of the created management domain	The value is a string of 0 to 128 characters.
City	Name of the city where the created management domain is located	The value is a string of 0 to 128 characters.
Country	Name of the country where the created management domain is located	The value is a string of 0 to 64 characters.
Level	Level of the created management domain	Select <b>Tier 1, Tier 2, Tier 3, Tier 4, A, B</b> , or <b>C</b> from the drop-down list box.
Descript ion	Description of the created management domain	The value is a string of 0 to 512 characters.
Owner	Management personnel for the created management domain	The value is a string of 0 to 64 characters.

Parame ter Name	Description	Setting Requirement
Longitu de	Longitude of the position where the created management domain is located	Value range: -180 to +180. A maximum of 10 decimal places are allowed.
Latitude	Latitude of the position where the created management domain is located	Value range: –90 to +90. A maximum of 10 decimal places are allowed.
City Power Supply Mode	City power supply mode of the created management domain	Select <b>Dual power supply</b> or <b>Single power supply</b> from the drop-down list box.
Voltage Type (VAC)	Voltage system of the created management domain	Select <b>110V</b> , <b>220V</b> , or <b>380V</b> from the drop-down list.
UPS Workin g Mode	UPS working mode of the created management domain	Select N, N+X(X=1~N), 2N, or 2(N+1) from the drop-down list box.
Has Generat or	Whether a generator is installed in the created management domain	Select <b>Single Generator</b> , <b>Dual Generator</b> , or <b>NULL</b> from the drop-down list box.
Input Voltage	Input voltage of the created management domain	Select <b>6KV</b> , <b>10KV</b> , or <b>35KV</b> from the drop-down list box. <b>NOTE</b> This parameter needs to be set when the domain is <b>Site</b> .
Output Voltage	Output voltage of the created management domain	Select 110V, 220V, 380V, or 400V from the drop- down list box.  NOTE  This parameter needs to be set when the domain is Site.

Parame ter Name	Description	Setting Requirement
Plan Power (kW)	Total power supply for the created management domain	The value is a floating number ranging from 1 to 10,000,000 (three decimal places).
Frequen cy	Mains power frequency of the created management domain	Select <b>50Hz</b> or <b>60Hz</b> from the drop-down list box.
Cooling Mode	Refrigerating mode of the created management domain	Select Water Cooled Direct Expansion, Air Cooled Direct Expansion, Chilled-water refrigeration, Double-cold Source, or Free cooling from the drop-down list.
Air- Distribu tion	Air supply mode of the equipment room	Select Underfloor Air Distribution, Horizontal Air Distribution, Side displacement Air- distribution, Vertical Overhead Air Distribution, Horizontal overhead Air-distribution, or Fresh air convection from the drop-down list box.
Plan Refriger ating Capacit y (kW)	Cooling power of the created management domain	The value is a floating number ranging from 1 to 10,000,000 (three decimal places).

**Table 1-6** Parameters for the Container management domain

Parame ter	Description	Setting Requirement
Parent Object	Upper-level management domain name	The system automatically identifies this name.
Туре	Type of the added container	The system automatically identifies this type.
Contain er Type	Type of the container you can add	Select Device Container, Cooling Container, Generator Container, Power Container, NOC Container, AIO Container, Container Cluster, or Transformer.
Name	Name of the container	The value is a string of 1 to 128 characters.

Parame ter	Description	Setting Requirement
SN	SN of the added container	The value is a string of 0 to 128 characters.
Box Size	Size of the container	Select <b>20-Feet</b> or <b>40-Feet</b> .
Locatio n	Physical location of the added container	The value is a string of 0 to 64 characters.
Descript ion	Description of the added container	The value is a string of 0 to 512 characters.
Left Image, Right Image, Back	You can set Left Image, Right Image, and Back Image of a container.	NOTE  The container on the view uses the default image. To manually change the background image of the container, contact the technical support to obtain the image.  If the background image of the container is not set, Not
Image		Uploaded is displayed. After the background image of the container is uploaded, Wait Save is displayed. After you click in the upper area of the current page, Uploaded is displayed.  After the background image of the container is set, you can perform the following operations to check the
		setting in the <b>View</b> page.  Method: Click on the right of the position column. In the displayed <b>Upload Image</b> dialog box, click Select the obtained image on the
		local PC and click <b>OK</b> .  To delete the uploaded background image, click  , and then click <b>Clear</b> in the displayed <b>Upload Image</b> dialog box.
Count	You can select the number of containers to be combined.	You can combine two to twenty equipment containers.  NOTE This parameter needs to be set when Container Type is Container Cluster.
Childre n Name	You can set the name of a container.	The value is a string of 1 to 30 characters.  NOTE  This parameter needs to be set when Container Type is Container Cluster.

Table 1-7 Parameters for the Modular management domain

Name	Description	Setting Requirement
Parent Object	Management domain name of the smart module	The system automatically identifies this name.
Type	Type of a smart module	The system automatically identifies this type.
Name	Name of the smart module.	The value is a string of 1 to 128 characters.
Manufa cturer	Manufacturer of the device	The value is a string of 0 to 64 characters.
Directio n	Direction of the device	The default value is <b>Horizontal</b> . Select <b>Horizontal</b> or <b>Vertical</b> from the drop-down list box.
Layout	Layout of the device	The default value is single-row wide aisle1.  Select single-row wide aisle1, single-row wide aisle2, dual-row wide aisle, single-row narrow aisle1, single-row narrow aisle2, or single-row dual aisle from the drop-down list box.
Half- Size Cabinet	Number of half- sized cabinets in each row of the smart module	The default value is <b>11</b> .  Number of half-sized cabinets in each row of the smart module. The value is an integer ranging from 4 to 50.
Locatio n	Position of the smart module in the management domain	The value is a string of 0 to 64 characters.
Install Mode	Installation mode of the smart module	The default value is <b>Floor Installation</b> .  Select <b>Floor Installation</b> , <b>Cabinet Installation</b> , <b>Wall Installation</b> , or <b>Ceiling Installation</b> .
Wire Type	Cabling mode of the smart module	The default value is <b>Ascending Line</b> . Select <b>Ascending Line</b> , <b>Down Line</b> , or <b>Floor Line</b> .
Airflow Type	Heat dissipation channel of the smart module.	The default value is Vertical Under-Floor Air-Distribution.  Select Vertical Under-Floor Air-Distribution, Horizontal Displacement Air-Distribution, Side Displacement Air-Distribution, Vertical Overhead Air-Distribution, Horizontal Overhead Air-Distribution, or Natural Convection Overhead Air-Distribution.

Name	Description	Setting Requirement
Aisle Size	Width of the aisle in the smart module	The default value is <b>1200</b> .  The value is an integer ranging from 0 to 65,535.
Height	Height of the smart module	The default value is <b>2300</b> . Select <b>2300</b> , <b>2500</b> , or <b>2800</b> from the drop-down list box.
Aisle Contain ment Type	Aisle containment type of a smart module	The default value is <b>Cold Aisle</b> .  Select <b>Hot Aisle</b> or <b>Cold Aisle</b> from the dropdown list box.

# 1.4.3.2 Basic Device Parameters

This section describes the basic parameters that need to be set when you create a device on the NetEco client.

They include but are not limited to the following parameters. Configure parameters as required. The parameter marked with an asterisk (\*) is mandatory.

Table 1-8 Description of device parameters

Attribute	Parameter	Description
Managem ent Info	Parent Object	Name of the management domain to which the device belongs
	Туре	Type of the device
	Name	Name of the device The value is a string of 1 to 128 characters.
	Med Node	Node ID used at the mediation layer
	Protocol Type	Protocol version for the device

Attribute	Parameter	Description
	IP Address	It must be an IPv4 address in the X.X.X.X format, where X is a number ranging from 0 to 255. In addition, 0.0.0.0 is not allowed.
		<ul> <li>When the device protocol is MODBUS_TCP, set the IP address of the data collector to which the device connects.</li> </ul>
		<ul> <li>When the device protocol is MODBUS_RTU, set the IP address of the data collector to which the device connects.</li> </ul>
		When the device protocol is Simple Network     Management Protocol (SNMP), set the IP address     of the device.
		When the device protocol is CInterface, set the IP address of the device.
	Port	The value is an integer ranging from 0 to 65,535.
		<ul> <li>When the device protocol is MODBUS_TCP, set the corresponding port of the device. The port is 502 by default.</li> </ul>
		When the device protocol is MODBUS_RTU, set the port number of the data collector to which the device connect.
		When the device protocol is SNMP, set the corresponding port of the device. The port is 161 by default.
		When the device protocol is CInterface, set the corresponding port of the device.
	Device Address	The value is an integer ranging from 0 to 255.
		When the device protocol is MODBUS_TCP or MODBUS_RTU, set the address of the device.
		When the device protocol is SNMP, the device address parameter does not exist.
		When the device protocol is CInterface, the device address parameter does not exist.
		NOTE  The value combination of the IP Address, Port, and Device  Address must be unique to each device.

Attribute	Parameter	Description
	Out Time	Time when testing the connection times out. The default value is three seconds.
		The value is an integer ranging from 1 to 60.  NOTE
		<ul> <li>When the NMS delivers a heartbeat message to the device, the device determines that the device does not respond if the duration exceeds the value of this parameter.</li> </ul>
		<ul> <li>This parameter affects the detection speed when the device is disconnected. The heartbeat is invalid only when the time specified in <b>Out Time</b> is reached. In this case, the device may be disconnected.</li> </ul>
		<ul> <li>This parameter affects the packet response success rate of the device. If the device takes 2 seconds to respond to the NMS and <b>Out Time</b> is set to less than 2 seconds, the device does not receive any response.</li> </ul>
	Security Name	Name of a user  NOTE Specify this parameter when configuring devices that support the SNMPv3 protocol.
	Context Name	Context name of the managed object
		The value is a string of 0–60 characters and cannot
		contain special characters ,"#%&'+/\;<=>? .
	Authenticati on Protocol	Set this parameter to the value of <b>Authentication Protocol</b> configured on the device. The default value is <b>SHA</b> .
		The <b>SHA</b> and <b>MD5</b> protocols are supported.
		<b>NOTE</b> Specify this parameter when configuring devices that support the SNMPv3 protocol.
		NOTICE  MD5 is an insecure protocol. SHA is recommended.
	Authenticati on Password	Set this parameter to the authentication password configured on the device.
		Value range: a–z, A–Z, 0–9, _ (8–15 characters, at least two types of characters, different from the user name or its reverse)
		<b>NOTE</b> Specify this parameter when configuring devices that support the SNMPv3 protocol.
		You are advised to set <b>Authentication Password</b> and <b>Privacy Password</b> to different values.

Attribute	Parameter	Description
	Privacy Protocol	Set this parameter to the value of <b>Privacy Protocol</b> configured on the device. The default value is <b>AES128</b> .
		The AES128 and CBC_DES protocols are supported.  NOTE Specify this parameter when configuring devices that support the SNMPv3 protocol.  NOTICE
		DES is an insecure protocol. AES is recommended.
	Privacy Password	Set this parameter to the proprietary protocol key configured on the device.
		Value range: a–z, A–Z, 0–9, _ (8–15 characters, at least two types of characters, different from the user name or its reverse)
		NOTE Specify this parameter when configuring devices that support the SNMPv3 protocol.
		You are advised to set <b>Authentication Password</b> and <b>Privacy Password</b> to different values.
	Context	Context engine ID of the managed object
E	Engine ID	The value is a string of 0–60 characters and cannot contain special characters ,"#%&'+ $\$ :<=>?
	Read Community	Set this parameter to the read community configured on the device.
		Modifying the community per three months is advised.
		NOTE Specify this parameter when configuring devices that support the SNMPv1/v2 protocol.
	Write	Set the write community configured on the device.
	Community	Modifying the community per three months is advised.
		NOTE Specify this parameter when configuring devices that support the SNMPv1/v2 protocol.

Attribute	Parameter	Description
	Connection Mode	Connection mode of a device. You can set this parameter to Non-SSL Connection or SSL Connection.
		If you modify the connection mode on the NMS, you must modify the connection mode on the device WebUI accordingly.  NOTE
		The connection mode settings for the NMS and device must be the same.
		<ul> <li>By default, Connection Mode is set to SSL Connection for the NMS and device.</li> </ul>
	Authenticati on Password	Re-authentication password for the NMS and device  1. Click <b>Modify</b> .
		In the displayed dialog box, enter <b>New Password</b> and <b>Confirm Password</b> .
		NOTE
		The password must contain 8 to 32 characters.
		<ul> <li>The password includes at least three of the following types: lowercase letters, uppercase letters, digits, and special characters (~!@#^*_={}:,./?-`\$). If the password does not comply with the rules, please change the password on the device side.</li> </ul>
		Change the password periodically (every three or six months) to improve system security and prevent security risks, such as violent password cracking.
		3. Select a value for <b>Send To Device</b> .
		NOTE  If you select YES, the re-authentication password for the NMS and device is changed at the same time. If you select NO, only the re-authentication password for the NMS is changed.
		4. Click <b>OK</b> .
		NOTE You can only change the re-authentication password for the ECC800-Pro.
	Camera Code	The camera code specified in the intelligent video surveillance system contains 15 digits. For details, see <i>Device Installation and Commissioning Guide</i> .
		NOTE The camera code is the value of <b>Device ID</b> whose last three digits are replaced with <b>101</b> . For example, if the value of <b>Device ID</b> is <b>87871900000000</b> , the value of <b>Camera Code</b> is <b>878719000000101</b> .

Attribute	Parameter	Description
Bind AccessCon troller	AccessContr oller	When creating a fingerprint controller, you can set whether to bind the fingerprint controller to the corresponding access controller.  NOTE  The fingerprint controller must be bound to the TycoSun access controller for use.  The access controller to be bound must be in single-card mode.
	Door Passage	When creating a TycoSun access controller, Door Passage is Enabled by default. You can set Door Passage to Enabled or Disabled as required.  NOTE When creating a fingerprint controller, if a door passage whose status is Enabled, the fingerprint controller can bind the door passage.
Setting UPS	UPS	When creating an iBOX, you can set whether to bind UPSs in the same management domain.
Electricity Info	Rated Power (kW)	Rated power consumption of a device The value is a floating number ranging from 0 to 65,535 (three decimal places).
	Power Mode	Click , and choose Single power supply or Dual power supply.
Asset Info	Model	Model of the device.  The value is a string of 0 to 64 characters.
	Manufacture r	Manufacturer of the device The value is a string of 0 to 64 characters.
	Serial Number	Serial number of the device upon delivery The value is a string of 0 to 64 characters.
	Lock Number	The value of this parameter cannot be modified.
	Weight (kg)	Weight of the device
	SN	Device number The value is a string of 0 to 64 characters.
	Location	Location of the device in the management domain The value is a string of 0 to 64 characters.
	Airflow Type	Select Front to Rear, Bottom to Top, Side Left to Side Right, Side Right to Side Left, or Front to Top.

Attribute	Parameter	Description
	Status	Device status Select <b>Enabled</b> , <b>Power-on</b> , <b>Power-off</b> , <b>Idle</b> , or <b>Offline</b> .
	Project No.	The value is a string of 0 to 64 characters.
	Start Date of Use (yyyy-MM- dd)	Device activation time
	Temperature Range (°C)	Temperature range in which the device works properly The value can be modified.
	Owner	The value is a string of 0 to 64 characters.
	Department	The value is a string of 0 to 64 characters.
	Installation Mode	The installation modes of different devices are different. Select the installation mode as required.  Select Floor Build In, Cabinet Build In, Wall Build In, or Ceiling installation. The cabinet and PDU also support installation modes of Antistatic floor installation and Cement floor installation.
	Wire Type	Select <b>Ascending Line</b> , <b>Down Line</b> , or <b>Floor Line</b> .
Status Info	Start Date Of Use (yyyy-MM- dd)	Start date of use of the device
	Last Maintenanc e (yyyy- MM-dd)	Last maintenance time of the device
Extended Info	Rated Output Power (kW)	Rated output power of the device The value is an integer ranging from 0 to 65,535.
	Rated Cooling Capacity (kW)	Rated cooling capacity of the device
	Distribution Area	Select Inlet Side or Outlet Side.
	Install Height (m)	Select <b>0.6</b> , <b>1.2</b> , or <b>1.8</b> .

2022-02-25

Attribute	Parameter	Description
	Temperature Range (°C)	Temperature range in which the device works properly  The value can be modified.
		The value can be mounted.
	Installation Mode	The installation modes of different devices are different. Select the installation mode as required.
		Select Floor Build In, Cabinet Build In, Wall Build In, or Ceiling installation. The cabinet and PDU also support installation modes of Antistatic floor installation and Cement floor installation.
Protocol Info	Number of Heartbeats	Indicates that the device is disconnected for <i>N</i> consecutive heartbeat failures. The default value is <b>3</b> .
		The value is an integer ranging from 1 to 3.  NOTE  This parameter affects the speed at which the NMS detects device disconnection.
	Heartbeat Period (s)	Interval for the NMS to send heartbeat detection messages to the device to determine whether the device is connected.
		The value is an integer ranging from 1 to 10,000.
		NOTE  The default value varies according to protocols.
	Sending Interval	Interval at which the device sends each packet. The default value is 600 ms.
	(ms)	The value is an integer ranging from 50 to 10,000.
		NOTE  This parameter affects the packet processing efficiency.  Based on the response efficiency of the device, the device can process a packet within the interval specified by Sending Interval (ms), which is the highest efficiency.
	Receiving Timeout (ms)	Indicates the timeout period for the NMS to receive packets from the device. The default value is 1000 ms.
		The value is an integer ranging from 500 to 10,000.

# 2 Device Management

Through device management, the layout and running status of devices on the network can be displayed in real time.

#### 2.1 Device View

You can set views for the system to intuitively display equipment positions and running status.

#### 2.2 Configuration

This section describes how to configure device management.

#### 2.3 Alarm Management

The NetEco provides management functions such as monitoring network alarms, querying alarms or events, and setting remote alarm notifications. These functions help you quickly detect, locate, and rectify network faults.

### 2.4 Predefined Big Screen

# 2.1 Device View

You can set views for the system to intuitively display equipment positions and running status.

## 2.1.1 Device View

You can set views for the system to intuitively display equipment positions and running status. This facilitates status monitoring for the entire network.

## 2.1.1.1 Managing Views

The **View** page displays the layout and running status of devices in the equipment room, and monitors the running status of devices on the entire network in real time. In addition, the system intuitively displays the physical environment of devices in the management domain view in 2D or 2.5D mode, facilitating efficient O&M and quick fault locating.

## **Prerequisites**

- The device has been connected to the NetEco.
- You have the operation rights for **View**.

## **Context**

## **CAUTION**

- Exercise caution when shutting down the smart cooling product. Doing so may cause devices and equipment room overheating, which will damage the devices.
- Exercise caution when powering off the rPDU or PDU2000. Doing so may affect the power supply to equipment, which will interrupt services.

## **Procedure**

- **Step 1** Choose **Device Management > Device Vew > View**.
- **Step 2** On the **View** page, view the overview information about managed objects on the entire network.

Table 2-1 Operation task

Operatio n	Description	Procedure
Modifying scenario names	Perform this operation when you want to modify the name of a scenario.	<ol> <li>Click in the upper left corner of the page. The Scenario-based Configuration dialog box is displayed.</li> <li>Click in the Operation column to</li> </ol>
		modify the scenario name, and click <b>OK</b> .

Operatio n	Description	Procedure
Viewing the overview of managed objects on the entire network	You can view the number of nodes with alarms of each severity, number of nodes without alarms, total number of alarms, and maintenance information. In addition, you can scan the QR code to install the NetEco app.	<ul> <li>In the upper left area of the page, view the number of nodes with alarms of each severity and the number of nodes without alarms.</li> <li>In the Alarm area on the right of the page, view the total number of alarms and the number of alarms of each severity for managed objects on the entire network.</li> <li>In the Maintenance area on the right of the page, view the maintenance information about the managed objects on the entire network.</li> <li>In the Download APP area on the right of the page, you can scan the QR code to install the NetEco app.</li> </ul>

**Step 3** View the management domain view.

- 1. Access the management domain.
  - Method 1: Click the search box on the left of the page. In the expanded navigation tree, select a management domain.

#### □ NOTE

To query and select a management domain by setting search criteria, perform the following operations:

- In the Recommended Filter area, click Connection Status: Connected or Connection Status: Disconnected, and then click the name of the management domain.
- Enter a keyword in the text box, click , and click the management domain
- Method 2: Double-click the management domain icon to access the management domain.
- 2. To view the detailed information about a management domain and the information about all the devices in the management domain, perform the following operations as required.

Table 2-2 Viewing the management domain view

Ope ratio n	Description	Procedure
Swit chin g to the 2D or 2.5D mod e	The 2D or 2.5D mode displays the layout of devices, device running status, alarm status, and signal counter status in the management domain on a plane.	Click a on the toolbar on the left.
View ing the over view infor mati on age men t dom ain	You can view basic information about submanagement domains or devices in a management domain, and information about Statistics of Faulty Devices, License Consumption, and Statistics of Disconnected Devices in the management domain.	<ol> <li>Click on the toolbar on the left.</li> <li>On the Overview page, you can perform the following operations:         <ul> <li>You can click a device name to go to the device view page and click a management domain to go to the management domain view page of the device.</li> <li>You can click the device running status icon in the Alarm Status column to go to the Alarm tab page of the device and view the current alarm information of the device.</li> <li>The value of License Consumption is the total number of licenses consumed by devices in the management domain.</li> </ul> </li> <li>NOTE         <ul> <li>If the device is a non-intelligent device, redirection is not supported.</li> </ul> </li> </ol>
View ing coun ter mon itori ng infor mati on	You can view the real- time monitoring counter signal information about IT cabinets in the management domain, and view or modify the device monitoring view to learn about the running status of devices based on the real-time signals of the devices.	<ol> <li>Click on the toolbar on the left to view the real-time monitoring counter signal information about the IT cabinets.</li> <li>In the Signal dialog box, click in the Operation column to view the monitoring view.</li> <li>NOTE         <ul> <li>To modify a monitoring view, click Modify in the Monitoring View dialog box.</li> </ul> </li> </ol>

Ope ratio n	Description	Procedure
Addi ng a cont rol elem ent	An entry for directly adding control elements is provided on the <b>View</b> page.	Click on the toolbar on the left and drag the control to a proper position in the view. For details, see 2.1.1.2 Adding Control Elements.  NOTE  You can add controls in the toolbox to the management domain only when is displayed.
Conf iguri ng a mon itori ng view	You can view and modify the monitoring view to learn the running status of a device. Only signal counters of key devices can be modified.	Click on the toolbar on the left. For details, see 2.1.1.3 Configuring a Monitoring View.
View ing cam era infor mati on	If cameras have been added to the management domain, you can view camera information and play video.	Click on the toolbar on the left to view camera information. To play a video, click the name of an online camera in the <b>Name</b> column.

Ope ratio n	Description	Procedure
View ing envir onm ent infor mati on abo ut a man age men t dom ain	The following lists the devices and methods for measuring the temperature and humidity of the environment module.  - Air conditioner: average supply air and return air temperature and humidity  - Sensor/Collector: The sensor/collector with temperature and humidity counters collects the reported temperature and humidity values and participates in calculation. If a smart module is deployed, the statistics result is displayed by cold aisle and hot aisle.  I Click Environment for a device except cabinets. In the displayed Average temperature and humidity change curve dialog box, you can view the average temperature and humidity in 24 hours, top 10 highest temperature and humidity values, and top 10 lowest temperature and humidity values, and top 10 lowest temperature and humidity values of the management domain.	In the right pane of the page, view the environment information about the management domain.

Ope ratio n	Description	Procedure
	■ Click Environment for a cabinet. In the displayed Average temperature change curve dialog box, you can view the average temperature of the cabinet in 24 hours. You can click Avg Temperature (Front) or Avg Temperature (Back) to display or hide the trend chart. If an item is highlighted, the corresponding trend chart is displayed.	

	ratio n	Description	
		NOTE  If the management domain is a smart module, the status of the smoke detector and water sensor is displayed. If the management domain is a cabinet, the status of the smoke detector and door status sensor is displayed.	
		- A door status sensor state can be Closed, Opened, Unknown, or Not Configured. Unknown indicates that the door status sensor is bound to indicators and the door status information is not obtained. Not Configured indicates that no door status sensor control is created or no counter is bound. You can click on the left of the page. For details about how to configure a door status sensor control, see 2.1.1.2 Adding Control Elements. On the 2.5D view page, the door status sensor state is displayed in Environment after the Door state counter is bound to the door status sensor control.	
		- The water sensor state can be Normal, Alarm, or Not Configured. Not Configured indicates that no water sensor control is created or no counter is bound. You can click on the left of the page. For details about how to configure a water sensor control, see 2.1.1.2 Adding Control Elements. On the 2.5D view page, the water sensor state is displayed as Normal or Alarm in Environment after the appropriate counter and alarm are	
2022-02-25		bound to the water sensor control (the bound alarm must be an uncleared alarm in the current alarm list).  - The smoke detector	40

Procedure

Description

Ope

Ope ratio n	Description	Procedure
Quer ying man age men t dom ain alar ms	By default, the number of uncleared alarms collected by alarm severity and device type in the equipment room is displayed.  NOTE  The device types are as follows:  - Power supply: PDU, UPS, ATS, DG, transformer, battery string, and rPDU  - Cooling: water chiller, pump, cooling tower, and air conditioner  - Environment: sensors, such as the water sensor, smoke detector, and temperature and humidity sensor in equipment rooms or smart modules  - Security: access controller and camera  - Others: alarms reported	<ol> <li>In the right pane of the page, view the alarm information about the management domain.</li> <li>Click Alarm to go to the Current Alarms page.</li> </ol>
	by the ECC	

## **Step 4** View the device view.

- 1. Enter the device view.
  - Method 1: Click the search box on the left of the page. In the expanded navigation tree, select a device in the equipment room.
  - Method 2: Double-click the device name on the View page.

Displays device information such as overview, alarms, and signals, helping you learn about the device status in real time and handle abnormal data to better understand the device running status.

2. View details about the device view and perform the following operations as required.

#### **◯** NOTE

For Air conditioner\_NetCol5000-A025\_BIN4 and Air conditioner\_NetCol5000-A042\_BIN4, if an alarm is generated for the internal fan, heater, electronic expansion valve, humidifier, air filter, compressor, or external fan of the air conditioner, the corresponding component is displayed in the color set for the alarm severity in the air conditioner logical flow diagram.

**Table 2-3** Operation task

Operation	Description	Procedure
Viewing basic device information	Displays the basic device information, energy flow diagram, and real-time data of some counters, and provides a quick entry for modifying device configuration information.	In the left pane of the page, view the basic information, energy flow diagram, and real-time data of some counters of devices.  NOTE  If you need to modify the device configuration information, click Edit to go to the Planning Configuration page.
Viewing monitoring counters for devices	You can set device monitoring counters to effectively monitor devices for timely handling of abnormal data.	<ol> <li>Select a device and click in the upper right corner of the page.</li> <li>In the Setting dialog box, select counters and click OK.</li> </ol>
Viewing the comprehensi ve analysis of devices	Displays the changes of concerned counters in trend charts, status charts, and comparison charts, helping you understand the comprehensive analysis of devices in a timely manner.	On the Comprehensive Analysis tab page in the upper part of the page, view the comprehensive analysis of devices.  NOTE  To display multiple comprehensive analysis tab pages and set the chart style or layout, click in the upper right corner of the tab page.
Viewing KPI information	Displays concerned KPIs in a list. You can set the display of more KPIs, and view and modify the monitoring views of KPIs to learn about the detailed running status of devices. Only signal counters of key devices can be modified.	<ol> <li>On the KPI tab page in the upper area of the page, click</li> <li>Select the counter to be bound and click OK.</li> <li>Click in the Operation column to display the monitoring view of the counter.</li> </ol>

Operation	Description	Procedure
Viewing control signal information	Displays the AO/DO signal of the device in a list. You can set the display of more control signals, and view and modify the monitoring views of control signals to learn about the detailed running status of devices. Only signal counters of key devices can be modified.	<ol> <li>On the Signal tab page in the lower part of the page, click .</li> <li>Select the counter to be bound and click OK.</li> <li>Click in the Operation column to display the monitoring view of the counter.</li> <li>Click in the Operation column to set the real-time control signal value and deliver the signal remotely.</li> </ol>
Viewing device signals	Allows you to view real-time device running signals to learn about the device running status.	<ol> <li>On the Signal tab page in the lower part of the page, view the monitoring signal information about devices.</li> <li>Click in the Operation column of the device signal value counter. In the displayed Monitoring View dialog box, view and modify the monitoring view.</li> </ol>
Managing device alarms	Allows you to view and handle device alarms in a timely manner.	On the <b>Alarm</b> tab page in the lower part of the page, view the alarm details of the device.

----End

## 2.1.1.2 Adding Control Elements

You can add control elements and view control details on the **View** page. Each control can describe objects in the equipment room view, monitor devices in real time, and link to other view pages.

# **Prerequisites**

You have the operation rights for View.

## **Procedure**

- **Step 1** Choose **Device Management > Device Vew > View**.
- **Step 2** Click the search box on the left of the page to expand the navigation tree and select a management domain.

**Step 3** On the toolbar on the left, click and drag the control to a proper position in the view.

**◯** NOTE

The 2.5D view button is unavailable in the park, building, and floor views.

**Step 4** In the **Property Panel** dialog box, set the basic properties of the control in the **Basic Properties** area.

Table 2-4 Setting control attributes

Operation	Procedure	
Binding counters	<ol> <li>Click — next to Counter.</li> <li>In the Select Data dialog box, select the managed objects and counters to be added and click OK.</li> </ol>	
Binding alarms	<ol> <li>Click — next to Current Alarm.</li> <li>In the Select Data dialog box, select the alarm to be bound, and then click OK.</li> <li>NOTE         You can bind a maximum of 20 alarms to a device in the equipment room. After alarms are bound to a device, the counter control icon is displayed in the color of the alarm with the highest severity when alarms are raised for the device.     </li> </ol>	
Setting control icons		

Step 5 In the Extended Properties area, set extended attributes of the control and click  $\times$  .

**Step 6** Move the mouse to the top of the control to display the control measurement information.

#### 

- To modify the basic properties or extended properties of a control, perform the following operations:
  - 1. Double-click the control icon.
  - 2. In the **Property Panel** dialog box, modify the basic properties or extended properties of the control, and then click  $\times$ .
- To delete a control, click the control icon, choose ≥, and click Delete.

----End

## 2.1.1.3 Configuring a Monitoring View

Provides functions such as setting the layer of the view page.

## 2.1.1.3.1 Managing the Service Layer

On the **View** page, you can select a service layer to quickly switch the service layer view to be displayed.

## **Procedure**

- **Step 1** Choose **Device Management > Device Vew > View**.
- **Step 2** Click the search box on the left of the page to expand the navigation tree and select a management domain.
- **Step 3** Click on the toolbar on the left.
- **Step 4** On the **Monitor View Config** page, choose **Business Layer Management**.

To reselect a management domain, click **Choice** on the **Business Layer Management** page.

**Step 5** On the **Business Layer Management** page, perform the following operations based on the application scenario.

Table 2-5 Managing the service layer

Operation	Procedure
Managing service layers	<ul> <li>Adding a service layer</li> <li>1. Click Add.</li> <li>2. In the Add Layer dialog box, set Service Layer Name and click OK.</li> </ul>
	<ul> <li>Modifying a service layer</li> <li>In the Service Layer area, select a service layer,</li> <li>change the service layer name, and click Save.</li> </ul>
	<ul> <li>Deleting a service layer</li> <li>In the Service Layer area, select a service layer and click Delete.</li> </ul>
Monitoring signal of the management control	<ul> <li>Adding a monitoring signal for the control</li> <li>In the Service Layer area, select a service layer and click Create.</li> <li>In the Create control dialog box, set Device and</li> </ul>
	<ul><li>Measurement Object, and then click Next.</li><li>3. Set Measurement Counter and Control Type, and then click OK.</li></ul>
	<ul> <li>Modifying the monitoring signal of the control</li> <li>In the Service Layer area, select a service layer and click Edit in the Operation column.</li> </ul>
	<ol> <li>In the Property Panel dialog box, modify the basic attributes and extended attributes, and then click OK.</li> </ol>
	NOTE  To apply the basic or extended properties of the control to other management domains and devices, click <b>Apply</b> to Others.
	<ul> <li>Deleting the monitoring signal of a control         In the Service Layer area, select a service layer, select         one or more monitoring counters, and click Delete.</li> </ul>

----End

## Follow-up Procedure

After the service layer configuration is complete, click **Back to View** in the upper right corner of the **Business Layer Management** page to return to the view. On the **View** page, you can view the service layer view.

- 1. Click the search box on the left of the page to expand the navigation tree and select a management domain.
- 2. Click on the toolbar on the left to switch to the 2D view.
- 3. Click on the toolbar on the left to view the corresponding service layer view.

## 2.1.1.3.2 Setting the Quick Navigation Bar

On the **View** page, you can customize the navigation bar. After a quick navigation bar is added, the navigation bar can be displayed on the **View** page, helping users quickly switch the view angle.

### **Procedure**

- **Step 1** Choose **Device Management** > **Device Vew** > **View**.
- **Step 2** Click the search box on the left of the page to expand the navigation tree and select a management domain.
- **Step 3** Click on the toolbar on the left.
- Step 4 On the Monitor View Config page, choose Quick Navigation Config.
- **Step 5** On the **Quick Navigation Config** page, perform the following operations based on the application scenario.

**Table 2-6** Managing the navigation bar

Operation	Procedure
Managing the navigation bar	<ul><li>Adding a navigation bar</li><li>1. Click <b>Add</b>.</li></ul>
	<ol><li>In the Add Navigation Bar dialog box, set Navigation bar name and click OK.</li></ol>
	<ul> <li>Modifying a navigation bar</li> <li>In the Navigation Bar area, select a navigation bar,</li> <li>change the navigation bar name, and click Save.</li> </ul>
	<ul> <li>Deleting a navigation bar</li> <li>In the Navigation Bar area, click Delete.</li> </ul>
Managing quick	Adding quick navigation
navigation	<ol> <li>In the Navigation Bar area, choose a navigation bar and click Create.</li> </ol>
	<ol><li>In the Create Quick Navigation dialog box, set the related parameters, and then click OK.</li></ol>
	Modifying quick navigation
	<ol> <li>In the Navigation Bar area, click  in the Operation column.</li> </ol>
	<ol><li>In the Property Panel dialog box, modify the related parameters, and then click OK.</li></ol>
	<ul> <li>Deleting quick navigation</li> <li>In the Navigation Bar area, select one or more quick navigation records, and click Delete.</li> </ul>

----End

## 2.1.1.3.3 Setting View Display Parameters

You can set parameters such as the display mode of the navigation tree and view, whether to display the O&M index, and overview.

### **Procedure**

- **Step 1** Choose **Device Management > Device Vew > View**.
- **Step 2** Click the search box on the left of the page to expand the navigation tree and select a management domain.
- **Step 3** Click on the toolbar on the left.
- **Step 4** On the **Monitor View Config** page, choose **Data Center View Settings**.
- Step 5 On the Data Center View Settings page, set related parameters and click Apply.

----End

## 2.1.1.3.4 Device Page Settings

On the **View** page, you can view the energy flow diagram of key devices by default and set the display effect of the page.

## **Procedure**

- **Step 1** Choose **Device Management > Device Vew > View**.
- **Step 2** Click the search box on the left of the page to expand the navigation tree and select a management domain.
- **Step 3** Click on the toolbar on the left.
- **Step 4** On the **Monitor View Config** page, choose **Device Page Settings**.
- **Step 5** On the **Device Page Settings** page, click **Create** in the upper right corner.
- **Step 6** In the **Create** dialog box, set the related parameters, and then click **OK**.

To delete a created device page, select one or more device pages and click **Delete**.

----End

# 2.1.2 Battery Management

This section describes how to check the SOH of batteries and battery groups in the root node, or in a building, equipment room, or other region, handle abnormal batteries in a timely manner.

## **Prerequisites**

Battery devices communicate with the NetEco properly.

#### **Procedure**

- **Step 1** Select **Device Management > Device View > Battery Management**.
- **Step 2** Check battery SOH, take lead-acid batteries as an example.

#### □ NOTE

Under the root node, click the position of the faulty battery or the name of the battery group to go to the battery group information page.

- Check the SOH of a battery group under the management domain.

  In the navigation tree on the left, choose the root node, building or equipment room to check the status of a faulty battery or a faulty battery group in the whole region.
- Check the SOH of a battery group under the device.
   In the navigation tree on the left, choose the device to check the status of basic information, a faulty battery, a faulty battery group in the whole region.
- Check the SOH of a single battery group.

In the navigation tree on the left, choose the battery group to check the overview and historical trend of the group. You can view the battery group in real time in chart, table, or discharge curve form. The number of batteries in that group is also displayed.

#### **◯** NOTE

- Click <sup>III</sup> to sort battery strings by counter.
- Click the battery to go to the **Battery analysis** page. You can view the battery status in chart or table form. Besides, data can be exported from that page.
- Lithium ion battery relative to lead-acid battery, Highest Temperature and Lowest
   Temperature and Highest Voltage and Lowest Voltage are measured.

----End

## Follow-up Procedure

You can perform the following operations on the **Check the battery health status** page.

Operation	Procedure
Checking historical data	Click the name of a counter to set whether to display the counter in the view. If the name is highlighted, the counter is displayed in the historical trend chart. If the name is unavailable, the counter is not displayed in the chart.
	<ul> <li>Click  ,select a data area to display the data of the specified area.</li> </ul>
	Click  to restore the zoomed view.
	Click to restore the zoomed page.
	<ul> <li>Click  to save the historical trend chart as a picture.</li> </ul>
	Click = to check the SOH in tables.
Exporting Historical Data	Exporting Historical Battery String Data     Click in the lower right corner of <b>History Trend</b> to export the historical battery string data.
	Exporting Historical Battery Data
	<ul> <li>Click a battery in the table view. On the Battery Analysis page that is displayed, click Export to export historical battery data.</li> </ul>
	<ul> <li>Click in the upper right corner of the table view, In the displayed Battery</li> <li>Analysis, On the page, click Export and export historical battery data.</li> </ul>

# 2.2 Configuration

This section describes how to configure device management.

# 2.2.1 Planning Configuration

On the **Planning Configuration** page, you can create, modify, and delete management domains and devices.

## 2.2.1.1 Relocating Management Domains or Devices

You can use the relocate function to relocate the management domain or device to be relocated to the target management domain.

#### Procedure

- **Step 1** Choose **Device Management > Configuration > Planning Configuration**.
- **Step 2** On the **Planning Configuration** page, click **Relocate** on the toolbar.
- **Step 3** In the **Relocate Domain or Device** dialog box, select the management domain or device to be relocated and the target management domain, and then click **OK**.

----End

## 2.2.1.2 Synchronizing Device Configuration Data to the NetEco

When the configuration data of a device changes, you can use the synchronization function of the NetEco to synchronize the data on the NetEco with the data on the device. This ensures data consistency between the NetEco and the device.

## **Prerequisites**

The device is properly connected.

#### Context

After a device is created, the NetEco automatically synchronizes configuration data from the device when the network connection is normal. In this case, the configuration data on the NetEco is the same as that on the device. In the subsequent maintenance, you may need to modify the configuration parameters on the device directly. This may result in the inconsistency of the configuration data between the device and the NetEco. To ensure data consistency, the NetEco provides two synchronization modes: automatic synchronization and manual synchronization. For details, see Table 2-7.

**Table 2-7** Device configuration data synchronization modes and mechanisms

Synchr	onization	Synchronization	Advantages and
Mode		Mechanism	Disadvantages
Auto matic synch roniz ation	Periodic automatic synchronizati on	The NetEco initiates data synchronization to the device once every five days.	The synchronization time is fixed, which can ensure data synchronization to some extent. However, the synchronization period is long.

Synchr Mode	onization	Synchronization Mechanism	Advantages and Disadvantages
	Triggered automatic synchronizati on	When the configuration data of a device changes or a component is added to or removed from a device, the device sends a synchronization notification to the NetEco. After receiving the notification, the NetEco immediately initiates data synchronization.	Due to network problems, the NetEco may fail to receive synchronization notifications and therefore cannot initiate data synchronization in a timely manner.
Manua synchro	l onization	Data synchronization is initiated immediately.	Data can be synchronized in time.

### **Procedure**

- **Step 1** Choose **Device Management > Configuration > Planning Configuration**.
- **Step 2** On the **Planning Configuration** page, click .
- **Step 3** In the **Synchronize** dialog box, select a device, and then click **OK**.

----End

# 2.2.2 Managing Device Signals

You can change the name of a counter through signal management to identify the counter more easily.

## **Prerequisites**

- You have the **Signal Management** permission.
- You have logged in to the NetEco client using a web browser.

## **Procedure**

- **Step 1** Choose **Device Management > Configuration > Signal Management**.
- **Step 2** In the navigation tree on the left, select the device to be modified and perform the following operations as required.

Table 2-8 Managing signals

Operation	Description	Procedure
Customizing signals	You can customize device signals, bind signal data sources, and modify or delete signals.	<ol> <li>On the Sampling, Statistics, or Configuration tab page, click Customize Signal.</li> <li>On the Customize</li> </ol>
		<b>Signal</b> page, perform the following operations as required:
		<ul><li>– Customizing signals</li></ul>
		a. On the Sampling Signals or Statistical Signals tab page, click Create Signal.
		b. In the <b>Create</b> dialog box, click <b>Add</b> .
		c. Set signal parameters and click <b>Save</b> .
		- Binding signal data source On the Sampling Signals or Statistical Signals tab page, select one or more signals and click Batch Bind. Or click in the Operation column.
		<ul> <li>Modifying signals</li> <li>On the Sampling</li> <li>Signals or</li> <li>Statistical Signals</li> </ul>
		tab page, click / in the <b>Operation</b> column.
		<ul> <li>Deleting signals</li> <li>On the Sampling</li> <li>Signals or</li> </ul>

Operation	Description	Procedure
		Statistical Signals tab page, select one or more signals and click Delete. Or click in the Operation column.

Operation	Description	Procedure
Managing signals	You can modify parameters such as the signal name and collection period as required. In addition, you can apply the modified signal parameters to devices of the same type in batches.	<ul> <li>Modifying a single signal On the Sampling, Statistics, or Configuration tab page,, modify the related parameters of the signal, and then click Apply.</li> <li>Modifying signals in batches On the Sampling, Statistics, or Configuration tab page, modify the related parameters of the signal, and then click Batch Apply.</li> <li>NOTE</li> <li>If you have modified signal parameters but have not clicked Apply or Batch Apply, you can click Revoke to restore the original parameter settings.</li> <li>If you have modified signal parameters and clicked Apply or Batch Apply, you can click Revert to restore the original parameter settings.</li> <li>The View, Planning Configuration, and Historical Data pages will display the modified signal names of counters. (On the Historical Data page, if you select a single device, the modified counter name is displayed.)</li> </ul>

----End

# 2.3 Alarm Management

The NetEco provides management functions such as monitoring network alarms, querying alarms or events, and setting remote alarm notifications. These functions help you quickly detect, locate, and rectify network faults.

# 2.3.1 Viewing and Handling Current Alarms

On the **Current Alarms** page, O&M personnel can view current alarms that are updated in real time to learn the latest alarm status and handle the alarms.

## 2.3.1.1 Viewing Current Alarms

The **Current Alarms** page displays current alarms that are updated in real time.

### Context

- If a new alarm is reported and the number of current alarms exceeds the upper capacity threshold, alarm management enables the mechanism of processing full current alarm cache and moves some alarms to the historicalalarm list.
- When you go to the **Current Alarms** page for the first time, alarms in the alarm list are sorted in descending order of **Arrived On** by default.
- The newly reported alarms are displayed in bold on the page.
- The background color of cleared alarms is green by default.
- You can only monitor and view alarms of authorized MOs.
- A maximum of 200 **Current Alarms** pages can be opened.

#### **Procedure**

- Monitoring alarms
  - a. Choose **Device Management > Alarms Management > Current Alarms** from the main menu.
  - Table 2-9 describes alarm monitoring methods.

**Table 2-9** Alarm monitoring methods

Task	Task Description
Monitoring alarms using the alarm list	On the <b>Current Alarms</b> page, monitor the alarms reported by all NEs and systems in real time.
Monitoring alarms using alarm indicators	The alarm indicators in the upper right corner of the <b>Current Alarms</b> page show the number of critical alarms, number of major alarms, number of minor alarms, and number of warning alarms.

Task	Task Description	
Monitoring alarms using the statistics panel	Click in the upper right corner of the <b>Current Alarms</b> page to view the alarm statistics charts.  The statistical result is obtained based on the filtered alarms.	
	The Top 10 Alarms, Duration, Top 10 Alarm Sources, Severity, and Status statistical charts can be displayed on the statistics panel. Four statistical charts can be displayed at the same time. You can click in the upper right corner of the statistics panel and then select the chart to be displayed from the drop-down menu in the upper right corner of each chart.	
	On the statistics panel, you can click any statistical result to quickly display the alarms that meet the condition. If you close the statistics panel, the filter criteria selected on the panel are automatically deselected.	
	Alarm management allows a maximum of 10 statistics panels to be opened by online users concurrently.	
	You can click in the upper right corner of the statistics panel to manually refresh the statistical data. Within 10 minutes after you open the statistics panel or manually refresh the statistical data, the system automatically refreshes the data every minute.	

### Querying alarms

- a. Choose **Device Management > Alarms Management > Current Alarms** from the main menu.
- b. You can click **Template Management** in the upper left corner of the page to view all filter templates and select a filter template from the **Quick Filter** panel. Users with the **Administrators** role can manage templates saved by all users.

The following types of templates are provided:

- Favorite: You can add the templates that you often use to your favorites.
- Custom: The template is customized by the current user. You can set whether to share the template with other users. You can set a custom template as the key template. The alarms that are filtered using the key template are displayed in both the emergency maintenance notification list and alarm list.
- Shared: Such a template can be shared with other users.

- Default: Default filter template.
- Other: Filter templates that are not shared by other users. Other templates are visible only to users assigned the **Administrators** role.

#### 

The filter templates on the **Current Alarms**, **Historical Alarms**, and **Masked Alarms** pages are independent of each other and cannot be shared.

- c. If the filter templates under **Template Management** do not meet your requirements, click **Filter** in the upper left corner of the **Current Alarms** page to set filter criteria. Set filter criteria and click OK to search for the alarms to be concerned about and handled.
- d. Click **Save** or **Save As** to save the current filter criteria as a filter template. Not only the filter criteria, but also the alarm display column information and the combo sorting information configured by users are saved in the filter template.
- e. Export current alarms. Alarms can be exported to an .xlsx or .csv file. When the exported file format is set to .xlsx and the number of alarms exceeds 100,000, the file is exported as a .zip package. When the exported file format is set to .csv and the number of alarms exceeds 10,000, the file is exported as a .zip package.
  - Export some alarms: Select the alarms to be exported, click Export, and choose Selected.
  - Export all alarms: Click Export and choose All.

#### 

Only the information about the alarm columns displayed on the page can be exported. You can click in the upper right corner of the alarm list to set the alarm columns to be displayed.

## **Parameter Description**

For details about parameters on the alarm filter panel, see **Table 2-10**.

Table 2-10 Description of parameters on the alarm filter panel

Parameter	Description
Alarm name	Name of the alarms to be queried. You can import or export the selected alarms or export all alarms when adding alarms.
Alarm source	Device or NE where an alarm is generated.  If multiple alarm source conditions are set, the filtering result is the union of all the conditions. That is, all the alarms that meet any of the conditions are displayed on the page.
Severity	Alarm severity, including critical, major, minor, and warning. By default, all alarm severities are selected. You must select at least one alarm severity.

Parameter	Description	
Alarm status	Alarm status, including the acknowledgment and clearance status, maintenance status, and validity status.  This parameter is not displayed on the <b>Masked Alarms</b> page.	
Last occurred	Time when the alarm last occurred.  This parameter is displayed as <b>Occurred</b> in <b>Alarm Logs</b> , <b>Masked Alarms</b> , and <b>Historical Alarms</b> , indicating the last occurrence time of an alarm.	
Cleared	Time when an alarm is cleared. You can set this parameter in the <b>Advanced settings</b> area on the <b>Alarm Logs</b> or <b>Historical Alarms</b> page. This parameter is not displayed on the <b>Masked Alarms</b> page.	

Parameter	Description	
Advanced settings	You can set alarm parameters to filter desired alarms.	
	If advanced criteria are set, the filtering result is determined by the intersection of all the criteria. That is, only the alarms that meet all the advanced criteria are displayed.	
	Operators (case-sensitive):	
	• <b>contains</b> : Filters the alarms that contain the specified character string.	
	• <b>does not contain</b> : Filters alarms that do not contain the specified character string.	
	• <b>begins with</b> : Filters alarms that begin with the specified character string.	
	• <b>ends with</b> : Filters alarms that end with the specified character string.	
	• <b>is in</b> : Filters the alarms that are the same as the specified character string. For example, in the <b>Location Info</b> area, set <b>Operator</b> to <b>is in</b> and set <b>Value</b> to <i>XXX</i> . In this case, the location information of the filtered alarms contains <i>XXX</i> , and the alarms whose location information contains <i>XXX</i> <b>123</b> are not displayed.	
	• <b>is not in</b> : Filters alarms that are different from the specified character string. For example, in the <b>Location Info</b> area, set <b>Operator</b> to <b>is not in</b> and set <b>Value</b> to <i>XXX</i> . In this case, the location information of the filtered alarms does not contain <i>XXX</i> , and the alarms whose location information contains <i>XXX</i> <b>123</b> are displayed.	
	• is blank: Filters the alarms if their values of this parameter are empty.	
	• is not blank: Filters the alarms if their values of this parameter are not empty.	
	To improve the maintenance efficiency, you are advised to retain the default settings of <b>Associated alarm ID</b> , that is, <b>Root alarms</b> , <b>Aggregated alarms</b> , and <b>Normal alarms</b> are selected. This parameter is not displayed on the <b>Masked Alarms</b> or <b>Historical Alarms</b> page. Meanings of the options:	
	Normal alarms: Indicates that the alarm does not have root alarms or correlative alarms and aggregated alarms or original alarms.	
	Root alarms: Alarm that causes multiple correlative alarms.	
	Correlative alarms: Alarm that is generated due to the root alarm.	
	<ul> <li>Aggregated alarms: After an alarm that meets the aggregation rules is reported, a new alarm is generated, which corresponds to multiple original alarms.</li> </ul>	

Parameter	Description	
	Original alarms: Alarms that meet the aggregation rules correspond to an aggregated alarm.	

For details about parameters in the alarm list, see Table 2-11.

**Table 2-11** Description of parameters in the alarm list

Name	Description	
Alarm Serial Number	Alarm SN. When an alarm is generated, it may be modified multiple times. For example, its severity may change or it may be cleared. The SN uniquely identifies an alarm.	
Alarm Matched Rule Name	An alarm meets the rule and is handled according to the rule settings.	
Occurrences	Number of occurrences or merged times for an alarm of an alarm source, that is, the repeated or merged alarms have the same location information and alarm ID. This parameter helps users to increase concerns on the alarm.	
	This parameter is not displayed on the <b>Masked Alarms</b> or <b>Historical Alarms</b> page.	
Alarm Source	Device or NE that generates an alarm.	

Name	Description	
Name	Name of an alarm. An alarm name tells what faults occur on an alarm source. For example, the high CPU usage alarm can be known by its name that the alarm is sent from the CPU.	
	The meanings of the icons displayed next to alarm names are as follows:	
	This icon is displayed when an alarm is a root alarm. You can expand the row that contains the alarm in the list to view its correlative alarms.	
	• this icon is displayed when an alarm is a correlative alarm. You can expand the row contains the alarm in the list to view its root alarms.	
	• *: This icon is displayed when an alarm is an original alarm.	
	•	
	• 4: This icon is displayed when the alarm is a toggling alarm. Expand <b>Filter criteria</b> and set <b>Toggling Identifier</b> in the <b>Advanced settings</b> area to filter alarms.	
	• 📆: This icon is displayed when an alarm reference page is available for an alarm. Click this icon to view the alarm reference page.	
	This icon is displayed when an alarm has remarks.  Click the alarm name to view the remarks on the alarm details page.	
Alarm ID	ID of an alarm, which corresponds to the alarm name.	
Severity	Four alarm severities: critical, major, minor, and warning.	
Acknowledgment Status	Acknowledgment status of the alarm. Available options are:  • Acknowledged  • Unacknowledged	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Clearance Status	Clearance status of an alarm. Available options are:  • Cleared	
	Uncleared	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	

Name	Description		
Toggling Times	Number of times that alarms that meet the toggling conditions are reported during the toggling.  This parameter is not displayed on the <b>Masked Alarms</b>		
	page.		
Possible Causes	Possible causes of an alarm, which can provide guidance for alarm handling.		
Maintenance Status	Maintenance status of an alarm. For example, the <b>NORMAL</b> state means that the alarm source is running normally instead of being commissioned or upgraded.		
	This parameter is not displayed on the <b>Masked Alarms</b> page.		
Acknowledged	Time when an alarm is acknowledged.		
On	This parameter is not displayed on the <b>Masked Alarms</b> page.		
Cleared On	Time when an alarm is cleared.		
	This parameter is not displayed on the <b>Masked Alarms</b> page.		
Alarm Source Identifier	Identifier allocated by alarm management to the source system.		
Alarm Source Type	Type of the NE where an alarm is generated.		
Туре	Type of an alarm, indicating the type of the cause which triggers the alarm.		
Operation	Operations that users can perform on the alarm.		
	Acknowledge the alarm		
	Clear the alarm		
	Send notifications by emails		
	Send SMS message notifications		
	Set masking rules		
	Set an identification rule		
	Set a notification rule		
	Set an intermittent/toggling rule     Set an appropriate multi-		
	Set an aggregation rule     Switch the winner		
	Switch the view		
Location Info	Information that helps you quickly locate the location where the alarm is generated.		

Name	Description	
First Occurred	If the alarm is a merged alarm, the time when it first occurred is displayed. If the alarm is not a merged alarm, its generation time is displayed.	
	This parameter is not displayed on the <b>Masked Alarms</b> or <b>Historical Alarms</b> page.	
Arrived On	Time when the alarm arrives at alarm management.	
Last Occurred	If the alarm is a merged alarm, its last occurrence time is displayed. If the alarm is not a merged alarm, its generation time is displayed.	
	On the <b>Masked Alarms</b> and <b>Historical Alarms</b> pages, this parameter is displayed as <b>Occurred</b> .	
Acknowledged By	User who acknowledges the alarm. If the alarm is unacknowledged, the user who unacknowledges the alarm is displayed in the <b>Acknowledged By</b> column.	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Cleared By	User who clears the alarm.	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Handler	Username of the current alarm handler. The O&M personnel can assign alarms to handlers.	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Auto Clear	Whether an alarm can be automatically cleared.	
	Yes: The alarm can be automatically cleared. After the fault that triggers the alarm is rectified, Clearance     Status of the alarm automatically is changed to Cleared.	
	No: The alarm cannot be automatically cleared. After the fault that triggers the alarm is rectified, you must manually clear the alarm.	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Other Information	Information irrelevant to alarm locating to help users understand the alarm.	
Comments	Alarm comments entered by users. The comments cannot exceed 512 characters.	
	Setting method: Select an alarm and click <b>Comment</b> to enter comments.	
Reason ID	ID of the alarm cause.	

Name	Description	
Clearance Type	Alarm clearance type:	
	(Blank): uncleared.	
	<ul> <li>normal clear: A device fault is rectified and alarm management receives a clear alarm. Then the alarm is automatically cleared.</li> </ul>	
	• <b>restore clear</b> : After a device restarts, alarm management detects whether a fault exists. The original fault alarm is automatically cleared.	
	manual clear: An alarm is manually cleared.	
	configure clear: A resource object is deleted, and the alarms generated by the resource object are automatically cleared.	
	correlation clear: When receiving a root alarm of uncleared correlative alarms, alarm management handles the alarms using a correlation rule, reports the root alarm, and automatically clears the correlative alarms. The clearance type of the correlative alarms is correlation clearance.	
	clear from system: The system clears earlier alarms according to the full-cache processing rule because the storage space is limited.	
	• <b>status switch clear</b> : Because the device status switches, the active alarm in the previous status is automatically cleared and is reported again in the device status after the switch. The clearance type of the active alarm in the previous status is status switch clearance.	
	alarm synchronization-based clear: During alarm synchronization, if some uncleared alarms exist in alarm management but cannot be found in the alarms synchronized from NEs, these uncleared alarms are automatically cleared.	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Validity	The default value is <b>Valid</b> . You can set it to <b>Invalid</b> on the <b>Identification Rules</b> page.	
	This parameter is not displayed on the <b>Masked Alarms</b> page.	
Duration	Duration from <b>Last Occurred</b> to <b>Cleared On</b> .  This parameter is not displayed on the <b>Masked Alarms</b> page.	
Resource ID	ID of the alarm source.	
Device Category	Alarm source categories.	

Name	Description	
Threshold Rule	Threshold for reporting an alarm, that is, the threshold of the fault-related measurement indicator. For example, the "High Ambient Temperature" alarm is reported when the ambient temperature exceeds the threshold.	
Threshold Information	When a threshold-crossing alarm is reported, the alarm generation value is displayed in the threshold information. When the threshold-crossing alarm is cleared, the alarm generation and clearance values are displayed in the threshold information.	
	NOTE  The clearance value is displayed in the threshold information only when the threshold-crossing alarm is cleared.	

For details about the parameters on the **Alarm Information** tab page, see **Table 2-12**.

Table 2-12 Description of the Alarm Information tab page

Tab Page	Description	Operation Method
Alarm Details	For details about alarm parameters, see .  NOTE  If the alarm reference is available, click the link next to Causes and Suggestions to switch to the alarm reference page.	To set the parameters to be displayed on the <b>Details</b> tab page, click <b>Select Fields</b> in the upper right corner of the <b>Details</b> tab page.
Handling and Experience	On the <b>Handling</b> tab page, you can view alarm handling recommendations preconfigured in alarm management.	To modify the experience records, click <b>Experience</b> . On the tab page that is displayed, click <b>Modify</b> , record the experience, and then click <b>Save</b> .
	On the <b>Experience</b> tab page, you can view or modify alarm handling experience.	
Comments	On the <b>Comments</b> tab page, you can add comments for the alarm.	To modify comments, click  Modify in the upper right corner of the tab page, enter comments, and then click Save.

Tab Page	Description	Operation Method
Handling Records in Last 2 Months	You can view all manual operations performed on the alarm in the last two months for O&M personnel to handle alarms.	-
Root Alarms/ Correlative Alarms	<ul> <li>If the reported alarm is a root alarm, the         Correlative Alarms tab page is displayed. You can view its correlative alarms.</li> <li>If the reported alarm is a correlative alarm, the Root Alarms tab page is displayed. You can view its root alarms.</li> <li>If the reported alarm is a root alarm and a correlative alarm, the Root Alarms and Correlative Alarms tab pages are displayed.</li> </ul>	
Aggregated Alarm/ Original Alarms	<ul> <li>If the reported alarm is an aggregated alarm, the Original Alarms page is displayed. You can view the alarms that have been aggregated into this alarm.</li> <li>If the reported alarm is an original alarm, the Aggregated Alarm tab page is displayed. You can view the alarm into which it has been aggregated.</li> </ul>	_

For details about the parameters on the **Template Management** panel, see **Table 2-13**.

**Table 2-13** Buttons on the Template Management panel

Button	Description	Operation Method
Search Template	You can search for a filter template based on the template name, name of the user who created the template, or comments.	<ol> <li>On the Quick Filter panel, enter a template name, username, or comment in the search box.</li> <li>Click to search the template.</li> </ol>
Share/ Unshare	You can share or cancel the sharing of custom templates. You can also select a template shared by other users from the <b>Shared</b> area.  The administrator can share or cancel the sharing of all templates except the default templates. Other users can only share or cancel the sharing of custom templates.  The template is not shared.  The template is shared.	1. On the <b>Quick Filter</b> panel, select the desired template.  2. Click the icon next to the template name.
Add to Favorites/ Remove from Favorites	You can add a template to or remove a template from your favorites. The favorite template will be displayed in the Favorite area.  You can only perform the following operations on the preset templates: Add to Favorites, Remove from Favorites, Set as Default Template, or Cancel Default Template.  The template is not added to favorites.  The template is added to favorites.	
Set as Default Template/ Cancel Default Template	You can set or cancel the default template for the current page. Filtered alarms will be displayed based on the default template when you enter this page.  The template marked with $\bigcirc$ is the default template.	<ol> <li>On the Quick Filter panel, select the desired template.</li> <li>Click next to the template or click and choose Set as Default Template or Cancel Default Template.</li> </ol>

Button	Description	Operation Method
Rename	Renames a filter template.  The administrator can rename all the templates except the templates in the <b>Default</b> area. Other users can rename only custom templates.	<ol> <li>On the Quick Filter panel, select the desired template.</li> <li>Click on the right of the template.</li> <li>Choose Rename from the displayed menu.</li> <li>In the dialog box that is displayed, enter the new template name.</li> </ol>
Modify Comments	Modifies the comments of a filter template.  The administrator can modify the comments of all templates except the templates in the <b>Default</b> area. Other users can modify only the comments of the custom templates.	<ol> <li>On the Quick Filter panel, select the desired template.</li> <li>Click on the right of the template.</li> <li>Choose Modify Comments from the displayed menu.</li> <li>In the dialog box that is displayed, modify the comments.</li> </ol>
Delete	Deletes a filter template. The administrator can delete all the templates except the templates in the <b>Default</b> area. Other users can delete only custom templates.	<ol> <li>On the Quick Filter panel, select the desired template.</li> <li>Click on the right of the template.</li> <li>Choose Delete from the displayed menu.</li> </ol>
Open Template on New Tab	A new tab page is opened and the list of the alarms or events that are filtered using the filter template is displayed on the new tab page.	<ol> <li>On the Quick Filter panel, select the desired template.</li> <li>Click on the right of the template, or click and choose Open Template on New Tab.</li> </ol>

# 2.3.1.2 Handling Alarms

In alarm management, O&M personnel can perform operations on alarms, such as specifying a handler, acknowledging alarms, and clearing alarms, to facilitate troubleshooting.

## **Prerequisites**

You have the following operation permissions: **Alarm Operation**, **Clear Alarm** and **Synchronize NE Alarms**.

### **Context**

Alarm management comprises the following alarm operations: acknowledging alarms, clearing alarms, changing alarm severities, and setting alarms to the invalid or maintenance state. **Table 2-14** describes alarm acknowledgement and clearance operations. **Figure 2-1** shows the relationships between alarm statuses.

**Table 2-14** Alarm handling operations

Paramet er	Function	Description
Acknowl edge	Identifies the user who handles an alarm to avoid one alarm being handled by multiple users.	After an alarm is acknowledged, the alarm will be or has been handled. When the alarm is acknowledged, the alarm status is changed from unacknowledged to acknowledged.
		If you want another engineer to handle the alarm, you can unacknowledge the alarm. When the alarm is unacknowledged, the alarm status is changed from acknowledged to unacknowledged.
Clear	Identifies whether the fault that causes an alarm is rectified.	When a fault occurs on the interconnected NE or in the system, an alarm is generated. When the fault is rectified, a clear alarm is generated and the alarm is cleared. If the system fails to receive the clear alarm or the alarm cannot be automatically cleared due to a network fault, you need to manually clear the alarm.
		When you manually clear the alarm, an alarm clearance command is sent from alarm management, and then the corresponding NE or system clears the corresponding alarm.

Unacknowledged and unacknowledged alarms

Clear

Cleared and acknowledged and acknowledged alarms

Figure 2-1 Alarm status relationship

Based on the alarm acknowledgment and clearance status, alarms are classified into:

- Current alarms: include uncleared and unacknowledged alarms, acknowledged and uncleared alarms, and unacknowledged and cleared alarms. O&M personnel can monitor and handle alarms that they are concerned about on the Current Alarms page.
- Historical alarms: include alarms that have been cleared and acknowledged.
   Historical alarms are a data source for network performance optimization.
   O&M personnel can query and collect statistics on alarms.

### **Procedure**

**Step 1** Choose **Device Management > Alarms Management > Current Alarms** from the main menu.

**Step 2** On the **Current Alarms** page, you can perform the following operations:

Operatio n	Scenario	Operation
Viewing alarm details	Obtains key alarm information, including alarm names, repair recommendations, and location information, to facilitate fault diagnosis and troubleshooting.	In the alarm list, select an alarm and click  below the list to view the alarm details.
Manually acknowle dging an alarm	An acknowledged alarm indicates that the alarm is being handled by the user whose name is displayed in the <b>Acknowledged By</b> column. When the alarm is acknowledged, the alarm status is changed from unacknowledged to acknowledged.	You can select one or more alarms and click <b>Acknowledge</b> above the alarm list. You can also click in the <b>Operation</b> column of the row that contains the desired alarm.  After you have acknowledged an alarm, the username is displayed in the <b>Acknowledged By</b> column.

Operatio n	Scenario	Operation
Specify a handler	Assigns the O&M personnel to handle an alarm.	In the alarm list, select an alarm and click "" in the <b>Operation</b> column to select a user to handle the alarm.  After the alarm is acknowledged, the username is displayed in the <b>Handler</b> column.
Manually clearing alarms	Some alarms cannot be automatically cleared. Therefore, you need to clear the alarms manually after the faults are rectified.	You can select one or more alarms and click Clear above the alarm list. You can also click in the Operation column of the row that contains the desired alarm.  If an alarm has been acknowledged after being cleared, the alarm will be moved to the Historical Alarms page.  If an alarm has not been acknowledged after being cleared, it is retained on the Current Alarms page, with a green background.  NOTE  The cleared alarm cannot be restored. Exercise caution when performing the operation.
Recording maintena nce experienc e	After handling an alarm, the O&M personnel can record the handling experience for future reference in a timely manner.  Choose Device Management > Alarms Management > Alarm Settings from the main menu. In the navigation pane, choose Experience to manage the experience records.	In the alarm list, select an alarm, click below the list, and click <b>Modify</b> in the <b>Experience</b> area.
Quick entries for setting alarm rules	O&M personnel can quickly set rules related to an alarm from the quick entries. Only authorized users can perform related operations. For details about the rules, see Table 2-15.	In the <b>Operation</b> column that contains a desired alarm, click to select a rule to be set.

Table 2-15 Introduction to quick entries for rules

Rule	Description
Send Email Notification	The information about the selected alarms is immediately sent to O&M personnel by email.  NOTE  To send notifications to relevant personnel, you need to enter their personal information, such as mobile numbers and email addresses. You are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that the user's
Send SMS Message Notification	personal information is fully protected.  The information about the selected alarm is immediately sent to the O&M personnel by SMS message.  NOTE  To send notifications to relevant personnel, you need to enter their personal information, such as mobile numbers and email
	addresses. You are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that the user's personal information is fully protected.
Set Masking Rule	You can set an alarm masking rule to mask alarms that you are not concerned about. The masked alarms will not be displayed on the <b>Current Alarms</b> page.
Set Identification Rule	After an identification rule is set, the system automatically sets a status identifier for the alarms that match the rule. When monitoring or querying alarms, you can set filter criteria to filter out the alarms. For example, you can set the alarms generated in commissioning scenarios to <b>Maintenance status</b> .
Set Notification Rule	The system automatically sends the information about alarms that meet the rule conditions to O&M personnel based on the notification method and content template set in the rule. In this way, the O&M personnel can learn about the alarm information and take corresponding measures in a timely manner.
Setting Intermittent/ Toggling Rule	After a rule is set, intermittent or toggling alarms can be discarded or masked to reduce interference caused by repetitive alarms.
Set Aggregation Rule	After an aggregation rule is set, the system automatically aggregates the repeated alarms reported within the specified period into one alarm.

----End

# **Parameter Description**

Table 2-16 Buttons in the alarm operation bar

Button	Description
Auto Refresh	<ul> <li>Enable: Alarms on the current page are refreshed in real time. By default, alarms are refreshed every 3 seconds.</li> <li>Disable: Locks the alarms on the current page. In this case, only the alarm information on the current page is updated. If other alarms are reported, the alarms are not displayed on the page.</li> </ul>
Quick Filter	Displays selected alarms quickly.
Refresh interval	Changes the automatic refresh interval. When an alarm is reported to the NMS, the NMS obtains the alarm reporting frequency.
Combo Sorting	Sorts alarms by multiple alarm fields. A maximum of four alarm fields can be set.
Clear	When the fault that triggers an alarm is rectified but the alarm is not cleared automatically, click <b>Clear</b> to manually clear the alarm. After the alarm is cleared, its status is changed to <b>Cleared</b> .
Acknowledge/ Unacknowledge	After an alarm is acknowledged, the alarm will be or has been handled. When the alarm is acknowledged, the alarm status is changed from unacknowledged to acknowledged. If you want another engineer to handle the alarm, you can unacknowledge the alarm. When the alarm is unacknowledged, the alarm status is changed from acknowledged to unacknowledged.
Specify Handler	Specifies the user who handles the alarm. The specified handler is displayed in the <b>Handler</b> column. The options are as follows: <b>Myself</b> , <b>Other Users</b> , and <b>Cancel</b> .
Comment	Edits the comments of an alarm.
Export	Alarms can be exported to an .xlsx or .csv file. When the exported file format is set to .xlsx and the number of alarms exceeds 100,000, the file is exported as a .zip package. When the exported file format is set to .csv and the number of alarms exceeds 10,000, the file is exported as a .zip package.  A maximum of five users can export some alarms at a time, and a maximum of two users can export all alarms at a time.

Button	Description	
Set as Invalid/Set as Valid	Sets selected alarms as invalid alarms or valid alarms. When monitoring or querying alarms, you can set filter criteria to filter out such alarms, improving alarm handling efficiency. The O&M personnel can set alarms that they are not concerned about as invalid alarms.	
Set as Under Maintenance/Set as Normal	Sets selected alarms to the maintenance or normal state. When monitoring or querying alarms, you can set filter criteria to filter out such alarms, improving alarm handling efficiency. For example, you can set the alarms generated in commissioning scenarios to <b>Maintenance status</b> .	
Send Email Notification	Immediately sends information about the selected alarms to O&M personnel by email.  NOTE  To send notifications to relevant personnel, you need to enter their	
	personal information, such as mobile numbers and email addresses. You are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that the user's personal information is fully protected.	
Send SMS Message	Immediately sends the information about the selected alarm to the O&M personnel by SMS message.	
Notification	NOTE  To send notifications to relevant personnel, you need to enter their personal information, such as mobile numbers and email addresses. You are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that the user's personal information is fully protected.	

# 2.3.2 Historical Alarms

By analyzing historical alarms, users can understand device running statuses and determine whether rules are properly configured.

# **Prerequisites**

- By default, 20,000 historical alarms can be displayed. When the number of alarms exceeds the upper limit, the first 20,000 alarms are displayed based on the filter criteria and sorting. If you want to query other alarms, you can modify the filter criteria and sort the alarms.
- You can only monitor and view alarms of authorized MOs.
- A total number of 30 **Historical Alarms** pages can be opened concurrently by online users.

## **Procedure**

1. Choose **Device Management > Alarm Management > Historical Alarms**.

- 2. On the **Historical Alarms** page, click **Filter** to expand the panel and set filter criteria to find desired historical alarms.
- 3. Click **Save** or **Save As** to save the current filter criteria as a filter template.

You can click **Template Management** in the upper left corner of the page to view all filter templates and select a filter template from the **Quick Filter** panel. Users with the **Administrators** role can manage templates saved by all users.

The following types of templates are provided:

- **Favorite**: You can add the templates that you often use to your favorites.
- Custom: Filter templates customized by the current user, which can be shared to other users.
- **Shared**: Available filter templates shared by other users.
- **Other**: Filter templates that are not shared by other users. These templates are visible only to users with the **Administrators** role.

#### ∩ NOTE

The filter templates on the **Current Alarms**, **Historical Alarms** pages are independent from each other and cannot be shared.

- 4. Export historical alarms. Alarms can be exported to an .xlsx or .csv file. When the export file format is set to .xlsx and the number of alarms exceeds 100,000, the file is exported as a .zip package. When the exported file format is set to .csv and the number of alarms exceeds 10,000, the file is exported as a .zip package.
  - Export some alarms: Select the alarms to be exported, click Export, and choose Selected.
  - Export all alarms: Click Export and choose All.

### 2.3.3 Masked Alarms

By analyzing masked alarms, users can understand device running statuses and determine whether rules are properly configured.

## **Prerequisites**

- By default, 20,000 masked alarms can be displayed. When the number of alarms exceeds the upper limit, the first 20,000 alarms are displayed based on the filter criteria and sorting. If you want to query other alarms, you can modify the filter criteria and sort the alarms.
- You can create an alarm masking rule to mask alarms that you are not concerned about. The masked alarms will be displayed on the Masked Alarms page or discarded.
- Masked alarms are not deleted from the masked alarm list when the corresponding masking rules are disabled or deleted.
- You can only monitor and view alarms of authorized MOs.

### **Procedure**

- 1. Choose **Device Management > Alarm Management > Masked Alarms**.
- 2. On the **Masked Alarms** page, click **Filter** to expand the panel and set filter criteria to find desired masked alarms.

3. Click **Save** or **Save** As to save the current filter criteria as a filter template.

You can click **Template Management** in the upper left corner of the page to view all filter templates and select a filter template from the **Quick Filter** panel. Users with the **Administrators** role can manage templates saved by all users.

The following types of templates are provided:

- **Favorite**: You can add the templates that you often use to your favorites.
- Custom: Filter templates customized by the current user, which can be shared to other users.
- **Shared**: Available filter templates shared by other users.
- Other: Filter templates that are not shared by other users. These templates are visible only to users with the Administrators role.

#### **◯** NOTE

The filter templates on the **Current Alarms**, **Historical Alarms**, **Masked Alarms** pages are independent from each other and cannot be shared.

- 4. Export masked alarms. Alarms can be exported to an .xlsx or .csv file. When the export file format is set to .xlsx and the number of alarms exceeds 100,000, the file is exported as a .zip package. When the exported file format is set to .csv and the number of alarms exceeds 10,000, the file is exported as a .zip package.
  - Export some alarms: Select the alarms to be exported, click Export, and choose Selected.
  - Export all alarms: Click Export and choose All.

# 2.3.4 Sync Alarm

You can manually create an alarm synchronization task on the NetEco to ensure that the alarms on the NetEco are consistent with the device alarms and quickly detect concerned alarms. If a device is disconnected from the NetEco and then reconnected to the NetEco again, you are advised to manually synchronize device alarms.

# **Prerequisites**

You have the **Synchronize Alarms** operation rights.

#### **Procedure**

- **Step 1** Choose **Device Management > Alarm Management > Sync Alarm**.
- **Step 2** In the displayed **Sync Alarms** window, select the device name.
- **Step 3** Perform the following operations based on service requirements:
  - Sync Current Alarms:Click Sync Alarm. Historical alarms can be synchronized only when the selected devices include controllers. You can select Synchronize historical alarms simultaneously as required, set the synchronization period, and click OK to deliver the synchronization task.
  - Viewing synchronization tasks: Click **Query Task** to query the data of alarm synchronization tasks.

#### □ NOTE

The NetEco supports daily alarm synchronization. For details, contact technical support engineers.

----End

# 2.3.5 Alarm Setting

You can set alarm rules to customize alarm monitoring policies as required, improving troubleshooting efficiency.

## 2.3.5.1 Setting Colors for Alarms

You can set colors for different alarm or event severities to easily identify the concerned alarms or events.

#### Context

After the colors for alarms or events at different severities are set, the alarm indicator colors and the colors in the **Severity** column of the alarm list or event list are displayed in the configured colors.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Personalization** > **Color Settings**.
- **Step 3** On the **Color Settings** page, set the colors for alarm and events at different severities.
- Step 4 Click OK.

----End

# 2.3.5.2 Setting Alarm Display Modes

When you need to identify alarms in different states more conveniently, you can set the alarm display mode as required to quickly identify concerned alarms.

### Context

After the alarm display mode is set, the parameter in the **Severity** column in the alarm list or event list is displayed in the specified style. Alarms in different states are displayed in the specified background colors.

#### Procedure

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Personalization** > **Alarm Display Mode**.

- **Step 3** On the **Alarm Display Mode** page, set the mode and background colors for alarms and events in different states.
  - **Icon**: Severity icon and parameter in the **Severity** column in the alarm list or event list. The colors of the severity icon are displayed by severity. The alarm background colors are displayed by state.
  - **Column background**: In the alarm list or event list, the background colors of the parameters in the **Severity** column are displayed by severity. The alarm background colors are displayed by state.
  - Row background: The background colors of the unacknowledged and uncleared alarms are displayed by severity, whereas the background colors of the alarms in other states are displayed by state. The alarm background colors are displayed by severity.

Step 4 Click OK.

----End

## 2.3.5.3 Setting Alarm Sounds

You can set different alarm sounds for alarm at different severities or specify alarm sound for different alarm names to facilitate alarm monitoring. When an alarm is generated, the sound box on your PC produces a corresponding sound.

### Context

By default, four alarm sounds are provided: Critical/Sound by alarm name: Critical.mp3; Major: Major.mp3; Minor: Minor.mp3; Warning: Warning.mp3.

#### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Personalization** > **Alarm Sounds**.
- **Step 3** On the **Alarm Sounds** page, set different sounds for alarms at different severities.
  - Click it to listen to the selected sound file.
  - Click . In the Custom Alarm Sound dialog box that is displayed, upload, view, or delete a custom alarm sound file.
  - Click + and select the alarms for **Sound by alarm name**. A maximum of 20 alarms can be selected.
- **Step 4** Set **Alarm Status** for alarms at different severities for which the system will play sounds.

When an alarm whose status is the specified one at the specified severity is reported or the status of an alarm changes to the specified status, the system plays the corresponding alarm sound.

**Step 5** Set the duration for playing the alarm sound. When an alarm is reported, the corresponding alarm sound is automatically stopped after being played for the specified duration. At the same time, the alarm indicator keeps blinking for the specified duration even the alarm sound is muted. When all alarms at the severity

that trigger the corresponding alarm sound are cleared or acknowledged, the alarm sound and the blinking of the alarm indicator are stopped. When an alarm specified in **Sound by alarm name** is cleared or acknowledged, the alarm sound and the blinking of the alarm indicator are not stopped.

**Step 6** Select whether to enable the sound setting. If the sound setting is disabled, the sound is not played when an alarm at the corresponding severity is reported.

### Step 7 Click OK.

**Ⅲ** NOTE

When an alarm meets both the Sound by alarm name rule and the severity (Critical, Major, Minor, or Warning) rule, and both the rules are enabled, the alarm sound set in the sound by alarm name rule is played for the alarm.

----End

## 2.3.5.4 Setting Alarm Font Colors

You can set font colors for read and unread alarms to distinguish alarms.

#### **Context**

The newly reported alarms are all unread alarms.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Personalization** > **Font Colors**.
- **Step 3** Sets the font colors for read and unread alarms.
- Step 4 Click OK.

----End

# 2.3.5.5 Highlighting Alarms

If alarms at a severity are not handled within the specified period of time, that is, the alarm status remains unchanged, the alarms are highlighted in the alarm list according to the highlight settings.

#### Context

- The highlight function takes effect only for current alarms.
- In the alarm list, the font color of the alarms that meet the highlight conditions is

### **Procedure**

**Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.

- **Step 2** In the navigation pane, choose **Personalization** > **Highlight**.
- **Step 3** On the **Highlight** page, set **Effective Time (min)** and **Alarm Status**. After an alarm at the severity is generated, the alarm is highlighted if the duration of the alarm in the specified status is greater than or equal to the specified effective time.
- **Step 4** Select whether to enable the function of highlighting alarms at the corresponding severity.
- Step 5 Click OK.

----End

## 2.3.5.6 Monitoring Alarms Based on Emergency Maintenance Notification

You can view the alarms reported by the system and MOs. However, O&M personnel tend to first handle alarms reported by MOs that they managed, or they may ignore or handled some important alarms in a delayed manner because they are not familiar with the alarms reported by MOs. As a result, system exceptions occur. Therefore, alarm management provides **Emergency Maintenance**Notification. The **Emergency Maintenance Notification** dialog box is used to monitor alarms and remind O&M personnel to handle alarms in manner.

## **Prerequisites**

An emergency maintenance notification template has been configured on the system, and the emergency maintenance notification function has been enabled on the PowerEcho page.

### **Context**

- The **Emergency Maintenance Notification** panel can be displayed on any PowerEcho page.
- A maximum of five key alarms can be displayed on the **Emergency Maintenance Notification** panel.
- In addition to the system administrator, a maximum of 49 users can view the **Emergency Maintenance Notification** panel.
- The notification panel or is displayed only when there are uncleared alarms that match the emergency maintenance notification template.

#### **Procedure**

**Step 1** When alarms specified by **Emergency Maintenance Notification** are reported, the **Emergency Maintenance Notification** panel is displayed in the lower right corner of the page. If you clear the **Pop up when notification received** check box,

is displayed in the lower right corner of the page. You can click the icon to expand the notification panel.

**Step 2** On the **Emergency Maintenance Notification** panel, view the key information about the alarms, such as the alarm name and alarm source.

- **Step 3** Click **Detail** to switch to the **Current Alarms** page. The alarms on the **Current Alarms** page are filtered by **Emergency Maintenance Notification**.
- **Step 4** Click an alarm name to view the alarm details and handle the alarm. Cleared alarms are not displayed on the **Emergency Maintenance Notification** panel.

----End

## 2.3.5.7 Setting Global Alarm Indicators

When you need to learn about the overall situation of alarms on all pages in real time and quickly open the alarm list page, you can enable the global alarm indicators. After this function is enabled, the alarm indicators on the current alarms page are displayed on all pages. You can use the alarm indicators to quickly open the current alarms page and filter alarms at a severity, facilitating alarm monitoring.

#### Context

- The settings take effect immediately, and remain valid on other clients after the current user logs in to them. However, the settings are invalid for other users.
- A maximum of 150 pages that have global alarm indicators can be opened at the same time.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Personalization** > **Global Alarm Indicators**.
- **Step 3** Enable or disable the global alarm indicators, and click **OK**.

----End

## 2.3.5.8 Configuring Masking Rules

You can set an alarm masking rule to mask alarms or events that you are not concerned about. New alarms or events meeting the masking rules will not be displayed on the **Current Alarms**, **Historical Alarms**, or **Event Logs** page. For example, when upgrading a device, you can set an alarm masking rule to mask alarms that require no attention.

## **Prerequisites**

You have the following operation permissions: **Set Masking Rules**.

#### **Context**

 After a rule is created successfully, if Alarm sources is set to All alarm sources or Event sources is set to All event sources in the rule, only the users whose managed objects are All Objects can modify or delete the rule. Other users can only modify or delete the rule in which Alarm sources is set to Custom alarm sources or Event sources is set to Custom event sources.

- A rule is valid only to the alarms or events reported after the rule is enabled.
   Alarms meeting the conditions reported before the rule takes effect will not be masked, and alarms meeting the conditions reported after the rule takes effect will be displayed in the masked alarm list or discarded.
- The masking rules are used to mask alarms based on the redefined name attributes. If both name redefinition rule and masking rule are set for an alarm, the name redefinition rule will take effect before the masking rule takes effect.
- A maximum of 1000 masking rules can be created.
- If all of the following conditions are met, the masking rule will mask all alarms or events, and alarms or events cannot be reported.
  - The masking rule is enabled.
  - All alarm or event sources are selected in the masking rule.
  - All alarm or event severities are selected in the masking rule.
  - Designated alarms or Designated events is not selected, and advanced conditions are not set in the masking rule.
  - The time filter condition is not set in the masking rule.
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Masking Rules**.
- **Step 3** On the **Masking Rules** page, click **Create** and select **Alarm Masking Rules** or **Event Masking Rules**.
- **Step 4** In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
- **Step 5** In the **Conditions** area, set the alarms or events to be masked, and their severities and alarm or event sources. Set advanced conditions to filter the alarms or events for the rule to take effect based on parameters.

## **NOTE**

- All alarm sources or All event sources is available only for users whose managed objects are All Objects.
- In Alarm sources or Event sources, you can select All alarm sources or All event sources to mask the alarms or events that meet the conditions and are generated by the system and all MOs. Therefore, exercise caution when performing this operation.
- **Step 6** In the **Time Filter** area, set the time and period for the rule to take effect.
- **Step 7** In the **Action** area, set the handling policy for the masked alarms or events. Set **Masked alarms** to **Discard** or **Displayed on Masked Alarms**.

#### 

- When an event masking rule is created, masked events can only be discarded.
- If **Discard** is selected, the alarms will not be displayed. Therefore, exercise caution when performing this operation.

**Step 8** In the **Other** area, set the priority for the rule.

Step 9 Click OK.

----End

### **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily from the rule list and click **Disable**. To use a disabled rule, select the rule and click **Enable**.
- Migrating rules: You can click Export on the rule page of the source system to export rules. Then, click Import in the target system to import the rule file exported from the source system to the target system.
- Backing up, collecting statistics on, and reviewing rules, and modifying rules in batches: You can click **Export** on the rule page to export rules and back up, review, and collect statistics on the rules. If you need to modify rules in batches, you can modify the rules in batches in the exported rule file. Then, click **Import** on the rule page to import the modified rule file.

## Task Example

#### Scenario

O&M personnel plan to commission device A at 01:00 AM every Monday in April 20*XX*. Each commissioning is completed within two hours, during which services of device A are interrupted. Alarms generated during this period are predictable and do not need to be handled. You need to configure masking rules to mask these alarms.

#### **Procedure**

- 1. On the Masking Rules page, click Create and select Alarm Masking Rules.
- 2. In the **Basic Information** area, enter the rule name.
- 3. In the **Conditions** area, select **Custom alarm sources** and add device A to the custom alarm sources.
- 4. In the **Time Filter** area, set **By period** to **20***XX***-04-01 00:00:00** to **20***XX***-04-30 23:59:59**, set **By day** to **Mon**, and set **By time** to **01:00** to **03:00**.
- 5. In the Action area, set Masked alarms to Displayed on Masked Alarms.
- 6. Retain the default settings for other parameters.
- 7. Click OK.

#### Result

The alarms generated by device A from 01:00 AM to 03:00 AM every Monday in April 20*XX* are not displayed on the **Current Alarms**, **Alarm Logs**, and **Historical Alarms** pages. You can view the masked alarms on the **Masked Alarms** page.

# **Parameter Description**

The following uses the parameters for creating an alarm rule as an example, and they are similar to those for creating an event rule.

Table 2-17 Parameters for creating an alarm masking rule

Item	Parameter	Description
Conditio ns	Alarms	<ul> <li>If you select <b>Designated alarms</b>, the rule takes effect only for the alarms you added.         <b>Alarm ID</b> and <b>Group Name</b>: Unique identifiers of an alarm.     </li> <li>If you do not select <b>Designated alarms</b>, the</li> </ul>
		rule takes effect for all alarms by default.
	Alarm sources	All alarm sources: If this option is selected, the rule takes effect for the alarms generated by all alarm sources.
		Custom alarm sources: If this option is selected, the rule takes effect only for the alarms of specified alarm sources.
	Advanced conditions	Restrictions on items such as location information and alarm source type. For example, if you want to filter alarms by location information, select <b>Location Info</b> and <b>contains</b> and enter the alarm location information in the text box.
Time Filter	By period	Time range within which the rule will take effect. By default, <b>Server time</b> is selected.
	By day	Days on which the rule takes effect in a week.
	By time	Period for the rule to take effect in a day.
Action	Masked alarms	<ul> <li>Displayed on the Masked Alarms page: The masked alarms will be displayed on the page opened by choosing Service Monitor &gt; Alarms &gt; Masked Alarms from the main menu.</li> <li>Discard: Masked alarms will be deleted. If Discard is selected, the alarms will not be displayed. Therefore, exercise caution when performing this operation.</li> </ul>
Other	Priority	Sets the priorities for alarm masking rules.
Change History	-	After a masking rule is created successfully, you can click a rule name and view the change history of the rule in the <b>Change History</b> area. This item is not displayed when you create a rule.

## 2.3.5.9 Configuring Intermittent/Toggling Rules

After the intermittent/toggling rule is set, the alarms that last for a short period of time or are frequently reported can be discarded or displayed on the **Masked Alarms** page to reduce interference caused by repetitive alarms.

## **Prerequisites**

You have the following operation permissions: **Set Intermittent/Toggling Rules**.

#### **Context**

- A rule is valid only to the alarms reported after the rule is enabled.
- Before setting rules, you need to understand the following concepts:
  - Original alarm: The alarms that meet the conditions in the intermittent/ toggling rules are original alarms.
  - Intermittent policy: When the interval between alarm generation and alarm clearance is less than a specific period, the alarm is considered as an intermittent alarm. The period is called intermittent period.
  - Toggling policy: When the number of times that an alarm (with the same alarm ID) is reported by the same alarm source in a specified period reaches the trigger condition, the toggling handling is started. You can set the action to generate a toggling alarm or avalanche alarm, or redefine the original alarm severity. When the number of times that the alarm is reported by the same alarm source in the specified period reaches the termination condition, the toggling handling is terminated. After the toggling ends, the generated toggling or avalanche alarm is automatically cleared. If the original alarms are not cleared, the last original alarm is reported.
- If the interval between the time when an alarm is generated and the time when the alarm is received is longer than 30 minutes, the alarm does not match the intermittent/toggling rule even if the alarm meets the conditions.
- A maximum of 1000 intermittent/toggling rules can be created.
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- Step 2 In the navigation pane, choose Intermittent/Toggling Rules.
- Step 3 On the Intermittent/Toggling Rules page, click Create.
- **Step 4** In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
- **Step 5** In the **Conditions** area, set the alarm severities, alarms, and alarm sources for the rule to take effect. Set advanced conditions to filter the alarms for the rule to take effect based on alarm parameters.
- **Step 6** In the **Time Filter** area, set the time and period for the rule to take effect as required.

- **Step 7** In the **Analysis Type** area, select **Intermittent analysis** or **Toggling analysis** or both as required.
- **Step 8** In the **Intermittent Policy** and **Toggling Policy** areas, configure the policies.
  - **Intermittent Policy**: Sets an intermittent period and action. For example, if the intermittent period is set to **30** and the policy action is set to **Discard**, the alarm is discarded when the interval between the generation and clearance of the alarm is less than 30 seconds.
    - Period: If the interval between the alarm generation time and alarm clearance time is less than the set period, the alarm meets the intermittent policy.
    - **Action**: The action for handling the alarm that meets the intermittent policy can be set to **Discard** or **Displayed on Masked Alarms**.
  - **Toggling Policy**: Sets the toggling trigger condition, termination condition, and handling policy. The differences between toggling alarms and avalanche alarms are as follows:
    - Toggling alarm: A new alarm is generated. The alarm is identified as a toggling alarm. The alarm information is the same as that of an original alarm. You can set **Toggling Identifier** in the **Advanced settings** area on the filter panel to filter the alarms.
    - Avalanche alarm: ALM-132 Avalanche alarm is generated.
- **Step 9** In the **Other** area, set the priority for the rule.

Step 10 Click OK.

----End

#### **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily from the rule list and click **Disable**. To use a disabled rule, select the rule and click **Enable**.
- Migrating rules: You can click Export on the rule page of the source system to export rules. Then, click Import in the target system to import the rule file exported from the source system to the target system.
- Backing up, collecting statistics on, and reviewing rules, and modifying rules
  in batches: You can click Export on the rule page to export rules and back up,
  review, and collect statistics on the rules. If you need to modify rules in
  batches, you can modify the rules in batches in the exported rule file. Then,
  click Import on the rule page to import the modified rule file.

## Task Example

#### Scenario

A minor alarm M lasts for a short period of time or is reported frequently. The cause may be that an NE or service switches between the normal state and the abnormal state repeatedly. To reduce the interference of such alarms, you can set an intermittent/togqling rule to handle the alarms using the following policies:

- Intermittent policy: If alarm M is reported and cleared within 30 seconds, this alarm is discarded.
- Toggling policy: If the number of times that alarm M is generated within 60 seconds is greater than 2, the toggling handling is triggered. If the number of times that alarm M is generated within 60 seconds is less than or equal to 0, the toggling handling is terminated.

#### **Procedure**

- On the Intermittent/Toggling Rules page, click Create.
- 2. In the **Basic Information** area, enter the rule name.
- 3. In the **Conditions** area, select **Designated alarms**. Click **Add Alarm** and select **M**, which indicates that the intermittent/toggling rule is performed on alarm M. After the alarm M is displayed in **Selected**, click **OK**.
- 4. In the **Analysis Type** area, select **Intermittent analysis** and **Toggling** analysis.
- 5. In the **Intermittent Policy** and **Toggling Policy** areas, configure the policies.
  - Intermittent Policy: Set Period (s)(T) to 30 and Action to Discard.
  - Toggling Policy: Set Period (s)(T1) to 60 and Generated alarms to 2 for Trigger condition, Period (s)(T2) to 60 and Generated alarms to 0 for Termination condition, and Handling policy to Generate a toggling alarm and discard original alarms generated after toggling.
- 6. Click OK.

#### Result

If alarm M is cleared within 30 seconds after being reported, it is discarded. If the M alarm is reported frequently, the original alarms generated after the toggling policy is triggered are discarded and a new toggling alarm is generated.

## 2.3.5.10 Configuring Aggregation Rules

If alarms or events are reported repeatedly within a specified period, users can configure rules to aggregate them into one, thereby reducing interference. When monitoring or viewing alarms, you can select **Aggregated alarms** to filter out original alarms that have been aggregated and focus only on the alarms you need to handle.

## **Prerequisites**

You have the following operation permissions: **Set Aggregation Rules**.

#### Context

- A rule is valid only to the alarms or events reported after the rule is enabled.
- In an aggregation rule, when the number of times that the same alarm or event (with the same alarm or event ID) is reported by the same NE in a specified period meets the trigger condition, an aggregation is triggered and a new aggregated alarm is generated. The alarms that meet all the conditions of the alarm aggregation rule are the original alarms. When an aggregated alarm is generated based on the rule, the correlative alarms are marked as original alarms. To view all original alarms, you can select **Original alarms** for **Associated alarm ID** when setting the filter criteria for current alarms.

- If an aggregated alarm generated based on the alarm aggregation rule is cleared, its correlative original alarms are cleared. If the original alarms are cleared, their correlative aggregated alarms are also cleared. To handle an aggregated alarm, handle the faults corresponding to the original alarms one by one.
- A maximum of 1000 custom aggregation rules can be created.
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.
- If the interval between the time when an alarm is generated and the time when the alarm arrives at the NMS is longer than 5 minutes, the alarm does not match the aggregation rule even if the alarm meets the conditions.
- On the page for creating an event aggregation rule, only the Generate an
  aggregated alarm and Generate an aggregated alarm and mask all
  original events options are provided in the Aggregation Action area. The
  information about the aggregated alarm generated based on the event
  aggregation rule is the same as that of an original event. The original events
  of the aggregated alarm cannot be viewed.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Aggregation Rules**.
- **Step 3** Create an aggregation rule.
  - 1. On the **Aggregation Rules** page, click **Create**, and choose the desired rule type from the drop-down menu.
  - 2. In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
  - 3. In the **Conditions** area, set the name, sources, and advanced conditions of the target alarm or event. If alarms or events reported by the selected alarm or event source meet the configured advanced conditions, aggregation analysis is performed.
  - 4. In the **Aggregation Parameters** and **Aggregation Action** areas, set aggregation parameters and aggregation action. For details about the parameters, see **Table 2-18**.
  - 5. Click OK.

----End

## **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily from the rule list and click **Disable**. To use a disabled rule, select the rule and click **Enable**.
- Migrating rules: You can click **Export** on the rule page of the source system to export rules. Then, click **Import** in the target system to import the rule file exported from the source system to the target system.

Backing up, collecting statistics on, and reviewing rules, and modifying rules
in batches: You can click **Export** on the rule page to export rules and back up,
review, and collect statistics on the rules. If you need to modify rules in
batches, you can modify the rules in batches in the exported rule file. Then,
click **Import** on the rule page to import the modified rule file.

## **Parameter Description**

The following uses the parameters for creating an alarm rule as an example, and they are similar to those for creating an event rule.

Table 2-18 Parameters for creating an alarm aggregation rule

Item	Parameter	Description
Aggregation Parameters	Aggregation scope	Intra-NE: Aggregates alarms that are from the same alarm source and meet the conditions.
	Key parameters	Sets a location information matching condition. When the location information of reported alarms meet the condition, the system determines whether the alarms are aggregated.
		Specified property: The condition is met when the values of properties in the location information of original alarms matches the settings in the condition.
		Full match: The condition is met when the location information of original alarms is the same.
		NOTE Only the location information conditions can be set for <b>Key parameters</b> .
	Trigger condition	In a specified period, when the number of alarms that meet aggregation conditions is greater than or equal to <b>Generated alarms</b> , an aggregation is triggered.
	Termination condition	In a specified period, when the number of alarms that meet aggregation conditions is less than or equal to <b>Generated alarms</b> , the aggregation is terminated.

Item	Parameter	Description
Aggregation Action	Aggregation action	Generate an aggregated alarm: A new aggregated alarm is generated, and the original alarms are marked as the original alarms and reported to the upper-layer NMS.
		Generate an aggregated alarm and mark all original alarms as correlative alarms: A new aggregated alarm is generated, and all original alarms are marked as correlative alarms.
		Generate an aggregated alarm and mask all original alarms for NMS: A new aggregated alarm is generated, and the original alarms are marked as the original alarms. In this case, the original alarms are not reported to the upper-layer NMS.
		Generate an aggregated alarm after aggregation and always display all original alarms on Masked Alarms: All original alarms are displayed on the Masked Alarms page regardless of whether aggregation is triggered, and an aggregated alarm is generated after aggregation is triggered.
		Generate an aggregated alarm and discard all original alarms: A new aggregated alarm is generated, and all original alarms are discarded.
		Generate an aggregated alarm and discard all original alarms after aggregation: If a new aggregated alarm is generated, the original alarms reported after the aggregation are discarded.
		Report original alarms without aggregated alarms: No aggregated alarms or original alarms are generated, and original alarms are not masked as original alarms. If this option is selected, you can customize the severity of original alarms in the Original alarm settings area.

Item	Parameter	Description
Aggregated alarm settings	Alarm sources:     NE: Reports an aggregated alarm whose alarm source is NE. The location information of the aggregated alarm contains rule ID and original alarm information. Other information of the aggregated alarm is the same as that of an original alarm.	
		OSS: An aggregated alarm, ALM-832     Parallel Alarm Exceeds the Limit, whose alarm source is OSS is reported.
		Reserved fields of Location Info: After this parameter is set, the specified fields are displayed in the Other Information column of the aggregated alarm list.
		You can also customize some fields of an aggregated alarm, for example, customizing the severity.
	Original alarm settings	This option is displayed when <b>Report original alarms without aggregated alarms</b> is selected for <b>Aggregation action</b> . You can set the severity of original alarms.

## 2.3.5.11 Configuring Correlation Rules

If an alarm causes other alarms, you can use the correlation rule to define the correlation between alarms. When O&M maintenance personnel monitor or view alarms, they can set a correlation rule to filter out correlative alarms and focus only on root alarms.

## **Prerequisites**

You have the following operation permissions: **Set Correlation Rules**.

### Context

- A rule is valid only to the alarms reported after the rule is enabled.
- After the rule is enabled, the NetEco needs to analyze alarm relationships, which affects the time for reporting alarms to the NetEco.
- A maximum of 1000 custom correlation rules can be created.
- The default correlation rules can be enabled or disabled, but cannot be modified or deleted.
- If the interval between the time when an alarm is generated and the time when the alarm arrives at the NMS is longer than 5 minutes, the alarm does not match the correlation rule even if the alarm meets the conditions.

• By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.

#### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Correlation Rules**.
- **Step 3** On the **Correlation Rules** page, click the **Default** tab. On the tab page that is displayed, check whether a rule meeting requirements exists.
  - If yes, go to **Step 4**.
  - If no, go to Step 5.
- **Step 4** On the **Default** tab page, enable or disable rules as required.
- **Step 5** Create a custom correlation rule.
  - 1. On the **Correlation Rules** page, click **Custom** and then click **Create**.
  - 2. In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
  - 3. In the **Alarms** area, select root alarms and correlative alarms and set actions.
    - Root alarms: Alarm that causes multiple correlative alarms.
    - **Correlative alarms**: Alarm that is generated due to the root alarm.
  - 4. In the **Conditions** area, click **Create** to create a correlation rule between the root alarm and the correlative alarms.
  - 5. In the **Other** area, set the generation interval between the root alarms and their correlative alarms and the priority of the rule.
    - A correlation is true only if the generation interval between the root alarm and the correlative alarm is shorter than or equal to the specified period.
  - 6. Click OK.

#### ----End

#### **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily
  from the rule list and click **Disable**. To use a disabled rule, select the rule and
  click **Enable**.
- Migrating rules: You can click **Export** on the rule page of the source system to export rules. Then, click **Import** in the target system to import the rule file exported from the source system to the target system.
- Backing up, collecting statistics on, and reviewing rules, and modifying rules
  in batches: You can click **Export** on the rule page to export rules and back up,
  review, and collect statistics on the rules. If you need to modify rules in
  batches, you can modify the rules in batches in the exported rule file. Then,
  click **Import** on the rule page to import the modified rule file.

## Task Example

#### Scenario

When the connection of an NE is faulty, the NE reports alarm M periodically. At the same time, a large number of connection interruption alarms N are generated by this NE or other NEs because of the connection interruption. The type of alarm N is the same as that of alarm M. In this case, you only need to handle alarm M instead of alarm N. By setting a correlation rule, you can set the alarm N generated later than the alarm M to a correlative alarm.

#### **Procedure**

- 1. On the **Correlation Rules** page, click **Custom** and then click **Create**.
- 2. In the **Basic Information** area, enter the rule name.
- 3. In the **Alarms** area, set **Root alarms** to alarm M and **Correlative alarms** to alarm N.
- 4. In the **Conditions** area, click **Create**. Set the following condition: The occurrence time of alarm N is later than the occurrence time of alarm M. Click **OK**.
- 5. Click OK.

#### Result

When the occurrence time of alarm N is later than that of alarm M, alarm M is the root alarm of alarm N. In this case, choose **Current Alarms** from the main menu and open the **Filter** tab page. In the **Advanced settings** area, click **Associated Alarm ID**, and then set **Operator** to **is in** and **Value** to **Normal alarms** and **Root alarms**. After the query is started, the correlative alarm N is not displayed in the current alarm list. You only need to handle the root alarm M.

## **Parameter Description**

**Table 2-19** Parameters for creating a correlation rule

Item	Parameter	Description
Alarms	Root alarms	Alarm that causes multiple correlative alarms.
		The following actions can be selected for the root alarms, which are the operations performed on the root alarms when the alarms that meet the conditions are reported.
		None
		Raise alarm severity by 1

Item	Parameter	Description
	Correlative alarms	Alarms caused by the root alarm.  The following actions can be selected for correlative alarms, which are the operations performed on correlative alarms when the alarms that meet the conditions are reported.  Redefine severity as Critical Redefine severity as Major Redefine severity as Minor Redefine severity as Warning Discard
Conditions	Including Location Info and Alarm Source Type	You can set conditions for each parameter.
	Comparison mode	<ul> <li>Value: indicates that an alarm attribute is compared with a specified value.</li> <li>Alarm: indicates that the attribute value of an alarm is compared with that of the other alarm.</li> </ul>
Other	Period	Generation interval between the root alarm and its correlative alarms. When the period is less than or equal to the specified value, the selected root alarm and its correlative alarms form a root-correlative relationship.
	Priority	Priority for a rule to take effect.

# 2.3.5.12 Configuring Auto Acknowledgement Rules

When the number of current alarms reaches the threshold, the system processes the full current alarm cache and moves current alarms to the historical alarm list. To prevent the important alarms in the full current alarm list from being processed, the system automatically acknowledges the current alarms in the

cleared status based on an acknowledgement rule specified by users and converts them to historical alarms.

## **Prerequisites**

You have the following operation permissions: **Set Auto Acknowledgement Rules**.

#### Context

- Auto acknowledgement rules take effect only for unacknowledged and cleared alarms. Alarms cleared before immediate acknowledgement is enabled are not affected.
- A maximum of 1000 auto acknowledgement rules are supported in the system. Four preset rules exist in the system and a maximum of 996 rules can be created.
- If an alarm complies with auto acknowledgement rules in both the delayed and immediate modes, the system acknowledges the alarm in immediate mode
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.

### Procedure

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Auto Acknowledgement Rules**.
- **Step 3** In the auto acknowledgement rule list, the first four rules are preset for automatically acknowledging alarms by severity. Check whether the rules already meet the requirements.
  - If yes, go to Step 4.
  - If no, go to Step 5.
- **Step 4** Enable an auto acknowledgement rule by alarm severity. For example, when the auto acknowledgement rule for major alarms is enabled, the cleared but unacknowledged major alarms will be acknowledged automatically.

In the auto acknowledgement rule list, the first four rules are preset. Only users who can manage all resources can enable or disable these rules.

- 1. Select the auto acknowledgement rule required based on the severity and click **Enable**.
- 2. In the **Mode** column, view the acknowledgement mode of the rule.
  - **Immediate**: indicates that alarms will be automatically acknowledged immediately after being cleared.
  - Delayed: indicates that alarms will be automatically acknowledged based on the settings in the Change Delay area after being cleared.
- **Step 5** Create a custom auto acknowledgement rule.
  - 1. On the **Auto Acknowledgement Rules** page, click **Create**.

- 2. In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
- 3. In the **Conditions** area, set the alarm severities, alarms, and alarm sources for the rule to take effect. Set advanced conditions to filter the alarms for the rule to take effect based on alarm parameters.

All alarm sources is available only for users whose managed objects are All Objects.

- 4. In the **Other** area, set the acknowledgement mode for the rule.
- 5. Click OK.
- **Step 6** On the **Auto Acknowledgement Rules** page, click **Change Delay** and set the parameters. If the acknowledgement mode is set to **Delay**, the system automatically acknowledges alarms based on the configuration in the **Change Delay** area.
  - 1. Click Change Delay and set Execute at and Duration.
  - 2. Click **Apply**.

----End

## 2.3.5.13 Configuring Identification Rules

After an identification rule is set, the system automatically sets alarms that match the rule to the maintenance or invalid state. When monitoring or querying alarms, you can set filter criteria to filter out the alarms. For example, you can set the status of alarms generated during commissioning to **Maintenance** so that O&M personnel do not need to spend time on these alarms.

## **Prerequisites**

You have the following operation permissions: Set Identification Rules.

### Context

- A rule is valid only to the alarms reported after the rule is enabled.
- Before an identification rule takes effect, Validity is set to Valid and Maintenance Status is set to NORMAL by default. The NORMAL state corresponds to the Normal state.
- A maximum of 1000 identification rules can be created.
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.

#### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Identification Rules**.
- Step 3 On the Identification Rules page, click Create.
- **Step 4** In the **Basic Information** area, set the rule name, description, and whether to enable the rule.

**Step 5** In the **Conditions** area, set the alarm severities, alarms, and alarm sources for the rule to take effect. Set advanced conditions to filter the alarms for the rule to take effect based on alarm parameters.

All alarm sources is available only when the user can manage all resources.

- **Step 6** In the **Time Filter** area, set the time and period for the rule to take effect as required.
- **Step 7** In the **Action** area, select the status of alarms you want to identify.
- Step 8 Click OK.

----End

#### **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily from the rule list and click **Disable**. To use a disabled rule, select the rule and click **Enable**.

## **Parameter Description**

**Table 2-20** Parameters for creating an identification rule

Item	Parameter	Description
Conditions	Alarms	<ul> <li>If you select <b>Designated alarms</b>, the rule takes effect only for the alarms you added.</li> <li><b>Alarm ID</b> and <b>Group Name</b>: Unique identifiers of an alarm.</li> </ul>
		If you do not select <b>Designated alarms</b> , the rule takes effect for all alarms by default.
	Alarm sources	All alarm sources: If this option is selected, the rule takes effect for the alarms generated by all alarm sources.
		Custom alarm sources: If this option is selected, the rule takes effect only for the alarms of specified alarm sources.
	Advanced conditions	Restrictions on items such as location information and alarm source type. For example, if you want to filter alarms by location information, select <b>Location Info</b> and <b>contains</b> and enter the alarm location information in the text box.
Time Filter	By period	Time range within which the rule will take effect. By default, <b>Server time</b> is selected.

Item	Parameter	Description
	By day	Days on which the rule takes effect in a week.
	By time	Period for the rule to take effect in a day.
Action	Set alarm identity as	Maintenance status: identifies the alarms generated due to NE commissioning or maintenance.
		<ul> <li>Invalid: identifies useless alarms that O&amp;M personnel judge from previous experience.</li> </ul>
		When monitoring or querying alarms, you can set filter criteria to filter out alarms that are in the <b>Maintenance</b> or that are <b>Invalid</b> .

## 2.3.5.14 Setting Alarm Name Groups

You can add multiple alarm or event names to a name group. When setting filter criteria for querying or collecting statistics on alarms or events, you can select a name group to perform operations on multiple alarms or events at a time.

## Context

Only the users with the **Administrator** role can modify or delete all name groups. Other users can only modify or delete the name groups created by themselves.

### Procedure

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Alarm/Event Name Group**.
- Step 3 On the Alarm/Event Name Group page, click Create and select Alarm Name Group or Event Name Group.
- **Step 4** Set the name of the group.
- **Step 5** In the **Members** area, click **Add Alarm** or **Add Event**, select the alarms or events to be contained in the name group. After the alarms or events are displayed in **Selected**, click **OK**.
- Step 6 Click OK.

----End

# 2.3.5.15 Configuring Unhandled Alarm Severity Rules

If some alarms that require special attention are not handled for a long time (that is, the alarms are not cleared or acknowledged for a long time), you need to raise the alarm severity. If some alarms that do not require special attention are not handled for a long time, you can lower the alarm severity. You can create

unhandled alarm severity rules to change the severity of alarms that are not handled within a specified period.

### Context

- After a rule is enabled, it takes effect for the alarms reported before and after the rule is enabled.
- After the alarm severity is changed, the alarm severity displayed in the alarm list is the new one. However, when you select an alarm for other rules, the alarm severity displayed is still the original one.
- A maximum of 2000 unhandled alarm severity rules can be created.
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.

#### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Unhandled Alarm Severity Rules**.
- Step 3 On the Unhandled Alarm Severity Rules page, click Create.
- **Step 4** In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
- **Step 5** In the **Conditions** area, set the alarm name, alarm ID, group name, and alarm status.
- **Step 6** In the **Handling Policy** area, set **Trigger condition** and **Action**.
- **Step 7** In the **Other** area, set the priority for the rule.
- Step 8 Click OK.

----End

### **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily from the rule list and click **Disable**. To use a disabled rule, select the rule and click **Enable**.

## 2.3.5.16 Configuring Notification Rules

O&M personnel cannot browse alarms or events on the alarm management page when they are out of office, for example, during off-work hours or business trips. Notification rules enable O&M personnel to receive SMS or email notifications about concerned alarms or events so that they can handle alarms in real time.

## **Prerequisites**

- You have completed the notification configuration. The navigation path is as follows: Choose System > System Settings > Notifications from the main menu.
- You have the following operation permissions: **Set Notification Rules**.

### Context

- Notifications by email and SMS message are sent through third-party servers and devices. Therefore, the sending capability (such as the delay when the notifications arrive) varies with the third-party servers and devices.
- The delay time cannot be set on the page for creating an event notification rule.
- By default, the rules are sorted by the enabled and disabled states, and the rules in the same state are sorted by update time in descending order.
- A maximum of 1000 notification rules can be created.

### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Notification Rules**.
- **Step 3** On the **Notification Rules** page, click **Create** and select **Alarm Notification Rules** or **Event Notification Rules**.
- **Step 4** In the **Basic Information** area, set the rule name, description, and whether to enable the rule.
- **Step 5** In the **Conditions** area, set the severities, alarm status, alarms or events, and alarm or event sources for the rule to take effect. Set advanced conditions to filter the alarms or events for the rule to take effect based on the parameters.
  - □ NOTE

**All alarm sources** or **All event sources** is available only for the users who can manage all resources

- **Step 6** In the **Time Filter** area, set the time and period for the rule to take effect as required.
- **Step 7** Set the notification method and content, recipient time zone, and recipients. When the alarms set in the rule are reported, the system sends notifications to users of specified groups by email or SMS message. **Table 2-21** describes the parameters for creating a notification rule.

□ NOTE

To send notifications to relevant personnel, you need to enter their personal information, such as mobile numbers and email addresses. You are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that the user's personal information is fully protected.

Step 8 Click OK.

----End

### **Related Tasks**

- Deleting a rule: You can select a redundant rule from the rule list and click **Delete** to reduce the rule maintenance workload.
- Enabling/disabling a rule: You can select a rule that is not used temporarily from the rule list and click **Disable**. To use a disabled rule, select the rule and click **Enable**.
- Migrating rules: You can click **Export** on the rule page of the source system to export rules. Then, click **Import** in the target system to import the rule file exported from the source system to the target system.
- Backing up, collecting statistics on, and reviewing rules, and modifying rules
  in batches: You can click **Export** on the rule page to export rules and back up,
  review, and collect statistics on the rules. If you need to modify rules in
  batches, you can modify the rules in batches in the exported rule file. Then,
  click **Import** on the rule page to import the modified rule file.

#### 

When the notification rules are exported, the email addresses and phone numbers of the recipient users are exported. You are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that the user's personal information is fully protected.

## **Parameter Description**

The following uses the parameters for creating an alarm rule as an example, and they are similar to those for creating an event rule.

**Table 2-21** Parameters for creating a notification rule

Item	Parameter	Description
Conditions	Alarms	<ul> <li>If you select <b>Designated alarms</b>, the rule takes effect only for the alarms you added.</li> <li><b>Alarm ID</b> and <b>Group Name</b>: Unique identifiers of an alarm.</li> </ul>
		<ul> <li>If you do not select <b>Designated alarms</b>, the rule takes effect for all alarms by default.</li> </ul>
	Alarm sources	All alarm sources: indicates that this rule takes effect for the alarms generated by all alarm sources.
		Custom alarm sources: indicates that this rule takes effect only for the alarms of specified alarm sources.

Item	Parameter	Description	
	Advanced conditions	Restrictions on items such as location information and alarm source type. For example, if you want to filter alarms by location information, select <b>Location Info</b> and <b>contains</b> and enter the alarm location information in the text box.	
Time Filter	By period	Time range within which the rule will take effect. By default, <b>Server time</b> is selected.	
By default, the rule	By month	Month for the rule to take effect in a year.	
takes effect at any time.	By day	Days on which the rule takes effect in a week.	
	By time	Period for the rule to take effect in a day.	
Notification Method	Email	Indicates that notifications will be sent by email. You need to select a notification template.	
	SMS message	Indicates that notifications will be sent by SMS message. You need to select a notification template.	
	Delay (min)	Indicates that you can set the delay time for sending a notification. The system records the time when the alarm arrives at the alarm management system. If the alarm is cleared within the delay time after the alarm arrives at the system, no notification is sent. Otherwise, the notification is sent.	
Recipient Time Zone	Recipient time zone	Indicates the time zone of the user who receives the notification. When the time zone of the recipient is different from that of the server, the alarm generation time in the notification is converted based on the time zone of the recipient. The daylight saving time (DST) is not supported.	
Recipient Groups	Recipient groups	Sets the user groups for receiving the notification.	

# 2.3.5.17 Configuring Notification Templates

When the default notification template does not meet your requirements, you can create a notification template and use it when configuring notification rules. The system fills the alarm information in an email or SMS message based on the notification template and sends the email or SMS message to related users.

## **Prerequisites**

You have the following operation permissions: **Set Notification Rules**.

## **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Notification Templates**.
- **Step 3** On the **Notification Templates** page, click **Create**.
- **Step 4** In the **Basic Information** area, enter the template name and description.
- **Step 5** In the **Notification Method and Content** area, select **Email** or **SMS message** as the notification method, and set the important information of the notification, such as, severity, name, and occurrence time.
  - If you select **New alarms + new cleared alarms** for **Subtitle**, a notification email can contain multiple alarms or events. The maximum size of an email is 2 MB. If the size of an email exceeds the maximum size, the email is split into multiple emails. When you create a notification rule, an email can contain a maximum of 200 alarms or events. If **Delay (min)** is set in the rule, the number of alarms in an email is not limited to 200.
  - If you deselect **New alarms + new cleared alarms** for **Subtitle**, only one alarm or event is sent in a notification email.

#### 

The contents in black in the template are fixed fields displayed in emails or SMS messages. Users can modify them as required. The contents in blue show alarm information and vary depending on alarms. You can add the contents in blue by selecting the labels below rather than manually editing them.

The meaning of **Occurred** varies in the following scenarios:

- Generally, when an alarm is reported, this parameter refers to the report time, corresponding to the First Occurred field on the Current Alarms page.
- When a merged alarm is reported, this parameter refers to the report time of the merged alarm, corresponding to the **Last Occurred** field on the **Current Alarms** page.
- When an alarm clear notification is sent, this parameter refers to the time when the alarm is generated, corresponding to the **Last Occurred** field on the **Alarm Logs** page.

## Step 6 Click OK.

----End

# 2.3.5.18 Managing Handling Experience

After handling an alarm, record the handling experience to the handling experience database for future reference or guidance.

## **Prerequisites**

You have the **Record Experience** permission.

#### Context

- The handling experience on the **Alarm Settings** > **Experience** page is the same as that in the alarm details.
- A maximum of 10,000 experience records can be created.

## **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Experience**.
- **Step 3** On the **Experience** page, click **Create**.
- **Step 4** Select the alarm whose handling experience needs to be created. If the page about the corresponding alarm reference exists for the alarm, a link to the alarm reference is provided next to the alarm name. **Table 2-22** describes parameters for creating handling experience.
- **Step 5** Enter experience.
- Step 6 Click OK.

----End

### **Related Tasks**

You can import or export alarm handling experience for statistics, review, and migration. On the **Experience** page, click **Export** or **Import** to export or import experience.

# **Parameter Description**

**Table 2-22** Parameters for creating experience

Parameter	Description
Alarm name	Name of an alarm.
Alarm ID	ID of an alarm.
Group name	Alarm group ID, which is assigned by NEs or devices that report alarms.

# 2.3.5.19 Setting the Current Alarm Threshold Warning

When the number of current alarms reaches the maximum capacity, the system moves some current alarms to the historical-alarm list based on the full-cache processing rule. To prevent important alarms from being moved to the historical-alarm list, you can set a threshold for current alarms. When the number of current alarms reaches a specified threshold, an alarm is reported to prompt users to handle the current alarms.

## **Prerequisites**

Only users with the **Administrators** role can set the current alarm threshold warning.

### Context

To prevent excessive current alarms from deteriorating system performance, alarm management provides a full-alarm processing rule. When the number of current alarms in the database reaches the upper threshold, alarm management applies the following rules to move some alarms to the historical alarm list until the number of alarms falls to 90% of the upper threshold.

- Alarms are moved to the historical-alarm list in the following sequence: cleared alarms, acknowledged and uncleared ADMC alarms, acknowledged and uncleared ADAC alarms, and unacknowledged and uncleared alarms.
- For alarms of the same type, the earlier alarms are moved to the historical alarm list first.
- In a distributed system, when the NE alarms are reported to different nodes and the processing of the full current alarm cache is triggered, the alarms are moved to the historical alarm list in descending order of the node alarm quantity. The more alarms are reported to a node, the higher the priority of the node is. For example, if an NE is connected to node A and node B, and the alarm quantity on node A is more than node B, the processing of the full current alarm cache is performed only on node A.

#### **Procedure**

- **Step 1** Choose **Device Management > Alarms Management > Alarm Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Current Alarm Threshold Warning**.
- **Step 3** Select whether to send an alarm when the number of current alarms reaches the threshold and set the thresholds for generating and clearing alarms.
  - **Generation threshold**: When the ratio of the number of current alarms to the maximum capacity is greater than or equal to the specified threshold, ALM-157 The Number of Current Alarms Reaches the Threshold is generated.
  - Clearance threshold: When the ratio of the number of current alarms to the maximum capacity is less than the specified threshold, ALM-157 The Number of Current Alarms Reaches the Threshold is cleared. The clearance threshold cannot be higher than the generation threshold.

Step 4 Click Apply.

----End

#### 2.3.5.20 Redefine Alarm

To quickly search for and handle key device alarms to which you pay special attention, you can redefine these alarms. The NetEco provides five types of alarm redefinition rules: redefine alarm name, redefine alarm type, redefine alarm severity, redefine alarm causes and redefine handling suggestions.

**Table 2-23** description of the function of redefining alarms.

**Table 2-23** Function of Redefining Alarms

Task Description	Operation entry	Procedure
Configuring Redefinition Alarms	<ol> <li>Choose Device         Management &gt;         Alarm Management         &gt; Alarm Settings.</li> <li>In the navigation tree on the left, choose Redefine Alarm.</li> <li>Set search criteria to filter alarm data.</li> </ol>	<ol> <li>In the device tree and select a target device.</li> <li>Click the operation column .</li> <li>Enter the redefinition alarm information according to the actual situation, and then click OK .</li> <li>NOTE         After saving redefinition alarms, the redefined alarm status is changed to enabled after the synchronization is complete.     </li> </ol>
Clearing Redefining Alarm Rules  NOTE  After saving redefinition alarms, the alarm redefinition rule can be cleared.		Use either of the following methods to clear redefinition alarms:  On the Redefine  Alarm page, Click in the row where the indicator to be cleared is located.  On the Redefine  Alarm page, Select the target data to be cleared and click  Clear above the page.

Task Description	Operation entry	Procedure
Enabling or disabling Redefining Alarm Rules		Use either of the following methods to enable or disable redefinition alarms:
		On the Redefine Alarm page, click  or the row of the target data row to be enabled.
		On the Redefine     Alarm page, select     the target data for     which redefinition     alarm rules need to     be enabled, click     Enable or Disable in     the upper part of the     page.
Refresh the redefined alarm		On the <b>Redefine Alarm</b> page, click <b>Refresh</b> in the upper part of the page to refresh the redefined alarm page.
Batch Redefinition Rule Application		On the <b>Redefine Alarm</b> page, click in the operation column for the target alarm in the active alarm list to apply alarm rules configured specified in the alarm rule to other rules in batches.

2022-02-25 108

Task Description	Operation entry	Procedure
Batch Apply to Devices		Select a target device from the device tree.
		<ul> <li>If you need to apply a specified alarm rule to alarms of other devices of the same type, select the alarm rule record and click Batch Apply to Devices. On the displayed page, select Selected for Selected items.</li> </ul>
		<ul> <li>If you need to apply all alarm rules of the target device to alarms of other devices of the same type, click Batch Apply to Devices. On the displayed page, select Select All for Selected items.</li> </ul>
		Set the application items and application scope.
		<ul> <li>If you need to apply a specified alarm rule of the target device to the alarms of all devices of the same type, select All Objects for Application scope.</li> </ul>
		<ul> <li>If you need to apply a specified alarm rule of the target device to the alarms of specified devices of the same type, select Custom for Application scope and select the</li> </ul>

Task Description	Operation entry	Procedure
		devices to which the alarm rule is to be applied in the management domain area.
		3. Click <b>OK</b> .

## 2.3.5.21 Threshold Alarm

This section describes the management of thresholds. When managing site components, you can customize threshold alarms for some key counters. You can set multiple threshold ranges for the same counter based on the alarm severity, including critical, major, minor, and warning.

## **Prerequisites**

You have the operation rights for **Set Threshold Rules**.

## **Context**

- You can set performance counter thresholds for certain components of NEs.
- The thresholds can be set based on the alarm severity, including **Critical**, **Major**, **Minor**, and **Warning**.
- After the threshold rule is set, the rule is enabled by default.
- After the file is exported, you can edit rules locally. Multiple rules correspond
  to one alarm name. The rule upper or lower thresholds are displayed in one
  rule. If one rule corresponds to one alarm name, you are advised to copy and
  insert the current signal data. The rule upper or lower thresholds are
  displayed in two rules.

#### Procedure

- **Step 1** Choose **Device Management > Alarm Management > Alarm Settings**.
- **Step 2** In the navigation tree on the left, click the **threshold alarm**.
- **Step 3** In the device tree and select a target device, choose **Real-Time Signals**, **Statistics Signals** or **Custom Signals**.
- **Step 4** Click in the **Operation** column of the target data. The **Set Rule** dialog box is displayed.
- **Step 5** Set the alarm name.
  - If multiple rules correspond to one alarm name, enter Alarm Name.
  - If one rule corresponds to one alarm name. Click to enable the customized threshold setting.

**Step 6** Select the threshold rule and set the rule parameters and duration. For details about parameters, see **Table 2-25**.

## Step 7 Click OK.

Table 2-24 Operations related to threshold rules

Tasks	Operation
Clear a threshold rules	Use either of the following methods to clear a threshold alarm:
	<ul> <li>Click for the counter whose threshold alarm needs to be cleared.</li> </ul>
	<ul> <li>Select the counter whose threshold alarm needs to be cleared, and click Clear in the upper part of the page.</li> </ul>
Enable or disable a threshold rules	Use either of the following methods to enable a threshold alarm:
	Click or for the counter whose threshold alarm needs to be enabled.
	<ul> <li>Select the counter whose threshold alarm needs to be enabled, and click <b>Enable</b> or <b>Disable</b> in the upper part of the page.</li> </ul>
Customize threshold rules  NOTE  You can custom threshold alarms only the Custom Signals tab page.	<ol> <li>Click Advanced and set Signal Name and Expression.</li> <li>Click Next.</li> <li>Set the alarm name.         <ul> <li>If multiple rules correspond to one alarm name, enter Alarm Name.</li> <li>If one rule corresponds to one alarm name.</li> </ul> </li> <li>Click to enable the customized threshold setting.</li> <li>Select the threshold rule and set the rule parameters and duration. For details about parameters, see Table 2-25.</li> <li>Click OK.</li> </ol>
Deleting Customized Signals and Counters  NOTE You can delete a custom counter only the Custom Signals tab page.	<ol> <li>Delete a custom counter.</li> <li>Click in the row that contains the custom counter to be deleted.</li> <li>On the current page, select the custom counters to be deleted and click Clear in the upper part of the page.</li> <li>In the displayed dialog box, click OK.</li> </ol>

Tasks	Operation
Batch Apply to Counters	In the <b>Threshold Alarm</b> window, click operation column for the target alarm in the active alarm list to apply the threshold conditions specified in the rule to other alarm rules with the same type of threshold condition. <b>NOTE</b> Meaning of the same type of threshold condition:  If the threshold condition of a selected rule is of the numeric type, the rule can only be batch applied to the rules whose threshold condition is the numeric type.  If the threshold condition of a selected rule is of the enumerated type, the rule can only be batch applied to the rules whose threshold condition is the enumerated type.
Batch Apply to Devices	In the Threshold Alarm window, click Batch Apply to Devices below the active alarm list to apply the selected alarm rules to other devices in batches.  NOTE  You can select either of the following options for batch application:  • All objects: The rules are applied to all existing and future devices of the same type.  • Custom: The rules are applied to devices of the same type under the current root node.  Rules for applying an empty rule: for two devices of the same type, if the threshold condition content in a rule of one device is not set, and the rule is applied to the other device's rule for which the threshold condition content has been set, the threshold condition content set for the rule of the other device will be cleared.
Exporting data	<ol> <li>Click Export.</li> <li>In the displayed dialog box, select export range and export data.</li> <li>Click OK.</li> </ol>
Importing data	<ol> <li>Click Import.</li> <li>In the displayed dialog box, click Upload.</li> <li>In the Upload dialog box, click the file to be uploaded.</li> <li>Select a local file and click OK.</li> </ol>
Refresh threshold alarms	In the <b>Threshold Alarm</b> window, click <b>Refresh</b> in the upper part of the page to refresh threshold alarms.

2022-02-25 112

**Table 2-25** Parameters for setting performance counter thresholds

Parameter	Description
Alarm name	Name of a threshold alarm. After <b>Alarm name</b> is selected, corresponding threshold alarms can be generated when performance counter measurement results meet alarm triggering conditions.
	You can set the alarm name as required.
Upper Threshold for XX Alarm	Upper threshold for a performance counter, which can be set as required. XX indicates the alarm severity. If the measured performance counter is greater than or equal to the upper-threshold, an alarm of the corresponding severity is generated.
	The value of this parameter must meet the following conditions:
	The value for triggering an upper-threshold alarm is greater than that for clearing the upper-threshold alarm.
	The value for triggering a high-level upper-threshold alarm is greater than that for triggering a low-level upper-threshold alarm.
Lower Threshold for XX Alarm	Lower threshold for a performance counter, which can be set as required. XX indicates the alarm severity. If the measured performance counter is less than or equal to the lower threshold, a lower-threshold alarm of the corresponding severity is generated.
	The value of this parameter must meet the following conditions:
	The value for triggering a lower-threshold alarm is less than or equal to the one for clearing the lower-threshold alarm.
	The value for triggering a high-level lower-threshold alarm is less than that for triggering a low-level lower-threshold alarm.
Condition for Clearing Upper	Threshold for clearing an upper-threshold alarm, which can be set as required. If the measured performance counter is less than or equal to this threshold, the upper-threshold alarm of the corresponding severity is cleared. The value for clearing an upper-threshold alarm must be less than or equal to the one for triggering the upper-threshold alarm.
Condition for Clearing Lower	Threshold for clearing a lower-threshold alarm, which can be set as required. If the measured performance counter is greater than or equal to this threshold, the lower-threshold alarm of the corresponding severity is cleared. The value for clearing a lower-threshold alarm must be greater than or equal to the one for triggering the lower-threshold alarm.

Parameter	Description
Duration	Duration refers to the time at which the threshold condition needs to be reached continuously for generating an alarm for a signal. If the value of a signal reaches the threshold condition continuously within that time specified by this parameter, a corresponding threshold alarm is generated. If the duration is 10s, the corresponding threshold alarm is generated when all signals reach the threshold within 10s.

----End

# 2.4 Predefined Big Screen

# 2.4.1 Predefined Big Screen

The predefined big-screen monitoring function allows users to display monitoring services such as topologies on high-resolution screens, facilitating the display of monitoring information and IT O&M effects of multiple smart modules.

## **Prerequisites**

- You have the operation rights of **View**, **Predefined Screen** and **Predefined Screen Setting**.
- You have the operation rights of View, Single Line, Chiller Group Control, Energy Analysis, and View Access Control Events.
- You have the management domain permissions for equipment rooms, outlets, and containers.

#### **Procedure**

- **Step 1** Choose **Device Management > Big Screen Monitor > Predefined Big Screen**.
- **Step 2** Select the equipment room for which you want to set the predefined big screen.
  - 1. Click in the upper part of the navigation tree.
  - 2. In the displayed dialog box, select the equipment room for which you want to set the predefined big screen.

Only one predefined big screen can be created for an equipment room.

- Click Yes.
- **Step 3** Set the company name and logo, and predefine the greetings and display time format on the big screen.
  - 1. Click in the upper left corner to set the company name and logo.
  - 2. Click above the topology to set the predefined big screen greeting.

3. Click 🤨 in the upper right corner to set the time format.

**Step 4** Set the service type and equipment room view display mode.

1. Click in the upper right corner of a service in the monitoring view to set the service data type.

#### **◯** NOTE

- You must have the operation rights of Energy Analysis to view PUE, Power Consumption Comparison, and Power Consumption Trend.
- You must have the operation rights of View Access Control Events to view Access Event.
- You must have the operation rights of **View** to view **Alarm Information**.
- 2. Click in the upper right corner of the topology to select the view display mode, and determine whether to show or hide the single-line electrical diagram and chiller group control. When **Choose View Mode** is set to **3D**, you can perform operations in **Table 2-26**.

#### □ NOTE

You must have the operation rights of **View**, **Single Line**, and, **Chiller Group Control** to view the 2D, 2.5D, and 3D topology views, single-line electrical diagrams, and chiller group control diagrams.

Table 2-26 view operation tasks

Operation	Description	Procedure
Adjusting views	Adjust the view effect to stay in the optimal view.	Zoom and rotate the view.
View details about the smart module in the equipment room.	The 3D view supports the drill-down function to view details about smart modules in the equipment room.	Double-click the smart module or device to be viewed to drill down, and right-click to return to the previous layer.
Viewing the space, power distribution, and cooling capacity of a cabinet	Display the space, power distribution, and cooling capacity of each cabinet in 3D mode.	Select <b>Power</b> , <b>Cooling</b> or <b>Space</b> on the right of the view.
Setting wall display status	Make equipment room walls transparent to highlight information about other devices in the equipment room.	Select <b>Transparent</b> on the right of the view.

Operation	Description	Procedure
Setting the Device Display Status	The sensors and cameras connected to the equipment room are displayed in the 3D topology.	Select <b>Device Location</b> on the right of the view, and then click the button for displaying the device.

- 3. View KPIs of key devices in the lower part of the topology.
- Step 5 Click Save.
- **Step 6** In the displayed dialog box, enter the name of the predefined big screen and click **OK**.

----End

## Follow-up Procedure

In the navigation tree on the left, choose a predefined big screen and perform the following operations:

If You Need to	Then
Modify the unit screen name.	Click . When the status becomes editable, you can modify the unit screen name.
Delete a unit screen.	Click to delete a predefined big screen.

2022-02-25 116

# 3 O&M Management

You can learn about the running status of all sites.

#### 3.1 Availability Management

The NetEco provides the site report function to allow you to learn about the running status of all sites in real time and analyze and handle problems in the sites.

#### 3.2 Security

The NetEco provides functions such as access control management and video management to ensure physical security of devices and environments and help you detect and handle exceptions in a timely manner.

# 3.1 Availability Management

The NetEco provides the site report function to allow you to learn about the running status of all sites in real time and analyze and handle problems in the sites.

# 3.1.1 Viewing a DC Report

This function allows you to view a DC report, including the overview, DC statistics, and alarm statistics.

### **Procedure**

- Step 1 Choose Maintenance Management > Availability Management > Net DC Report.
- **Step 2** On the **DC Report** page, view the overview, DC statistics, and alarm statistics.

In the **Alarms** area, click the alarm rectangle to go to the **Current Alarms** page to view detailed alarm information. For details about how to handle alarms, see **2.3.1.2 Handling Alarms**.

----End

# 3.2 Security

The NetEco provides functions such as access control management and video management to ensure physical security of devices and environments and help you detect and handle exceptions in a timely manner.

# 3.2.1 Access Control Management

The access control management module configures and manages access control devices and monitors access events to control and audit access rights, improving the security management capability of each management domain.

## 3.2.1.1 Managing Access Control Devices

You can create access control devices and remotely open and close the door of an access control device to effectively manage the access control device.

## **Prerequisites**

You have the operation rights for Access Control Management.

#### **Procedure**

- **Step 1** Choose **Maintenance Management** > **Security Protection** > **Access Control Management**.
- **Step 2** In the navigation tree on the left, choose **Device Management** and perform the following operations based on the scenario.

**Table 3-1** Managing access control devices

Operatio n	Description	Procedure
Creating an access control device	Before managing access control devices, you need to connect the access control devices to the NetEco.	<ol> <li>Click Create.</li> <li>On the Planning         Configuration page, create an access control device. For details, see 1.4.2 Adding a Device Through Automatic Discovery.     </li> </ol>
		After an access control device is created successfully, you can view the device on the <b>Device Management</b> page.

Operatio n	Description	Procedure
Remotely opening a door	You can remotely open a door under an access controller.	Click in the <b>Operation</b> column. <b>NOTE</b> The door is automatically closed within 6 seconds after the door is remotely opened.
Remotely closing a door	You can remotely close a door under an access controller.	<ul> <li>Remotely closing a single door         Click in the Operation column.     </li> <li>Remotely closing doors in batches         Click Remotely close door(s) in batches.     </li> </ul>

----End

## 3.2.1.2 Managing Access Control Events

You can query the access records and event records of a specified access control device within a specified time range, and export the query results to a PC for storage.

## **Prerequisites**

You have the operation rights for Access Control Management.

#### Procedure

- **Step 1** Choose **Maintenance Management** > **Security Protection** > **Access Control Management**.
- **Step 2** In the navigation tree, choose **Access Event**.
- **Step 3** Select an access control device, set the search criteria, and click **Search**.
  - Access Records: users' door opening/closing records on the device side
  - **Event Records**: all event records related to devices, including door opening/ closing records and door open alarm records

By default, the access records or event records of all access control devices within 24 hours on the current day are displayed. To export access records or event records, click **Export**.

#### □ NOTE

- If the event records on the NetEco are inconsistent with those on the device, you can click **Sync Log** to synchronize the log information on the device to the NetEco.
- For card swiping on an access controller, the card number, user name, and user ID are recorded for a valid card, and only the card number is recorded for an invalid card.

#### ----End

# 3.2.2 Video Management

The video management module provides functions such as camera management and parameter setting.

## 3.2.2.1 Managing Cameras

You can view camera details, create cameras, and play videos.

## **Prerequisites**

- You have the operation rights for Camera Management.
- Before playing videos from cameras managed by the video subsystem, you need to set video playback parameters. For details, see 6.5 How Do I Set Video Playback Parameters on the Video Surveillance Subsystem?.

## **Procedure**

- **Step 1** Choose **Maintenance Management > Security Protection > Camera Management**.
- **Step 2** In the navigation tree on the left, choose **Camera Information**.
- **Step 3** On the **Camera Information** page, you can perform operations as required.
  - Viewing camera information
     The detailed information about all cameras is displayed.
  - Creating a camera

**Table 3-2** Creating a camera

Operation	Procedure
Creating a directly connected camera	<ol> <li>Select Directly connected camera from the dropdown list box in the upper left corner of the page.</li> <li>On the Planning Configuration page, create a directly connected camera. For details, see Adding a Device Through Automatic Discovery.</li> </ol>

Operation	Procedure
Creating a camera in	Select <b>Video surveillance subsystem</b> from the drop- down list box in the upper left corner of the page.
automatic discovery mode	2. On the <b>Video Surveillance Subsystem</b> page, click <b>Create</b> .
	3. In the <b>Creating a Video Subsystem</b> dialog box, select a video subsystem type, set related parameters according to <b>Table 3-3</b> , and click <b>Test</b> .
	NOTE  If the test fails, check whether the parameters are correctly set.
	4. Click <b>Save</b> .

 Table 3-3 Parameters of the video subsystem

Parameter	Description	Example
IP	IP address of the video subsystem	192.168.8.10
Port	Port number of the video subsystem	9900

Parameter	Description	Example
User Name	User name for logging in to the client of the video subsystem  NOTE  - The NetEco needs to have browse and query permissions.  Configure the video system users with browse and query permissions.	Admin
	- You are advised to use a new user created in the video subsystem to connect to the camera. Before the connection, ensure that the initial password of the user has been changed and the user has successfully logged in to the video subsystem.	
	- You are advised to set the number of clients that can be logged in to by the user on the video subsystem to a value greater than 5. Otherwise, when the user has logged in to the video subsystem, the user cannot connect to the video subsystem through the NetEco.	
Password	User password for logging in to the client of the video subsystem.	Change_Me

# Playing videos

Click the name or of an online camera.

## ₩ NOTE

On the **View** page, click to view the camera information. Click the name of an online camera in the **Name** column to play videos.

----End

## 3.2.2.2 Viewing live videos

You can record suspicious images and alarm-triggered images, take snapshots, and view real-time videos to monitor sites for visualized site management.

## **Prerequisites**

- You have the operation rights for Camera Management.
- You have added cameras. For details, see **3.2.2.1 Managing Cameras**.
- Communication is normal between cameras and the NetEco.

#### 

For a camera managed by the video surveillance subsystem, ensure that the time of the video surveillance subsystem server is consistent with the NetEco server time.

 Before playing video from cameras managed by the video surveillance subsystem, you need to set video playback parameters. For details, see How Do I Set Video Playback Parameters on the Video Surveillance Subsystem?.

## **Procedure**

- **Step 1** Choose **Maintenance Management** > **Security Protection** > **Camera Management**.
- **Step 2** In the navigation tree on the left, choose **Live Video**.

## □ NOTE

If the Firefox browser is used, perform the following operations before playing a video for the first time (Firefox 78 is used as an example):

- 1. In the displayed **Confirm** dialog box, click **Yes**.
- 2. In the two dialog boxes that are displayed, click **Advanced**, and then click **Accept Risk** and **Continue**.
- **Step 3** You can click a video source to view video in full screen, record video, and take snapshots.

Table 3-4 Operation tasks

Operation	Procedure
Viewing videos in full screen	Click to display the video in full screen. To exit the full screen mode, right-click the mouse or press <b>Esc</b> .
Recording videos	<ol> <li>Click in the lower right corner and select Start Recording.</li> <li>In the Recording Length dialog box, set the video recording duration and click OK.</li> <li>NOTE</li> </ol>
	<ul> <li>The video can be recorded in up to nine split screens. You can select one, four, or nine split screens as required.</li> </ul>
	<ul> <li>After the recording time is set, the camera automatically stops video recording after the specified recording time. During video recording,</li> </ul>
	you can click in the lower right corner and choose <b>Stop Recording</b> .

Operation	Procedure
Taking snapshots	Click in the lower right corner and select <b>Capture Manually</b> .
Setting groups	Enable grouping , select the group name from the drop-down list box, and view the video of the group.
	Creating a group
	1. Click <b>Create</b> .
	2. Set related parameters and click <b>OK</b> .
	Deleting a group: Select one or more groups and click <b>Delete</b> .
	Modifying a group
	1. Click <b>Modify</b> in the <b>Operation</b> column of the target group.
	2. Modify related parameters and click <b>OK</b> .

----End

2022-02-25 124

**4** System

This section describes the operations related to the system.

## 4.1 System Settings

This section describes the operations related to system settings.

## 4.2 System Management

This section describes system management operations.

4.3 About

# 4.1 System Settings

This section describes the operations related to system settings.

# 4.1.1 System Configuration

You can refresh the system time, display the view, configure the protocol switch, and change the FTP password by system configuration.

## 4.1.1.1 Refreshing System Time

The system supports refreshing the NetEco server time and the client time simultaneously.

## **Procedure**

- **Step 1** Choose **System > System Setting > System Configuration**.
- **Step 2** In the navigation pane on the left, choose **System Configuration** > **System Time**.
- **Step 3** On the **System Time** page, click **Refresh** to refresh the NetEcoserver time and the client time.

## **NOTICE**

The NetEco server time and the client time are automatically refreshed once every 1 second. The refresh stops when you close the page.

----End

## 4.1.1.2 Modifying the FTP Password

This section describes how to modify the FTP password. To improve user security, users are advised to change their passwords periodically.

## **Prerequisites**

You have the operation rights for FTP password Setting.

## **Context**

The following figure shows the default information about the ftpuser and nftpuser users, as shown in **Table 4-1**.

<b>Table 4-1</b> Default information about the ftpuser and nftpuser user	Table 4-1	Default info	ormation a	bout the	ftpuser	and nftpuser	users
--	-----------	--------------	------------	----------	---------	--------------	-------

User	Initial Password	Description
ftpuser	Random password	<ul> <li>Common user.</li> <li>The <b>ftpuser</b> user is an FTP service operator responsible for file transfer between the NetEco server and clients or NEs.</li> </ul>
nftpuser	Random password	<ul> <li>Common user.</li> <li>User nftpuser is used for uploading and downloading files for the NMS to access the NetEco through the LAN.</li> </ul>

## **Procedure**

- **Step 1** Choose **System > System Setting > System Configuration**.
- **Step 2** In the left navigation pane of the **System Configuration** page, click **FTP Password Setting**.
- **Step 3** Set the user name and password, and click **Confirm**.

#### **NOTICE**

When you log in to the system for the first time, the passwords of users ftpuser and nftpuser are random. You need to reset the passwords.

#### ----End

## 4.1.2 Notifications

The notifications feature allows the system to send messages remotely. Users can set parameters related to notifications to enable the system to communicate with the short message service gateway (SMSGW), short message service (SMS) modem, or mail server. In this way, users can obtain important function notifications in a timely manner, such as alarms and events, in the form of SMS messages or emails.

## 4.1.2.1 Third-Party App Notification Settings

The NetEco can send alarm notifications to O&M personnel through the enterprise WeChat public account (service account).

## 4.1.2.1.1 Setting the WeChat Notification Server

This topic describes how to set notifications on WeChat.

## **Prerequisites**

- The enterprise WeChat official account or individual WeChat test account has been created, and information such as appid and appsecret of the official account has been obtained.
- The NetEco user has the operation rights for **Notifications**.
- You have obtained a valid WeChat certificate from the WeChat official account platform (https://mp.weixin.qq.com/) and imported it to NetEcoNBIService-Wechat Certificates. Import the WeChat certificate. For details, see 4.3.1.1 Managing Service Certificates.
- The network connection between the NetEco and WeChat official account platform (api.weixin.qq.com) is normal.

#### **◯** NOTE

- The WeChat official account platform uses the common domain name api.weixin.qq.com for interconnection. Ensure that the NetEco server can access the domain name as a client. The NetEco does not need to function as the server to be accessed by the domain name.
- To use the enterprise WeChat official account, you need to add the public IP address of the NetEco to the IP address whitelist of the official account.

## **Procedure**

- **Step 1** Choose **System > System Settings > Notifications** from the main menu.
- Step 2 On the Notifications page, choose Third-Party App Notification Settings > Server Configuration on the left. The Server Configuration page is displayed.

**Step 3** On the **Server Configuration** page, set parameters for the NetEco system and WeChat Official Account server by referring to the following table.

**Table 4-2** Setting Server parameters

Parameter	Description	Default Value
Notify method	Indicates the notification mode used for interconnecting with a third-party app server. Currently, only <b>WeChat Official Account</b> is supported.	WeChat Official Account
Official account for receiving notifications	Indicates the official account that receives the notifications.	Custom enterprise official account
Official account App ID	Indicates the ID of the official account that needs to receive notifications.	N/A
Official account App Secret	Indicates the key of the official account that needs to receive notifications.	N/A
Enable	The system sends third-party app notifications only when server parameter settings are enabled.	No

## Step 4 Click Apply.

----End

## 4.1.2.1.2 Configuring WeChat Notification Users

This topic describes how to configure WeChat notification users.

## **Prerequisites**

- O&M personnel who need to receive alarm notifications have followed the Official Account.
- The NetEco user has the operation rights for **Notifications**.

## **Procedure**

- **Step 1** Choose **System > Systems Settings > Notifications** from the main menu.
- **Step 2** On the **Notifications** page, choose **Third-Party App Notification Settings** > **Offical Account User**.
- Step 3 On the Offical Account User page, click Sync Users.

----End

## 4.1.2.1.3 Configuring WeChat Notification Rules

This topic describes how to configure WeChat notification users.

2022-02-25 128

## **Prerequisites**

- The NetEco user has the operation rights for Notifications.
- The WeChat notification server has been enabled.
- The notification users have been created.
- The alarm notification template ID set in the Official Account has been obtained.

#### **Procedure**

- **Step 1** Choose **System > Systems Settings > Notifications** from the main menu.
- Step 2 In the navigation pane on the left, choose Third-Party App Notification Settings > Notification Rule.
- **Step 3** On the **Notification Rule** page, click **Create**.
- **Step 4** On the **Create Notification Rule** page, set notification rule parameters and click **Test**.
  - If the users receive the WeChat test notification, the test is successful.
  - If the test is abnormal, check whether the configuration parameters are correct and whether the network connection is normal. If the configuration and network are normal but the test still fails, contact technical support engineers.

#### Step 5 Click OK.

----End

## 4.1.2.1.4 Configuring WeChat Notification User Groups

You can configure WeChat official account user groups to classify users and facilitate user management.

## **Prerequisites**

- O&M personnel who need to receive alarm notifications have followed the Official Account.
- The NetEco user has the operation rights for **Notifications**.

#### **Procedure**

- **Step 1** Choose **System > Systems Settings > Notifications** from the main menu.
- **Step 2** On the **Notifications** page, choose **Third-Party App Notification Settings** > **Offical Account User Group.**
- **Step 3** On the **Offical Account User Group** page, click **Create**.
- **Step 4** On the **Creating a User Group** page, set parameters such as **Group Name** and click **OK**.

----End

# 4.2 System Management

This section describes system management operations.

# 4.2.1 User Management

User management provides functions such as user rights management, area management, and user maintenance and monitoring.

The user management function allows users with different responsibilities to be granted proper permissions and allows users to adjust permissions based on service changes. This ensures that users have the necessary permissions to perform related tasks, thereby ensuring that other management tasks are carried out in an orderly manner, preventing unauthorized operations and insecure operations.

## 4.2.1.1 User Authorization

After system installation and commissioning, security administrators need to grant different operation rights to users of different roles based on service planning.

## 4.2.1.1.1 Authorization Process

This section describes the user authorization process and methods.

Figure 4-1 shows the user authorization process.




Figure 4-1 User authorization process

You can bind a user to role and grant permissions to the user in the following ways:

- Create a role and grant permissions to the role, create a user, and attach the user to the role, as shown in the preceding figure.
- Create a user (not attached to any role), select the user when creating a role, and grant permissions to the role.

## 4.2.1.1.2 Planning Authorization

Authorization planning classifies users based on their responsibilities. During user authorization, first perform authorization planning to reduce the workload on authorization and permission maintenance. Appropriate authorization planning improves system security and usability.

The authorization planning principles are as follows:

- Users with the same responsibilities are attached to the same role. Users with different responsibilities are attached to different roles.
- If multiple roles require the same application operations, plan a common application operation set for these roles. If not, plan application operation sets or grant application operation rights to each role separately.
- If multiple roles require the same device operations, plan a device operation set for these roles. If not, plan device operation sets or grant device operation rights to each role separately.

## 4.2.1.1.3 (Optional) Creating a Device Set

To efficiently grant permissions to users who manage same objects from different subnets or device types, security administrators need to plan and create a device set before role authorization.

## **Prerequisites**

Log in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Managed Objects**.
- **Step 3** On the **Device Sets** tab page, click **Create** and set basic information.

□ NOTE

You can quickly create a device set by clicking **Copy** in the **Operation** column of a device set and adjusting the information as required.

- **Step 4** You can choose **Select by Topology** and **Select by Device Type** in **Member Information** to select devices for a device set.
- Step 5 Click OK.

----End

## **Related Tasks**

You can perform the following operations as required:

• To modify a device set, click the name of the device set, and change members in the device set.

If the device set to be modified is associated with a user, the modification will take effect the next time the user logs in.

• To delete a device set, click **Delete** in the **Operation** column of the row that contains the device set to be deleted.

∩ NOTE

If the device set to be deleted is associated with a user, the user will lose management permissions on all the objects in this set.

## 4.2.1.1.4 (Optional) Creating a User-defined Operation Set

If operation sets are planned during authorization planning, security administrators need to create user-defined operation sets before user authorization. Authorizing roles using operation sets improves authorization efficiency.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Operation Sets**.
- **Step 3** On the **Operation Sets** page, click **Create**.

**Ⅲ** NOTE

You can quickly create an operation set by clicking **Copy** in the **Operation** column of an operation set and adjusting the information as required.

- **Step 4** On the displayed page, set **Operation set name**, **Type**, and **Description**.
- **Step 5** Select the operation rights to be included in the operation set from the list of available operation rights.

□ NOTE

You can delete redundant operation rights from the operation list by selecting these operation rights and clicking **Delete**.

**Step 6** On the **Operation Sets** page, click **OK**.

----End

## **Related Tasks**

For details about how to maintain operation set information, see **4.2.1.4.3**Common Operations for Operation Set Information Maintenance.

## 4.2.1.1.5 Creating a Role and Granting Permissions

If the default roles provided by the system cannot meet user authorization requirements in the authorization plan, security administrators need to create roles and grant them permissions based on the plan.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

- If only a few roles are required, create them one by one.
- If multiple roles are required or the roles are obtained from the files exported from other systems, create roles in batches.

#### **Procedure**

Creating a single role

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Roles**.
- Step 3 On the Roles page, click Create.

#### **Ⅲ** NOTE

You can quickly create a role by clicking **Copy** in the **Operation** column of a role and adjusting the information as required.

- **Step 4** On the displayed page, set basic role information.
- **Step 5** Select the users to be attached to the role.

After role authorization is complete, the users you have selected have the permissions included in this role.

- **Step 6** Click **Next** and select the managed objects included in the role based on the authorization plan.
  - All Objects: shows all the resources that can be managed by the system. It is the default managed object provided by the system and cannot be modified or deleted.
  - **Subnets**: shows all the subnets that can be managed by the system. If a subnet is selected for a user, this user can manage the subnet and all its managed objects, including devices and subnets.
  - **Devices**: If a user needs to manage specified devices, you can grant permissions by device.
  - **Resource Groups**: If a resource group is selected for a role, this role can manage all the resources in the group. Resources are grouped by resource type using Resource Groups.
- **Step 7** Click **Next**. Based on the authorization plan for application-level operation rights and device-level operation rights of the role, set application-level operation rights of the role on the **Application-Level** tab page and set device-level operation rights for each managed object included in the role on the **Device-Level** tab page.

When setting device-level operation rights, select a managed object first. The device operations that can be bound to the managed object are displayed in the **Operations** list box. Then, you can select the devices operations to be authorized.

#### Step 8 Click OK.

#### ----End

- Creating roles in batches
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** On the **Roles** page, click and choose **Batch Create Roles**.
- **Step 4** On the **Batch Create Roles** page, click a template name to download the template.

#### 

The system provides two template formats: **Role Template.xls** and **Role Template.xlsx**, and you can edit the template in .csv format. Select a template format as required.

- **Step 5** Fill in role information based on the template.
- **Step 6** Click . In the displayed dialog box, select the edited template.
- Step 7 Click Create.

After roles are imported, you can perform the following operations:

- 1. On the displayed page, view the number of successfully imported roles and the number of roles that fail to be imported.
- 2. In the **Result** list, view the imported roles and their details.
- 3. If partial failure occurs, modify the role information that failed to be imported based on the details, and import them again.
- Step 8 Click OK.
- **Step 9** Assign permissions to the roles created in batches based on the authorization plan.
  - 1. On the **Roles** page, click a role name.
  - 2. On the **Managed Objects** or **Operation Rights** tab page, click **Edit**, and assign permissions to the role.

----End

## Follow-up Procedure

If a user logs in to a third-party system in SSO mode, role information (excluding operation rights) about this user can be synchronized to the third-party system. To ensure that this user has the same operation rights on the third-party system as those on the system, create the same role for the user on the third-party system and bind the same operation rights to the role.

#### **Related Tasks**

For details about how to maintain role information, see **4.2.1.4.2 Common Operations for Role Information Maintenance**.

## 4.2.1.1.6 (Optional) Configuring User Policies

User policies refer to rules for system accesses and operation control. The system provides the default account policy and password policy. After authorization is planned, you need to set user policies if the default account policy or password policy does not meet requirements or if IP address access control or login time control is required for users.

For details about how to configure user policies, see **User Policy Management**.

## 4.2.1.1.7 Creating a User and Attaching the User to a Role

After a security administrator creates a user and attaches the user to a role, the user has the permissions of this role.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

- If only a few users are required, create them one by one.
- If multiple users need to be created or users are obtained from the files exported from other systems, create users in batches.
- If a user has logged in to the management system, disabling the user will force a logout of the user. Therefore, exercise caution when performing this operation.

## **Procedure**

- Creating a single user
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** On the **Users** page, click **Create**.
  - □ NOTE

You can quickly create a user by clicking **Copy** in the **Operation** column of a user and adjusting the information as required.

**Step 4** On the displayed page, set basic user information.

Users are classified into three types: **Local**, **Third-party**, and **Remote**, with different parameters for each user type.

- To create a user for logging in to the local system, set the user type to Local.
- In the scenario that a third-party system is connected, set the user type to **Third-party**. Third-party users can log in only through the third-party authentication interface, and are not allowed to log in using a web browser.
- To create a user for interconnecting an LDAP or RADIUS server, locally create a user with the same username as a user on the LDAP or RADIUS server and set the user type to **Remote**.
- **Step 5** Click **Advanced Settings**, set parameters such as **Max. online sessions**, and click **Next**.

Parameters are described in Table 4-3.

**Table 4-3** Advanced parameters

Paramete r	Description	Value Range
Max. online sessions	Maximum number of online sessions of an account.	By default, this parameter is disabled, indicating that the number of the user login sessions is not limited. If this parameter is enabled, the value range is from 1 to 500. The setting of this parameter is described as follows:
		<ul> <li>If Max. online sessions is set to 1, Login when maximum online sessions already in use can be Not allowed or Log out of the session.</li> </ul>
		<ul> <li>Not allowed: After the number of online sessions reaches the upper limit, the user cannot log in to the management system.</li> </ul>
		<ul> <li>Log out of the session: After the number of online sessions reaches the upper limit, the user's subsequent session causes the logout of a previous session.</li> </ul>
		<ul> <li>If Max. online sessions is set to a value from 2 to 500, Login when maximum online sessions already in use is Not allowed and the value cannot be changed.</li> </ul>
Account validity	Number of days during which an account can log in to the management system.	By default, this parameter is disabled, indicating that the account is permanently valid. If this parameter is enabled, the value range is from 1 to 180 (unit: day). This user account is not allowed to log in to the management system after the validity period elapses, and the user needs to contact the security administrator.

Paramete r	Description	Value Range
Allowed logins	Number of times during which an account can log in to the management system.	By default, this parameter is disabled, indicating that the number of the user account's login times is not limited. If this parameter is enabled, the value range is 0 to 10. The user account is not allowed to log in to the management system after the allowed login times are used up, and the user needs to contact the security administrator.
Auto- logout if no activity within	If a user does not perform any operation within the period specified by this parameter after logging in to the management system, the user will be logged out. This parameter can be set for local users and remote users. The default value for the third-party user is 30 minutes and cannot be changed.	The default value is 30 min. The value can be System setting (subject to the system account policy), 10 min, 30 min, 2 h, 6 h, 12 h, 24 h, 48 h, or Unlimited.
Enable the user policy if no login within a period	If a user does not log in to the management system for the period specified by this parameter, one of the following policies will be taken:  Deleting users Disabling a user Unlimited	By default, a user is disabled if the user remains offline for 60 consecutive days. The value range of this parameter is 1 to 1000 days.  By default, this parameter is unselected. In this case, the account policy in the system applies to this user. If this parameter is selected, the system deletes or disables a user based on the selected policy when the period during which this user does not log in reaches the value specified by this parameter.

Paramete r	Description	Value Range
Compulsor y password renewal	Password validity period policy. (This parameter is not displayed during the creation of remote users.)  Password validity (days)  In advance warning before password expires (days)  Min. password usage period (days)	By default, this parameter is unselected. In this case, the password policy in the system applies to this user. If this parameter is selected, the system prompts the user to change its password if the usage period of the password reaches the values specified by this parameter.  • The default value of Password validity (days) is 90, and the value range is from 2 to 999. 0 indicates that the password never expires.  • The default value of In advance warning before password expires (days) is 10, and the value range is from 1 to 99.  • The default value of Min. password usage period (days) is 10, and the value range is from 1 to 999.

- If the same parameters are set in Advanced Settings and Account Policy, the settings in Advanced Settings are used. For details about how to set the account policy, see 4.2.4.1 Setting the Account Policy.
- If the same parameters are set in **Advanced Settings** and **Password Policy**, the settings in **Advanced Settings** are used. For details about how to set the password policy, see **4.2.4.2 Setting the Password Policy**.

**Step 6** Select the role to which the user is attached and click **Next**.

Click a role name to view the permissions of the role.

You can create a role and attach the user to the new role. For details about how to create a role, see **4.2.1.1.5 Creating a Role and Granting Permissions**. After creating a role, you can click **Refresh** on the role list page and select the new role for the user from the role list.

#### **NOTICE**

When creating a user as the system administrator user, you are advised not to attach the new user to both the **Administrators** and **SMManagers** roles to ensure system security. A user attached to both the **Administrators** and **SMManagers** roles has the maximum permissions of all resources in the system. Exercise caution when using such users to perform operations and do not perform any operations that affect system security. For example, do not share or disclose the names and passwords or names of these users.

**Step 7** Select a login time policy and a client IP address policy for the user.

You can also click **Create** to create a login time policy or client IP address policy as needed.

Step 8 Click OK.

- ----End
- Creating users in batches
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** On the **Users** page, click and choose **Import Users**.
- **Step 4** On the **Import Users** page, click the template name to download the template and enter user information in the template.

· ~ `		_
	KII II	-

The system provides two template formats: **User Template.xls** and **User Template.xlsx**, and you can edit the template in .csv format. Select a template format as required.

**Step 5** Choose **Create Users** to import users.

_	_		_	_	_
4 1	rı	 a i		•	
		IN		,,,	•

If the passwords for the non-remote users are not configured in the imported file, set the passwords on the page.

- **Step 6** Click . In the displayed dialog box, select the edited template.
- **Step 7** Click **Create**. After the import is complete:
  - 1. On the displayed page, view the number of successfully imported users and the number of users who fail to be imported.
  - 2. In the **Result** list, view the imported users and their details.
  - 3. If partial failure occurs, modify the user information that failed to be imported based on the details, and import them again.

Step 8 Click OK.

----End

4 System

## **Related Tasks**

For details about how to maintain user information, see **4.2.1.4.1 Common Operations for User Information Maintenance**.

## 4.2.1.2 Permission Adjustment

Permissions can be maintained after security administrators perform initial user authorization. If the managed resources or users, or user responsibility is changed, security administrators need to adjust user permissions.

## 4.2.1.2.1 Permission Adjustment After Subnets Are Added

After a subnet is added, security administrators need to plan the user who manages the subnet and device-level operation rights for the new subnet, and then bind the operation rights to the role to which the user is attached.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- Operation rights for the new subnet have been planned.

### Context

The operations in this section will change user rights and the changes take effect upon the next login. Exercise caution when performing these operations.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** Check whether the role has been automatically bound to the operation rights for the new subnet.
  - If the parent subnet of the new subnet has been added to the managed objects of the role to which the user is attached and the operation sets bound to the parent subnet contain the operations on the new subnet, the user has the operation rights for the new subnet by default after the subnet is added, and no further action is required.
  - If the parent subnet of a new subnet has been added to the managed objects of the role to which the user is attached, but the operation set bound to the parent subnet does not contain operations on the new subnet, the user does not have the operation rights for the new subnet after the subnet is added. In this case, go to Step 4.
  - If the parent subnet of the new subnet is not added to the managed-object scope of the role to which the user is attached, go to **Step 5** and **Step 6**.
- **Step 4** Bind the device-level operation rights for the new subnet to the role.
  - 1. On the **Roles** page, click the role name.
  - 2. Go to the **Operation Rights** tab page and click **Device-Level**.

- 3. Click Edit.
- 4. In the **Authorization Objects** list, select the parent subnet to which you want to add a subnet. In the **Operations** list, select the device operation rights you want to bind to the new subnet.
- 5. Click OK.
- **Step 5** Add the new subnet to the managed-object scope of the role.
  - 1. On the **Roles** page, click the role name.
  - 2. Switch to the **Managed Objects** tab page and click **Edit**.
  - 3. Go to the **Subnets** tab page and select the new subnet.
  - 4. Click OK.
- **Step 6** Bind operation rights to the new subnet.
  - 1. On the **Roles** page, click the role name.
  - 2. Go to the **Operation Rights** tab page and click **Device-Level**.
  - 3. Click Edit.
  - 4. In the **Authorization Objects** list, select the new subnet. In the **Operations** list, select the device operation rights you want to bind to the new subnet.
  - 5. Click OK.

----End

## 4.2.1.2.2 Permission Adjustment After Devices Are Added

After a device is added, security administrators need to plan the user who manages the device and operation rights for the new device, and then bind the operation rights to the role to which the user is attached.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- Operation rights for the new device have been planned.

#### **Context**

The operations in this section will change user rights and the changes take effect upon the next login. Exercise caution when performing these operations.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** Check whether the role has been automatically bound to the operation rights for the new device.
  - If the subnet where the new device is located has been added to the managed objects of the role to which the user is attached and the operation sets bound to the subnet contain the operations on the new device, the user

- has the operation rights for the new device by default after the device is added, and no further action is required.
- If the subnet where the new device is located has been added to the managed objects of the role to which the user is attached and the operation sets bound to the subnet do not contain the operations on the new device, the user does not have the operation rights for the new device by default after the device is added. In this case, go to **Step 4**.
- If none of the preceding assumptions are satisfied, the new device is beyond the managed objects of the role to which the user is attached. In this case, go to **Step 5**.

**Step 4** Bind the operation rights for the new device to the role.

- 1. On the **Roles** page, click the role name.
- 2. Go to the **Operation Rights** tab page and click **Device-Level**.
- 3. Click Edit.
- 4. Select the device operation rights to be bound to the new device.
- 5. Click OK.

**Step 5** Add the new device to the managed objects of the role.

- 1. On the **Roles** page, click the desired role name. Go to the **Managed Objects** tab page.
- 2. Click Edit.
- 3. Go to the **Devices** tab, and select the new devices.
- 4. Click OK.

**Step 6** Bind operation rights to the new device.

- 1. On the **Roles** page, click the role name. Go to the **Operation Rights** tab page and click **Device-Level**.
- 2. In the **Authorization Objects** list, select the device by referring to **Step 5**. In the **Operations** list, select the operation rights to be bound to the device.
- 3. Click OK.

----End

## 4.2.1.2.3 Permission Adjustment After Networking Modification

After networking is modified, operation rights for managed objects involved in the modification may need to be transferred to another role. In this case, security administrators need to adjust the role permissions.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- Operation rights for the subnet whose networking is modified and for the devices on the subnet have been planned.

## Context

The operations in this section will change user rights and the changes take effect upon the next login. Exercise caution when performing these operations.

4 System

#### **Procedure**

- **Step 1** Check whether the networking is globally reorganized.
  - If it is, plan users and roles again.
  - If it is not, go to Step 2.
- **Step 2** Handle operation rights for the moved devices.
  - If devices are moved out of the network, users who manage the network lose the operation rights for the moved devices. No further action is required.
  - If devices are moved to the network, perform permission adjustment by following the instructions provided in 4.2.1.2.2 Permission Adjustment After Devices Are Added.

----End

## 4.2.1.2.4 Permission Adjustment After the Objects Managed by Users Are Changed

If the operation rights for an object need to be transferred from one role to another while the managed-object topology is not changed, security administrators need to adjust the managed objects and operation rights of the users.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- Operation rights for the target managed object have been planned.

#### Context

The operations in this section will change managed objects and operation rights and the changes will take effect upon the next login. Exercise caution when performing these operations.

#### **Procedure**

- 1. Choose **System > System Management > User Management** from the main menu.
- 2. In the navigation pane, choose **Roles**.
- 3. Click a role name, and go to the **Managed Objects** tab page. View the managed objects included in the role and add or delete managed objects based on new requirements.
- 4. Go to the **Operation Rights** tab page, and modify the device-level operation rights for the modified managed objects.

### 4.2.1.2.5 Permission Adjustment After Operation Rights of Users Are Changed

If certain operation rights attached to a role need to be added or deleted due to responsibility changes, security administrators need to adjust the role and permissions of this role as needed.

# **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

- If authorization for the role is not performed based on an operation set, adjust the permissions of the role by modifying the role.
- If authorization for the role is performed based on an operation set, adjust the permissions of the role by modifying the operation set.
- This operation will change the permissions of users attached to this role. Therefore, exercise caution when performing this operation. The permission changes will take effect after next login of these users.

### **Procedure**

- Modifying a role
  - a. Choose System > System Management > User Management from the main menu.
  - b. In the navigation pane, choose **Roles**.
  - c. Click the role to be modified, go to the **Operation Rights** page, and click **Edit**.
  - d. View the operation rights included in the role and add or delete operation rights based on new requirements.
- Modifying an operation set
  - a. Choose **System > System Management > User Management** from the main menu.
  - b. In the navigation pane, choose **Operation Sets**.
  - c. Select an operation set, and then click **Edit**.
  - d. View the operation rights included in the operation set and add or delete operation rights based on new requirements.

## □ NOTE

One operation may be included in multiple operation sets. Operation rights of a role can be deleted only when the operations are not included in any operation sets attached to this role.

## 4.2.1.2.6 Permission Adjustment After a User's Role Is Changed

After the position of an employee is changed, security administrators need to adjust the role to which the user account of the employee is attached to change permissions of the employee.

# **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

- Disabling and deleting users will force a logout of logged-in users. Therefore, exercise caution when performing these operations.
- A position change occurs in the following situations:
  - An employee is recruited.

- The role of an employee (as a user) is changed.
- An employee resigns.

## **Procedure**

- An employee is recruited.
  - a. Choose **System > System Management > User Management** from the main menu.
  - b. In the navigation pane, choose **Users**.
  - c. On the **Users** page, click **Create**.
  - d. On the displayed page, set basic user information and click **Next**.
  - e. Select the role to which the user is attached and click **Next**.
  - f. Set access control information about the user and click **OK**.
- The role of an employee (as a user) is changed.
  - a. Choose **System > System Management > User Management** from the main menu.
  - b. In the navigation pane, choose **Users**.
  - c. Click the name of the user whose role is changed and go to the **Roles** tab page.
  - d. Click **Edit** in the upper right corner of the page.
  - e. Add or delete the role of a user based on the user position changes.
- An employee resigns.
  - a. Choose **System > System Management > User Management** from the main menu.
  - b. In the navigation pane, choose **Users**. On the page that is displayed, perform the following operation as required:
    - If you want to retain the account, click **Disable** in the **Operation** column of the row that contains the user to disable the user.
    - If you do not want to retain the account, click **Delete** in the **Operation** column of the row that contains the user to delete the user.

# 4.2.1.3 Regional User Permission Management

To improve management efficiency, security administrators divide the network into regions based on service requirements and allow different personnel to manage users and services in different regions. In a region, region administrators can create roles, assign permissions to the roles, and attach users to roles to grant them corresponding permissions. This implement user management in the region.

### 4.2.1.3.1 Planning Authentication in a Region

Before region management, the security administrator must plan authentication in the region properly to reduce the workload of authorization and permission maintenance in regions.

Figure 4-2 shows the process of planning authentication in a region.

User Manual 4 System



Figure 4-2 Process of planning authentication in a region

• Plan regions.

Plan regions based on physical networking and service requirements. You are advised to plan regions based on administrative zones and managed objects.

- Plan the users who belong to the same administrative zone to the same region.
- Plan the administrative zones that have the same managed objects to the same region.
- A maximum of 20 regions can be planned.
- Plan the authorization scope of a region administrator.
   Each region has region administrators. Plan the operation rights and managed objects of region administrators after planning regions.
- Plan managed objects, operation sets, roles, and users in a region.
   Plan users who have same responsibilities to the same role. Analyze operation rights required for each role to fulfill their responsibilities and classify the operation rights into operation sets.

## 4.2.1.3.2 Creating a Region Management Process

This section describes the region management process.

Figure 4-3 shows the region management process.




Figure 4-3 Region management process

## 4.2.1.3.3 Creating a Region

Security administrators can create regions as planned to facilitate region-based management and improve permission management efficiency.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Regions**.
- Step 3 On the page that is displayed, click +.
- **Step 4** In the **Create Region** dialog box, enter basic region information and click **OK**.

- Select **Automatically create Region Administrators**. After a region is created, the system automatically generates a region administrator role for this region. By default, this role has the **User Management** and **Query Security Log** permissions.
- If Automatically create Region Administrators is not selected, you need to manually create a region administrator role after the region is created. For details, see 4.2.1.3.4
   Creating a Region Administrator Role.

----End

### **Related Tasks**

If you need to modify or delete a region due to service changes, click  $\mathscr{C}$  or  $\times$  in the upper right corner of the region box.

∩ NOTE

Before deleting a region, delete all the users, common roles, and operation sets from the region.

## 4.2.1.3.4 Creating a Region Administrator Role

After creating a region, security administrators need to create a region administrator role and specify the authorization scope for the region administrator role.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

If **Automatically create Region Administrators** is not selected when a region is created, you need to manually create the region administrator role for this region.

If **Automatically create Region Administrators** is selected, after the region is created, you need to set the authorization scope for the region administrator role that is automatically created.

### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Regions**.
- **Step 3** Select the target region and click the **Roles** tab.
- **Step 4** On the **Roles** tab page. Click **Create** and choose **Region Administrators**.
- **Step 5** On the **Basic Information** page, set the basic information and click **Next**.
- **Step 6** On the **Select Mandate-Managed Objects** page, set the managed objects that can be assigned by the region administrator based on the authorization planning.

The managed objects of a region administrator can be set by All Objects or Subnets.

**Step 7** On the **Select Mandate-Operation Rights** page, set the permissions that can be assigned by the region administrator based on the authorization planning.

□ NOTE

The authorization scope of a region administrator can be set by operation set.

### Step 8 Click OK.

**◯** NOTE

The region administrator role has the **User Management** and **Query Security Log** permissions.

----End

### **Related Tasks**

The security administrator can perform the following operations as required:

Exporting roles by region: Click , and choose Export All Roles.

**◯** NOTE

- If the number of roles exceeds 500, role information is exported to multiple files. That is, each file contains information about a maximum of 500 roles.
- The file is exported in .csv or .xlsx format and downloaded to the local PC as a .zip package.
- Security administrators can export role information of each region.

## 4.2.1.3.5 Creating a Region Administrator

After creating a region, security administrators need to create a region administrator and attach the region administrator to the region administrator role so that the region administrator has security management permissions on this region.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu
- **Step 2** In the navigation pane, choose **Regions**.
- **Step 3** In the region list, click the target region.
- **Step 4** On the **Users** tab page, click **Create** to create a user.
- **Step 5** On the displayed page, set basic user information.

- **Step 6** (Optional) Click **Advanced Settings**, set parameters such as **Max. online sessions**, and click **Next**.
- **Step 7** On the **Roles** page, select the region administrator role to which this user needs to be attached and click **Next**.
- Step 8 Set access control information about the user and click OK.

If the current access control information does not meet requirements, you can create the required access control information by referring to 4.2.4.3 Setting a Client IP Address Policy and 4.2.4.4 Setting a Login Time Policy.

After security administrators create a region administrator, the new region administrator will be displayed in the user list of the region. The region administrator can use this user account to log in to the NetEco and manage user permissions in the region.

----End

### **Related Tasks**

Security administrators can perform the following operations as required:

 Viewing region administrator information: Click a region administrator name to view basic information, operation rights, and access policies of this administrator.

### □ NOTE

Security administrators can view information about all region administrators. Region administrators can only view information about region administrators in their own regions.

• Exporting users in a region: Click , and choose **Export All Users** or **Export Selected Users**.

### □ NOTE

- The **Password**, **Mobile number**, and **Email address** fields are not exported. Therefore, the values of these fields are empty in the exported user information file
- Security administrators can export information about all the users (including users in regions) in the system.
- The file is exported in .csv or .xlsx format and downloaded to the local PC as a .zip package.

### 4.2.1.3.6 Creating Operation Sets in a Region As Planned

Region administrators can create operation sets in a region to improve permission management efficiency in the region.

## **Prerequisites**

You have logged in to the NetEco as a region administrator.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Operation Sets**.
- **Step 3** On the **Operation Sets** page, click **Create**.

□ NOTE

You can quickly create an operation set by clicking **Copy** in the **Operation** column of an operation set and adjusting the information as required.

- **Step 4** On the displayed page, set **Operation set name**, **Type**, and **Description**.
- **Step 5** Select operations for the operation set.

If unnecessary operations exist in the operation rights list, click **Delete** to delete them.

A region administrator can only create operation sets based on the operation rights of a region administrator role.

Step 6 Click OK.

----End

#### **Related Tasks**

You can adjust the operation rights included in an operation set as required by selecting an operation set and clicking **Edit**.

### 4.2.1.3.7 Creating a Role in a Region and Granting Permissions

A region administrator can create common roles in the region to centrally grant permissions to users in this region.

## **Prerequisites**

You have logged in to the NetEco as a region administrator.

### **Context**

- If only a few roles are required in a region, create them one by one.
- If multiple roles are required in a region or the roles are obtained from the files exported from other systems, create roles in batches.
- The operations in this section will change user permissions. Exercise caution when performing these operations.

#### **Procedure**

- Creating a common role in a region
- **Step 1** Choose **System > System Management > User Management** from the main menu.

- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** On the **Roles** page, click **Create**.

You can quickly create a role by clicking **Copy** in the **Operation** column of a role and adjusting the information as required.

**Step 4** On the displayed page, enter the basic role information, select users to be attached to the role, and click **Next**.

#### ∩ NOTE

If a user has been attached to a regional administrator role, you cannot attach this user to a common role.

- **Step 5** Select the managed objects included in the role based on the role plan during authorization planning.
  - All Objects: shows all the resources that can be managed by the system. It is the default managed object provided by the system and cannot be modified or deleted.
  - **Subnets**: shows all the subnets that can be managed by the system. If a subnet is selected for a user, this user can manage the subnet and all its managed objects, including devices and subnets.
- **Step 6** Based on the authorization plan for application-level operation rights and device-level operation rights of the role, set application-level operation rights of the role on the **Application-Level** tab page and set device-level operation rights for each managed object included in the role on the **Device-Level** tab page.

When you set device-level operation rights for a managed object, select the managed object first and then select the device operation sets to be bound to the object. After you select a managed object, device operation sets that can be bound to the object are listed in **Operations**.

Roles in regions can only be authorized by operation set. For details about how to create an operation set in a region, see **4.2.1.3.6 Creating Operation Sets in a Region As Planned**.

**Step 7** Confirm role information and click **OK**.

#### ----End

- Creating common roles in a region
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** On the **Roles** page, click and choose **Batch Create Roles**.
- **Step 4** On the **Batch Create Roles** page, click a template name to download the template.

The system provides two template formats: **Role Template.xls** and **Role Template.xlsx**, and you can edit the template in .csv format. Select a template format as required.

- **Step 5** Fill in role information based on the template.
- **Step 6** Click . In the displayed dialog box, select the edited template.

### Step 7 Click Create.

#### □ NOTE

Security administrators can import roles of all regions. Region administrators can import only roles of their own regions.

After roles are imported, you can perform the following operations:

- On the displayed page, view the number of successfully imported users and the number of users who fail to be imported.
- In the **Result** list, view the imported roles and their details.

### Step 8 Click OK.

- **Step 9** Assign permissions to the roles created in batches based on the authorization plan.
  - 1. On the **Roles** page, click a role name.
  - 2. On the **Managed Objects** or **Operation Rights** tab page, click **Edit**, and assign permissions to the role.

----End

# Follow-up Procedure

If a user logs in to a third-party system in SSO mode, role information (excluding operation rights) about this user can be synchronized to the third-party system. To ensure that this user has the same operation rights on the third-party system as those on the system, create the same role for the user on the third-party system and bind the same operation rights to the role.

### **Related Tasks**

You can perform the following operations as required:

- Viewing role information in a region: Click the name of the role whose information will be viewed.
- Modifying role information in a region: Click the name of the role whose information will be modified, and then click Edit.
- Deleting roles: To delete a single role, click **Delete** in the **Operation** column of the row that contains this role. To delete roles in batches, select the roles to be deleted and click **Delete**.

**□** NOTE

You cannot delete the region administrator role and the role to which the current user is attached.

Exporting roles: Click , and choose Export All Roles.

- If the number of roles exceeds 500, role information is exported to multiple files. That is, each file contains information about a maximum of 500 roles.
- A region administrator can export only roles of the region to which the region administrator belongs.
- The file is exported in .csv or .xlsx format and downloaded to the local PC as a .zip package.

## 4.2.1.3.8 Creating a User in a Region and Attaching the User to a Role

After a region administrator creates a user and attaches the user to a role, the user has the permissions of this role.

## **Prerequisites**

You have logged in to the NetEco as a region administrator.

## **Context**

- If only a few users are required in a region, create them one by one.
- If multiple users are required in a region or the users are obtained from the files exported from other systems, create users in batches.
- The operations in this section involve user permission adjustment, which will force a logout of logged-in users. Therefore, exercise caution when performing this operation.

### **Procedure**

- Creating a single user
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** On the **Users** page, click **Create** to create a user.

#### □ NOTE

- You can quickly create a user by clicking **Copy** in the **Operation** column of a user and adjusting the information as required.
- If you are copying a user attached to the region administrator role, the copied user will be detached from the role.
- **Step 4** On the displayed page, set basic user information.
- **Step 5** (Optional) Click **Advanced Settings**, set parameters such as **Max. online sessions**, and click **Next**.

## **MOTE**

- If the same parameters are set in **Advanced Settings** and **Account Policy**, the settings in **Advanced Settings** are used. For details about how to set the account policy, see **4.2.4.1 Setting the Account Policy**.
- If the same parameters are set in **Advanced Settings** and **Password Policy**, the settings in **Advanced Settings** are used. For details about how to set the password policy, see **Setting the Password Policy**.

**Step 6** Select the role to which the user is attached and click **Next**.

Click a role name to view information about the role, such as the permissions and managed objects included in the role.

#### ■ NOTE

A user cannot be attached to both the region administrator role and a common role of the region.

**Step 7** Set access control information about the user and click **OK**.

### □ NOTE

Third-party users can log in only through the third-party authentication interface. They are not allowed to log in using a web browser.

#### ----End

- Creating users in batches
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** On the **Users** page, click and choose **Import Users**.
- **Step 4** On the **Import Users** page, click the template name to download the template and enter user information in the template.

#### □ NOTE

The system provides two template formats: **User Template.xls** and **User Template.xlsx**, and you can edit the template in .csv format. Select a template format as required.

**Step 5** Choose **Create Users** to import users.

#### 

- If the passwords for the non-remote users are not configured in the imported file, set the passwords on the page.
- Region administrators can import users only to their own regions.
- **Step 6** Click . In the displayed dialog box, select the edited user information file.
- **Step 7** Click **Create**. After the import is complete:
  - In the displayed dialog box, view the number of successfully imported users and the number of users who fail to be imported.
  - In the Result list, view the imported users and their details.

#### Step 8 Click OK.

----End

## **Related Tasks**

 Viewing information about users in a region: Select a username and view Basic Information, Roles, and Access Policies.

- Modifying information about users in a region: Select a user name and then click view **Edit**.
- Resetting the password for a user in a region: Click Reset Password in the Operation column of the row that contains the user whose password needs to be reset.
- Deleting users in a region: To delete a single user, click **Delete** in the
   Operation column of the row that contains the user to be deleted. To delete
   users in batches, select the users to be deleted, and click **Delete**.

#### ∩ NOTE

The current user cannot be deleted.

- Disabling a user in a region: Click **Disable** in the **Operation** column of the row that contains the user to be disabled.
- Enabling a user in a region: Click **Enable** in the **Operation** column of the row that contains the user to be enabled.
- Unlocking users:
  - To unlock a user: Click Unlock in the Operation column of the row that contains the user.
  - To unlock users in batches: Click and choose Batch Unlock Users.
     If the users are not disabled, these users can log in to the NetEco after being unlocked.
- Exporting users in a region: Click , and choose **Export All Users** or **Export Selected Users**.

### ■ NOTE

- The **Password**, **Mobile number**, and **Email address** fields are not exported. Therefore, the values of these fields are empty in the exported user information file
- Security administrators can export information about all the users (including users in regions) in the system.
- The file is exported in .csv or .xlsx format and downloaded to the local PC as a .zip package.

### 4.2.1.3.9 Modifying User Information in a Region in Batches

Region administrators can modify user information (such as **Max. online sessions** and **Login Time Policy**) in batches, improving system security.

## **Prerequisites**

You have logged in to the NetEco as a region administrator.

## **Context**

- You can use the following methods to modify user information in batches:
  - Using the Batch Modify Users function
     Select the users whose information needs to be modified and click Batch Modify Users.
  - Modifying an exported user information file

Export user information as a file, edit the file, and then import it to the system.

• The operations in this section involve user permission adjustment, which will force a logout of logged-in users. Therefore, exercise caution when performing this operation.

### **Procedure**

- Using the Batch Modify Users function
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** In the user list, select one or more users, click , and choose **Batch Modify** Users.
- **Step 4** Check that the users on the **User List** page are consistent with those you want to modify, and click **Next**.

## 

To modify a user in User List, perform the following operations:

- If some users to be modified are not in the list, click **Cancel** and select the users to be modified again.
- If some users who do not need to be modified are in the list, click **Delete** in the
   Operation column of the rows that contain these users to delete them.
- Step 5 On the Modification Items tab page, modify user information and click OK.

#### **◯** NOTE

- You cannot modify your own information.
- A maximum of 100 users can be modified at a time.
- After the login time policy is modified, the users who do not meet the policy requirements will be forcibly logged out.
- **Step 6** On the **Modification Result** page, view the modification results and details.

#### ----End

- Modifying an exported user information file
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- Step 3 Select the users whose information needs to be exported, click , and choose Export All Users or Export Selected Users.

### **Ⅲ** NOTE

- The **Password**, **Mobile number**, and **Email address** fields are not exported. Therefore, the values of these fields are empty in the exported user information file.
- Security administrators can export information about all the users (including users in regions) in the system.

- **Step 4** In the **Select File Format** dialog box, select a file format and click **OK**.
- **Step 5** Modify the exported user information file.

- When modifying the user information file, do not change the sequence of the fields in the file
- If you change the value of a field to empty or an invalid value, the value of this field will not be changed.
- The following user information cannot be modified:
  - Type and Region of all users
  - All information about the current user
  - Password, Login Time Policy, Client IP Address Policy, Personal Client IP Address Policy, and Password Validity Period (Days) of remote users
  - Password and Auto-Logout If No Activity Within of third-party users
- **Step 6** Click and choose **Import Users**.
- **Step 7** In the **Import Users** window, choose **Update Users**.
- **Step 8** Click , select the modified user information file, and click **Modify**.
- **Step 9** After the import is complete:
  - 1. On the displayed page, view the number of successfully modified users and the number of users who fail to be modified.
  - 2. In the **Result** list, view the imported users and their details.

#### Step 10 Click OK.

----End

## 4.2.1.3.10 Moving Roles from the Default Region to Another Region

Security administrators can move roles from the default region to another region. The roles are then managed by the destination region administrator.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- A region has been created. For details about how to create a region, see **4.2.1.3.3 Creating a Region**.

### Context

The operations in this section will detach roles from related users, managed objects, and operation rights. Therefore, exercise caution when performing this operation.

#### **Procedure**

**Step 1** Choose **System > System Management > User Management** from the main menu.

- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** Select the roles to be moved, click , and choose **Move Selected Roles**.

Default roles, such as **Administrators** and **SMManagers**, and roles to which the current user is attached cannot be moved.

- Step 4 Confirm the roles to be moved in the list. Click Next.
- **Step 5** Select the destination region.

#### □ NOTE

After a role is move to another region, related users, managed objects, and operation rights will be detached from the role.

**Step 6** Click **Move**. On the **Moving Result** page, view the moving results and details.

After a role is moved, it is displayed in the role list of the destination region.

Step 7 Click OK.

----End

## Follow-up Procedure

After moving a role out of a region, bind managed objects and operation rights to the role again.

## 4.2.1.3.11 Moving Users from the Default Region to Another Region

Security administrators can move users from the default region to another region. The users are then managed by the destination region administrator.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- A region has been created. For details about how to create a region, see
   4.2.1.3.3 Creating a Region.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** Select the users to be moved, click , and choose **Move Selected Users**.

**◯** NOTE

Users attached to default roles, default users, third-party users, remote users, and the current user cannot be moved.

- Step 4 Confirm the users to be moved in the list. Click Next.
- **Step 5** Select the destination region.

#### 

After a user is moved out of the region, related roles will be detached from the user. If the user has logged in to the NetEco, this operation will force a logout of the user. Therefore, exercise caution when performing this operation.

**Step 6** Click **Move**. On the **Moving Result** page, view the moving results and details.

After a user is moved, it is displayed in the user list of the destination region.

Step 7 Click OK.

----End

# Follow-up Procedure

After a user is moved from the default region to another region, attach the user to roles again.

## 4.2.1.3.12 Moving Roles Out of a Region

When maintaining multiple regions, security administrators need to adjust some roles across regions. For example, security administrators may need to change a role in a region to a role in another region.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- A region has been created. For details about how to create a region, see
   4.2.1.3.3 Creating a Region.

### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Regions**.
- **Step 3** Click the region to which to-be-moved roles belong to open the page of this region.
- **Step 4** Click the **Roles** tab, select the roles to be moved, click , and choose **Move Selected Roles**.
- **Step 5** Confirm the roles to be moved in the list. Click **Next**.
- **Step 6** Select the destination region.

□ NOTE

After a role is moved out of the region, related users, managed objects, and operation rights will be detached from the role. Perform this operation with caution.

**Step 7** Click **Move**. On the **Moving Result** page, view the moving results and details.

After a role is moved, it is displayed in the role list of the destination region.

User Manual 4 System

### Step 8 Click OK.

----End

## Follow-up Procedure

After moving a role out of a region, bind managed objects and operation rights to the role again.

## 4.2.1.3.13 Moving Users Out of a Region

When maintaining multiple regions, security administrators need to adjust the responsibilities of some users across regions. For example, security administrators may need to change a local user in a region to a security administrator or local user of another region.

## **Prerequisites**

- You have logged in to the NetEco as a security administrator.
- A region has been created. For details about how to create a region, see
   4.2.1.3.3 Creating a Region.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Regions**.
- **Step 3** Click the region to which to-be-moved users belong to open the **User Management** page for the region.
- **Step 4** Select the users to be moved, click , and choose **Move Selected Users**.

□ NOTE

Third-party users, remote users, and users attached to a region administrator role cannot be moved

**Step 5** Confirm the users to be moved in the list. Click **Next**.

**◯** NOTE

To modify a user in **User List**, perform the following operations:

- If some users to be moved are not in the list, click Cancel and select the users to be moved again.
- If some users who do not need to be moved are in the list, click **Delete** in the **Operation** column of the rows that contain these users to delete them.

**Step 6** Select the destination region.

■ NOTE

- After a user is moved, related roles will be detached from the user.
- Moving users out of a region will force a logout of users who have logged in to the NetEco. Therefore, exercise caution when performing this operation.

User Manual 4 System

**Step 7** Click **Move**. On the **Moving Result** page, view the moving results and details.

After a user is moved, it is displayed in the user list of the destination region.

Step 8 Click OK.

----End

## Follow-up Procedure

After a user is moved out of a region, attach the user to roles again.

## 4.2.1.3.14 Monitoring Users in a Region

User sessions in a region can be monitored so that region administrators can know the online users of this region in the system, access addresses of these users, access time, and roles of the users. When detecting an unauthorized user operation, the system sends a message to the user or forcibly log out the user.

## **Prerequisites**

You have logged in to the NetEco as a region administrator.

### **Context**

- A user session refers to a connection between a user and the system. A session starts when the user logs in to the system and ends when the user logs out of the system. A user can generate multiple sessions.
- Multiple users can log in to the NetEco at the same time. The maximum number of login users is specified by the **Max. online sessions** parameter.
- User sessions in a region can be monitored only by region administrators.
- Users' personal information is not monitored during session monitoring.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Online Users**.

The status information about all online users in the region is displayed in the list.

□ NOTE

- Client Name indicates the name of the client where this session is generated.
- Third-party users do not consume resource control items.
- **Step 3** Click **Monitor** in the **Operation** column of the target user to view the status of the user.
  - The User Operations list displays only operations performed after the Online
    Users page is opened. Operations of the monitored users are updated in the
    User Operations list in real time.
  - Level indicates the risk level of an operation, including Risk, Minor, and Warning. The value of Level is the same as that recorded in operation logs.

**Step 4** When detecting that a user is performing risky operations, click **Log Out** in the **Operation** column of the user to forcibly log out the user.

#### **NOTICE**

This operation involves user login status and may force a logout of logged-in users. Therefore, exercise caution when performing this operation.

**Step 5** To send a message to a user, click **Send Message** in the **Operation** column of the user.

----End

### 4.2.1.4 User Maintenance

Security administrators can maintain user, role, and operation set information, and reset other users' passwords. Users can modify their personal information.

## 4.2.1.4.1 Common Operations for User Information Maintenance

Common operations for user information maintenance include viewing user information, enabling users, disabling users, deleting users, exporting user information, and modifying user information.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** Perform operations according to **Table 4-4** based on site requirements.

**Table 4-4** User maintenance operations

Common Operation	Procedure
Viewing user informatio n	Click a username to view the user information.
Disabling a user	Click <b>Disable</b> in the <b>Operation</b> column of the row that contains the user you want to disable.
Enabling a user	Click <b>Enable</b> in the <b>Operation</b> column of the row that contains the user you want to enable.

Common Operation	Procedure		
Deleting users	Click <b>Delete</b> in the <b>Operation</b> column of the row that contains the user to be deleted or select the users to be deleted and click <b>Delete</b> .  NOTE  • Default users, current user, and users attached to the <b>SMManagers</b> role		
	<ul> <li>cannot be deleted.</li> <li>Deleting a logged-in user will force a logout of the user. Therefore, exercise caution when performing this operation.</li> </ul>		
Importing user	1. On the <b>Users</b> page, click and choose <b>Import Users</b> .		
informatio n	On the <b>Import Users</b> page, click the template name to download the template and enter user information in the template.  NOTE		
	<ul> <li>The system provides two template formats: User Template.xls and User Template.xlsx, and you can edit the template in .csv format. Select a template format as required.</li> </ul>		
	<ul> <li>When editing a template in .csv format and creating a time policy, add double quotation marks before and after the time policy to ensure that the import is successful. The following shows an example.</li> </ul>		
	"NewTimePolicy;start-time:00:00,end-time:23:59;start-date: 2017-01-01,end-date:2017-12-31;week:135"		
	3. Fill in user information based on the template.		
	4. Set <b>Import Mode</b> , and click  in the dialog box that is displayed, select the edited template.		
	5. Click <b>Create</b> or <b>Modify</b> .  After the import is complete:		
	<ul> <li>a. On the displayed page, view the number of successfully imported operation sets and the number of operation sets that fail to be imported.</li> </ul>		
	b. In the <b>Result</b> list, view the imported users and their details.		
	c. If partial failure occurs, modify the user information that failed to be imported based on the details, and import them again.		
	6. Click <b>OK</b> .		
Exporting user informatio n	To export information about all users, click and choose <b>Export All Users</b> . To export information about certain users, select these users and click <b>Export Selected Users</b> .  NOTE		
	<ul> <li>The Password, Mobile number, and Email address fields are not exported. Therefore, the values of these fields are empty in the exported user information file.</li> </ul>		
	The file is exported in .csv or .xlsx format and downloaded to the local PC as a .zip package.		

Common Operation	Procedure	
Modifying user	Click the name of the user whose information needs to be modified.	
informatio n	2. Select the tab to be modified and click <b>Edit</b> to modify the user information.	
	NOTE	
	<ul> <li>Auto-logout if no activity within: If a user does not perform any operation within the period specified by this parameter, the user will be logged out. This parameter can be set for local users and remote users and cannot be set for third-party users.</li> </ul>	
	<ul> <li>During user modification, setting Enable account to No for a logged-in user will force a logout of the user. Therefore, exercise caution when performing this operation.</li> </ul>	
	3. Click <b>OK</b> .	
Unlocking users	To unlock a user: Click <b>Unlock</b> in the <b>Operation</b> column of the row that contains the user.	
	To unlock users in batches:	
	<ol> <li>Optional: You can change All statuses to Locked to quickly filter all locked users.</li> </ol>	
	2. Select users to be unlocked.	
	3. Click and choose <b>Batch Unlock Users</b> .	
	NOTE	
	Default users, unlocked users, current user, and users attached to the <b>SMManagers</b> role cannot be unlocked.	

----End

## 4.2.1.4.2 Common Operations for Role Information Maintenance

Common operations for role information maintenance include viewing role information, deleting roles, exporting role information, and modifying role information.

# **Prerequisites**

You have logged in to the NetEco as a security administrator.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Roles**.
- **Step 3** Perform operations according to **Table 4-5** based on site requirements.

**Table 4-5** Role maintenance operations

Common Operation	Procedure	
Viewing role informatio n	Click a role name to view information about this role.	
Deleting roles	Click <b>Delete</b> in the <b>Operation</b> column of the row that contains the role to be deleted or select the roles to be deleted and click <b>Delete</b> .  NOTE	
	You cannot delete default roles and the roles to which the current user is attached.	
	Deleting roles will cause the users attached to these roles to lose the permissions of the roles. Therefore, exercise caution when performing this operation.	
Exporting role information	Click and choose <b>Export All Roles</b> to export information about all roles.  NOTE	
	<ul> <li>If the number of roles exceeds 500, role information is exported to multiple files. That is, each file contains information about a maximum of 500 roles.</li> </ul>	
	The file is exported in .csv or .xlsx format and downloaded to the local PC as a .zip package.	
Modifying role	Click the name of a role whose information needs to be modified.	
informatio n	Select the tab to be modified and click <b>Edit</b> to modify the role information.	
	NOTE	
	<ul> <li>You cannot modify the managed objects and operation rights of the roles to which the current user is attached.</li> </ul>	
	<ul> <li>You cannot modify the managed objects and operation rights of default roles.</li> </ul>	
	<ul> <li>Modifying the role information will change the permissions of users attached to this role. Therefore, exercise caution when performing this operation. The permission changes will take effect upon page refreshing or after next login of these users.</li> </ul>	
Saving	1. Click the name of the desired role.	
informatio	2. Click the <b>Operation Rights</b> tab.	
n about role permissions	3. Click <b>Save</b> to save the information about the role permissions.	

# ----End

## 4.2.1.4.3 Common Operations for Operation Set Information Maintenance

Common operations for operation set maintenance include viewing operation set information, deleting an operation set, and modifying operation set information. Importing and exporting operation sets are applicable to system data migration.

## **Prerequisites**

You have logged in to the NetEco as a security administrator or the system administrator.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Operation Sets**.
- **Step 3** Perform the following operations as needed.

Common Operation	Procedure		
Viewing operation set information	Click an operation set name to view details about the operation set.		
Deleting an operation set	Click <b>Delete</b> in the <b>Operation</b> column of the row that contains the operation set.  NOTE  If the deleted operation set is associated with a user, the user will lose all operation rights included in the deleted operation set.  You cannot delete default operation sets and the operation sets to which the role of the current user is bound.		
Modifying operation set information	<ol> <li>Click the name of an operation set whose information needs to be modified.</li> <li>Click Edit and modify the operation rights in the operation set.</li> <li>NOTE         <ul> <li>If the modified operation set is associated with a user, the change takes effect the next time the user logs in.</li> <li>You cannot modify operation rights included in default operation sets or the operation sets to which the role of the current user is bound.</li> </ul> </li> </ol>		

Common Operation	Procedure		
Importing operation	1. Click and choose Import Operation Sets.		
sets	2. On the <b>Import Operation Sets</b> page, click 👨 .		
NOTE	3. In the displayed dialog box, select the .zip file to be imported.		
Only the system administrator user is	4. Click <b>Create</b> .  When the import is complete, perform the following operations to check the import result:		
authorized to perform this operation.	<ul> <li>a. On the displayed page, view the number of successfully imported operation sets and the number of operation sets that fail to be imported.</li> </ul>		
	b. In the <b>Result</b> list, view the imported operation sets and their details.		
	<ul> <li>c. If partial failure occurs, modify the operation set information that failed to be imported based on the details, and import them again.</li> </ul>		
	5. Click <b>OK</b> to close the <b>Import Operation Sets</b> page.		
Exporting all operation sets	Click and choose <b>Export All Operation Sets</b> from the drop-down menu to export all operation sets excluding the full operation sets.		
Only the system administrator user is authorized to perform this operation.	In the exported .zip file, a .csv file contains a maximum of 100 operation sets of the same type. If the number of operation sets exceeds 100, the operation sets are exported to multiple files.		

#### ----End

# 4.2.1.4.4 Viewing Authorization Details

By viewing authorization details, security administrators can quickly learn the users or roles to which permissions are granted so that they can adjust their permissions in a timely manner.

# **Prerequisites**

You have logged in to the NetEco as a security administrator.

## **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Authorization Details**.
- **Step 3** In the **Authorization Objects** area, select authorization objects.

- **Step 4** In the **Operations** area, select the names of the permissions to be viewed.
- **Step 5** In the **Authorized Users and Roles** area, view the users and roles to which the permissions are assigned.

----End

## Follow-up Procedure

If you find that the authorization is improper or illegal, adjust the permissions of the users or roles in time. For details, see **4.2.1.2 Permission Adjustment**.

## 4.2.1.4.5 Modifying User Information in Batches

Security administrators can modify user information (such as **Max. online sessions** and **Login Time Policy**) in batches, improving system security.

## **Prerequisites**

You have logged in to the NetEco as a security administrator.

### Context

- You can use the following methods to modify user information in batches:
  - Using the Batch Modify Users function
     Select the users whose information needs to be modified and click Batch Modify Users.
  - Modifying an exported user information file
     Export user information as a file, edit the file, and then import it to the system.
- The operations in this section involve user permission adjustment, which may force a logout of logged-in users. Therefore, exercise caution when performing this operation.

#### **Procedure**

- Using the **Batch Modify Users** function
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** In the user list, select one or more users, click , and choose **Batch Modify** Users.
- **Step 4** On the **User List** tab page, confirm the users whose information needs to be modified. Then, click **Next**.
- **Step 5** Select the users information to be modified on the **Modification Items** page as required. Click **OK**. On the **Modification Result** page, view the modification results and details.

If the existing time policies do not meet the requirements, click **Create** to create a policy and then click **Refresh**. Then, you can select the new time policy from the time policy list.

#### **◯** NOTE

- You cannot modify the system administrator user and your own information.
- A maximum of 100 users can be modified at a time.
- After the login time policy is modified, the users who do not meet the policy requirements will be forcibly logged out if Log out of sessions that do not comply with client IP address or login time policies is selected in the account policy.

#### Step 6 Click OK.

#### ----End

- Modifying an exported user information file
- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- Step 3 Select the users whose information needs to be exported, click , and choose Export Selected Users or Export All Users.
- **Step 4** In the **Select File Format** dialog box, select a file format and click **OK**.
- **Step 5** Modify the exported user information file.
  - When modifying the user information file, do not change the sequence of the fields in the file.
  - If you change the value of a field to empty or an invalid value, the value of this field will not be changed.
  - The following user information cannot be modified:
    - Type and Region of all users
    - Your own information and information about the system administrator user
    - Password, Login Time Policy, Client IP Address Policy, Personal Client
       IP Address Policy, and Password Validity Period (Days) of remote users
    - Roles, Login Time Policy, and Allowed logins of default users
    - Password and Auto-Logout If No Activity Within of third-party users
- **Step 6** Click and choose **Import Users**.
- **Step 7** In the **Import Users** window, choose **Update Users** to import users.
- **Step 8** Click , select the modified user information file, and click **Modify**.
- **Step 9** After the import is complete:
  - On the displayed page, view the number of successfully modified users and the number of users who fail to be modified.
  - In the **Result** list, view the imported users and their details.

### Step 10 Click OK.

----End

## 4.2.1.4.6 Changing Personal Password

If passwords are disclosed or remain unchanged for a long time, users can change their personal passwords by setting personal information. To improve user security, it is recommended that passwords be changed periodically (for example, every three months).

### **Context**

If you cannot change your password, contact the security administrator.

### **Procedure**

- **Step 1** Choose **System > System Settings > Personal Settings** from the main menu.
- **Step 2** In the navigation pane, choose **Change Password**.
- **Step 3** On the **Change Password** tab page, enter **Old password** and set **New password** and **Confirm password**.
- Step 4 Click Apply.

#### 

User information is more secure if a password is changed more frequently. If a user forgets the password due to frequent password changes, contact security administrators to reset the password.

----End

## 4.2.1.4.7 Modifying Personal Information

When personal information such as mobile numbers and email addresses changes or needs to be supplemented, users can periodically maintain their personal information by setting personal information to ensure its accuracy.

### **Procedure**

**Step 1** Choose **System > System Settings > Personal Settings** from the main menu.

#### **NOTICE**

- When you modify your personal information, such as mobile numbers and email addresses, you are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that your personal data is fully protected.
- To ensure the security of personal information, such as mobile numbers and email addresses, these data is anonymized on the page, and HTTPS encryption transmission channels are used.

- **Step 2** In the navigation pane, choose **Modify Personal Info**.
- **Step 3** On **Modify Personal Info**, modify personal information as required.

If the SMS and email verification codes cannot be obtained, ensure that the remote notification function is configured correctly.

Table 4-6 Parameter description

Parameter	Description	Procedure
Associate	Mobile number associated	Editing the mobile number
Mobile	with a user account.	1. Click <b>Edit</b> .
Number		2. Verify the identity information as prompted and click <b>Next</b> .
		3. Select a country or region code and enter a new mobile number.
		4. Click <b>Send Code</b> and enter the obtained verification code to verify that the mobile number is valid.
		5. Click <b>OK</b> .
		Verifying the mobile number
		1. Click <b>Verify</b> .
		2. Click <b>Send Code</b> and enter the obtained verification code to verify that the mobile number is valid.
		3. Click <b>OK</b> .
Associate	Email address associated	Editing the email address
Email Address	with a user account.	1. Click <b>Edit</b> .
Address		2. Verify the identity information as prompted and click <b>Next</b> .
		3. Enter a new email address.
		4. Click <b>Send Code</b> and enter the obtained verification code to verify that the email address is valid.
		5. Click <b>OK</b> .
		Verifying the email address
		1. Click <b>Verify</b> .
		2. Click <b>Send Code</b> and enter the obtained verification code to verify that the email address is valid.
		3. Click <b>OK</b> .

Parameter	Description	Procedure
Auto- Logout If No Activity Within	If a user does not perform any operation within the period specified by this parameter after login, the user will be logged out. This parameter can be set for local users and remote users. The default value for the third-party user is 30 minutes and cannot be changed.	<ol> <li>Click the drop-down list and select a value for Auto-Logout If No Activity Within.</li> <li>Click Save.</li> </ol>
Max. Online Sessions	You can set the maximum number of online sessions. This parameter is unselected by default, indicating that the maximum number of online sessions of an account is not limited. If this parameter is enabled, the default value is 1, and the value range is from 1 to 500.  If this parameter is set to 1, Login when maximum online sessions already in use can be Not allowed or Log out of the session.  If this parameter is set to a value from 2 to 500, Login when maximum online sessions already in use is set to Not allowed and cannot be changed.	<ol> <li>Select Max. online sessions to enable this function.</li> <li>Set the number of maximum online sessions.</li> <li>Click Save.</li> </ol>
Welcome Message	You can set the information to be displayed upon the next login.	<ol> <li>Click Edit.</li> <li>Enter the information to be displayed upon the next login.</li> <li>Click OK.</li> </ol>

## ----End

# 4.2.1.4.8 Resetting a User Password

If a user forgets the password or cannot change the password, this user needs to contact security administrators to reset the password. If a security administrator

forgets the password, this user needs to contact the system administrator user to reset the password.

### **Prerequisites**

You have logged in to the NetEco as a security administrator or the system administrator.

#### Context

This operation will force a logout of users who have logged in to the management system and selected **Force logout after password change** in the password policy. Therefore, exercise caution when performing this operation.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Users**.
- **Step 3** Click **Reset Password** in the **Operation** column of the row that contains the user and reset the password.

#### NOTICE

- You are not allowed to reset the password for the system administrator user.
  The password for the system administrator user cannot be retrieved. You can
  reset the password for the system administrator user only by reinstalling the
  system. Therefore, remember the password.
- For account security purposes, it is recommended that third-party users contact security administrators to periodically reset their passwords.

----End

### 4.2.1.5 User Monitoring

User sessions can be monitored so that security administrators can know the online users in the system, access addresses of these users, access time, and roles of the users. When detecting an unauthorized user operation, the system sends a message to the user or forcibly log out the user.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

• A user session refers to a connection between a user and the system. A session starts when the user logs in to the system and ends when the user logs out of the system. A user can generate multiple sessions.

- The maximum number of online sessions for a user is specified by the **Max**. **online sessions** parameter.
- Users' personal information is not monitored during session monitoring.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Management** from the main menu.
- **Step 2** In the navigation pane, choose **Online Users**.

The information about all online users is displayed in the list.

#### □ NOTE

- **Client Name** indicates the name of the client where this session is generated.
- Third-party users do not consume resource control items.
- **Step 3** Click **Monitor** in the **Operation** column of the target user to view the status of the user.
  - The User Operations list displays only operations performed after the Online
    Users page is opened. Operations of the monitored users are updated in the
    User Operations list in real time.
  - **Level** indicates the risk level of an operation, including **Risk**, **Minor**, and **Warning**. The value of **Level** is the same as that recorded in operation logs.
- **Step 4** To send a message to a user, click **Send Message** in the **Operation** column of the user. Alternatively, select multiple users and click **Send Message** in the upper right of the user list to send messages to these users.
- **Step 5** When detecting that a user is performing risky operations, click **Log Out** in the **Operation** column of the user to forcibly log out the user. Alternatively, select multiple users and click **Log Out** in the upper right of the user list to force a logout of these users in batches.

#### **NOTICE**

This operation involves user login status and may force a logout of logged-in users. Therefore, exercise caution when performing this operation.

----End

# 4.2.2 Personal Settings

This feature enables users to customize personal settings.

### 4.2.2.1 Changing Personal Password

If passwords are disclosed or remain unchanged for a long time, users can change their personal passwords by setting personal information. To improve user security, it is recommended that passwords be changed periodically (for example, every three months).

#### Context

If you cannot change your password, contact the security administrator.

#### **Procedure**

- **Step 1** Choose **System > System Management > Personal Settings**.
- **Step 2** In the navigation pane, choose **Change Password**.
- **Step 3** On the **Change Password** tab page, enter **Old password** and set **New password** and **Confirm password**.
- Step 4 Click Apply.

User information is more secure if a password is changed more frequently. If a user forgets the password due to frequent password changes, contact security administrators to reset the password.

----End

### 4.2.2.2 Modifying Personal Information

When personal information such as mobile numbers and email addresses changes or needs to be supplemented, users can periodically maintain their personal information by setting personal information to ensure its accuracy.

#### **Procedure**

**Step 1** Choose **System > System Management > Personal Settings**.

#### **NOTICE**

- When you modify your personal information, such as mobile numbers and email addresses, you are obligated to take considerable measures, in compliance with the laws of the countries concerned and the user privacy policies of your company, to ensure that your personal data is fully protected.
- To ensure the security of personal information, such as mobile numbers and email addresses, these data is anonymized on the page, and HTTPS encryption transmission channels are used.
- **Step 2** In the navigation pane, choose **Modify Personal Info**.
- **Step 3** On **Modify Personal Info**, modify personal information as required.

□ NOTE

If the SMS and email verification codes cannot be obtained, ensure that the remote notification function is configured correctly.

Table 4-7 Parameter description

Parameter	Description	Procedure
Associate Mobile Number	Mobile number associated with a user account.	<ul> <li>Editing the mobile number</li> <li>Click Edit.</li> <li>Verify the identity information as prompted and click Next.</li> <li>Select a country or region code and enter a new mobile number.</li> <li>Click Send Code and enter the obtained verification code to verify that the mobile number is valid.</li> <li>Click OK.</li> <li>Verifying the mobile number</li> <li>Click Verify.</li> <li>Click Send Code and enter the obtained verification code to verify that the mobile number is valid.</li> <li>Click Send Code and enter the obtained verification code to verify that the mobile number is valid.</li> <li>Click OK.</li> </ul>
Associate Email Address	Email address associated with a user account.	<ul> <li>Editing the email address</li> <li>Click Edit.</li> <li>Verify the identity information as prompted and click Next.</li> <li>Enter a new email address.</li> <li>Click Send Code and enter the obtained verification code to verify that the email address is valid.</li> <li>Click OK.</li> <li>Verifying the email address</li> <li>Click Verify.</li> <li>Click Send Code and enter the obtained verification code to verify that the email address is valid.</li> <li>Click OK.</li> </ul>

Parameter	Description	Procedure
Auto- Logout If No Activity Within	If a user does not perform any operation within the period specified by this parameter after login, the user will be logged out. This parameter can be set for local users and remote users. The default value for the third-party user is 30 minutes and cannot be changed.	<ol> <li>Click the drop-down list and select a value for Auto-Logout If No Activity Within.</li> <li>Click Save.</li> </ol>
Max. Online Sessions	You can set the maximum number of online sessions. This parameter is unselected by default, indicating that the maximum number of online sessions of an account is not limited. If this parameter is enabled, the default value is 1, and the value range is from 1 to 500.  If this parameter is set to 1, Login when maximum online sessions already in use can be Not allowed or Log out of the session.  If this parameter is set to a value from 2 to 500, Login when maximum online sessions already in use is set to Not allowed and cannot be changed.	<ol> <li>Select Max. online sessions to enable this function.</li> <li>Set the number of maximum online sessions.</li> <li>Click Save.</li> </ol>
Welcome Message	You can set the information to be displayed upon the next login.	<ol> <li>Click <b>Edit</b>.</li> <li>Enter the information to be displayed upon the next login.</li> <li>Click <b>OK</b>.</li> </ol>

Parameter	Description	Procedure
Display Associate Contact Information Page	This parameter specifies whether the Associate Contact Information page is displayed when the user logs in next time.  If this parameter is enabled, the Associate Contact Information page is displayed.	<ul> <li>Click Enable.</li> <li>Click Disable.</li> <li>NOTE         <ul> <li>In SSO mode, contact information can be associated only on the Associate Contact Information page. Exercise caution when setting this parameter.</li> </ul> </li> </ul>
	<ul> <li>If this parameter is disabled, the Associate Contact Information page is not displayed.</li> </ul>	

----End

### 4.2.2.3 Modifying Personal Client IP Address Control Policies

With the **Update ACL Policy** permission, you can configure your personal client IP address control policies. ACL is short for access control list.

#### **Procedure**

- **Step 1** Choose **System > System Management > Personal Settings**.
- Step 2 In the navigation pane, choose Personal Client IP Address Policies.
- **Step 3** On the **Personal Client IP Address Policies** page, view or modify your IP address control policies.

----End

### 4.2.2.4 Home Settings

After the home page information is configured, the page set by the user is displayed by default upon the next login, which helps users quickly view the menus that they want to follow.

#### **Procedure**

- **Step 1** Choose **System > System Management > Personal Settings**.
- **Step 2** In the navigation pane on the left, choose **Home Settings**.
- **Step 3** Paste the copied page URL to the URL bar on the home page and click **Apply**.

----End

# 4.2.3 Log Management

By managing fault logs of devices, users can learn the running status of devices.

### 4.2.3.1 Querying Logs

A log records the operations and major events of the management system. By querying logs, you can learn about the running status and operation details of the management system.

### **Prerequisites**

You have the operation rights for Log Management.

#### Context

Management system logs are classified into security logs, system logs, and operation logs.

- Security logs record security operations that are performed on the management system, such as logging in to the server, changing passwords, creating users, and logging out of the server.
- System logs record the events occurred on the management system, such as abnormal running, network failures, and attacks to the management system. These logs help you analyze the NMS status and rectify faults.
- Operation logs record the user operations that are performed on the management system.

#### **Procedure**

- Step 1 Choose System > System Management > Log Management.
- **Step 2** In the navigation tree in the left pane, choose **Security Logs**, **System Logs** or **Operation Logs**.
- **Step 3** On the page, view the log information, or set search criteria to view specified log information.

After clicking the value in the **Details** column of the target log, you can view logs details.

#### □ NOTE

A maximum of 1000 characters can be displayed in **Details**. The excess characters are displayed in the **A-B** form.

The management system server time is used for the filter criteria **Time period**. The value is 24 hours before the current time. For example, if the current time is 11:00:00, November 12, 2020, the default value of time period is from 11:00:00, November 11, 2020 to 11:00:00, November 12, 2020.

----End

### Follow-up Procedure

You can export the logs and back them up for future analysis.

#### **NOTICE**

Switching between pages will cause log exporting to be interrupted.

If	Then
Export all logs	1. Click <b>Export All</b> to export all logs.
	2. In the <b>File Download</b> dialog box, click <b>Save</b> .
	3. Select a save path and click <b>Save</b> .
	NOTE  Log files must be saved in .csv format.
Export the selected logs	In the log list, select the check box before     Event Name of the required log.
	2. Click <b>Export Selected</b> to export the selected logs.
	3. In the <b>File Download</b> dialog box, click <b>Save</b> .
	4. Select a save path and click <b>Save</b> .
	NOTE  Log files must be saved in .csv format.

# 4.2.4 User Policy Management

User policies allow you to set access control rules for users. This function improves O&M efficiency and prevents unauthorized users from accessing the system to ensure system security.

# 4.2.4.1 Setting the Account Policy

Security administrators set login or lockout policies for user accounts as needed to improve system access security. The account policy takes effect for all users.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Policies** from the main menu.
- **Step 2** In the navigation pane, choose **Account Policy**.
- **Step 3** On the **Account Policy** page, set the account policy.

#### □ NOTE

- If **Enable the user policy if no login within a period** is selected, the system will automatically delete the users who meet the policy. Perform this operation with caution.
- Auto-logout if no activity within: If a user does not perform any operation within the
  period specified by this parameter, the user will be logged out. The setting takes effect
  only for local and remote users and does not take effect for third-party users. If this
  parameter is set to Unlimited, user sessions will not be automatically logged out.
- If **Show warning upon successful login** is selected, a login warning message is displayed to notify users of rules that should be obeyed after users log in to the system. The warning message provides legal declaration. Security administrators can customize this warning message based on user management regulation.
- To improve account security, you are advised to enable all the items in the account policy.

#### Step 4 Click Apply.

----End

### 4.2.4.2 Setting the Password Policy

Security administrators set password complexity, change interval, and character limitation as needed to prevent users from setting weak passwords or using a password for a long period of time, improving system access security. The password policy takes effect for all users.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### Context

- If you disable the password complexity policy items and the item of forcibly changing passwords after they expire, user security reduces. You are advised to enable all password policies provided by the system.
- If the settings of the same policies in the personal policy of a user and the password policy are different, the settings in the personal policy take effect for the user.
- Periodically changing passwords can improve user information security and prevent accounts from being stolen. Exercise caution when disabling the function of periodically changing passwords and modifying a password change period.
- A new password policy does not affect the existing passwords.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Policies** from the main menu.
- **Step 2** In the navigation pane, choose **Password Policy**.
- **Step 3** On the **Password Policy** page, set the password policy. Some of the policy parameters are described in **Table 4-8**.

Table 4-8 Parameter description

Parameter	Description	
Force logout upon password reset	When a user password is reset, all online sessions generated by the user will be logged out.	
Password cannot be an increasing,	When setting a user password, the password must meet the following requirements:	
decreasing, or interval sequence of digits or letters	<ul> <li>The password cannot be digits or letters in ascending or descending sequence.</li> <li>For example, the password cannot be abcdef, fedcba, 123456, or 654321.</li> </ul>	
	<ul> <li>The password cannot contain an ascending or descending arithmetic sequence in consecutive odd digits or even digits.</li> <li>For example, the password cannot be 1a2a3a, 5a3a1a, a2b2c2, or 2e2c2a.</li> </ul>	
Password cannot contain words in password dictionary	When you create a user and set the password, the password cannot contain words in the password dictionary.	
	<ul> <li>No default password dictionary is provided. You can customize a password dictionary. For example, abcd1234 is a weak password and if it is added to the password dictionary, abcd1234 cannot be used as a user password.</li> </ul>	
	<ul> <li>In a password dictionary file, passwords are separated by line feeds. In the dictionary, a password that contains more than 128 characters is invalid.</li> </ul>	
	<b>NOTE</b> To update the password dictionary, perform the following steps:	
	Click <b>Download Password Dictionary</b> to download the existing password dictionary and modify it as required.	
	2. Click and select the modified password dictionary.	
	3. Click <b>Upload</b> to update the password dictionary.	

Parameter	Description
Convert strings in password based on conversion rules (refer to help	If a password contains a character string defined in the string conversion rules, the character string is converted into other characters based on certain rules. The converted password must meet complexity requirements.
documentation to configure the rules)	The string conversion rules define the rules for converting a character or string into an uppercase or
NOTE This parameter is displayed only when Password cannot contain words in password dictionary	lowercase letter. For example, if a rule for converting the string  - 1234 a into x exists in the string conversion rules, and xbcd!123 is contained in the password dictionary, and when the policy is enabled,  - 1234 abcd! 123 cannot be used as a user password.
is selected.	NOTE
	<ul> <li>For details about how to configure the string conversion rules, see "Configuring the String Conversion Rules of User Management".</li> </ul>
	<ul> <li>Strings refer to strings consisting of dangerous characters, invisible characters, and characters incurring SQL injection.</li> </ul>

Step 4 Click Apply.

----End

### 4.2.4.3 Setting a Client IP Address Policy

A client IP address policy provides a control mechanism for checking the accessibility of the IP address used by an external access request. Security administrators can set client IP address policies as required and bind the policies to specified users. The policies take effect only for the bound users. In this way, users can log in to the management system only from specified IP address segments, which improves system security.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Policies** from the main menu.
- **Step 2** In the navigation pane, choose **Client IP Address Policies**.
- **Step 3** On the **Client IP Address Policies** page, click **Create**.
- **Step 4** Set a client IP address policy and click **OK**.

#### **NOTICE**

Exercise caution when you set the client IP address policies for the system administrator user. If the client IP address of the system administrator user is not within the bound IP address range, the user cannot log in again after logout.

----End

### 4.2.4.4 Setting a Login Time Policy

A login time policy provides a control mechanism for checking the validity time of an external access request during system operation. Security administrators can set login time policies as required and bind the policies to specified users. The policies take effect only for the bound users. In this way, users can log in to the management system only within the specified time segments, which improves system security.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > System Management > User Policies** from the main menu.
- **Step 2** In the navigation pane, choose **Login Time Policies**.
- **Step 3** On the **Login Time Policies** page, click **Create**.
- **Step 4** Set the parameters of the login time policy and click **OK**.

#### □ NOTE

- The system administrator user is not restricted by the login time policy.
- If the start time is later than the end time for **Effective hours**, the system will automatically set the end time to the next day. For example, if **Effective hours** is set to 16:00–15:00, login is allowed within 16:00–24:00 today and 0:00–15:00 the next day.

----End

# 4.2.5 Security Configuration

The security configuration function provides the system security baselines (such as protocols, algorithms, and keys), and checks for risks of protocols, keys, and algorithms used by services and service configuration items based on the security baselines. Based on the check results, it provides risk warnings and rectification suggestions. This allows the security capabilities of different services to be monitored in a unified manner and ensures system security.

# 4.2.5.1 Overview of Security Configuration

This section describes basic information about the security configuration function, including its definition, benefits, scenarios, functions, and principles.

#### 4.2.5.1.1 **Definition**

The security configuration function monitors service configuration items in a unified manner, checks security configurations, and manages security baselines.

Security baselines consist of a series of security requirements and specifications, including protocols, algorithms, and keys. The security configuration function checks for risks of service configuration items based on security baselines.

#### 4.2.5.1.2 Benefits

The security configuration function allows you to monitor protocols, keys, and algorithms used by services and service configuration items, improving management efficiency. Security administrators can rectify security risks based on the check results to ensure service security.

#### 4.2.5.1.3 Scenarios

During routine maintenance, security administrators can use the security configuration function to check whether the protocols, keys, algorithms, and service configurations used by services meet the security baselines, ensuring service security.

#### 4.2.5.1.4 Functions

The security configuration function allows you to check service configurations and view security baselines.

- Checking service configurations

  Checks whether service configuration items have risks based on security baselines, and provides risk warnings and rectification suggestions.
- Viewing security baselines
   Displays security protocols and algorithms used by services.

#### **4.2.5.1.5 Principles**

The security configuration function checks for risks of service configuration items based on security baselines, and provides risk warnings and rectification suggestions. This helps security administrators detect and handle security risks of services in a timely manner.

**Figure 4-4** shows the principles of the security configuration function.

Manual 4 System




Figure 4-4 Principles of the security configuration function

### 4.2.5.2 Viewing Security Baselines

A security baseline provides secure protocols and algorithms for services. The system checks whether protocols and algorithms used by services are secure based on the security baseline.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > Security Configuration** from the main menu.
- **Step 2** In the navigation pane, choose **Security Baseline**.
- **Step 3** On the **Security Baseline** page, click the card of required baseline.
- **Step 4** View the configured security baseline.

The security configuration function will check for risks of protocols, keys, and algorithms used by services based on the security baseline, and provide risk warnings and rectification suggestions.

----End

### 4.2.5.3 Checking Security Configurations

Security administrators can configure check policies based on service security requirements to periodically check whether protocols, keys, and algorithms used by services meet the security baselines, and rectify the risks based on the check results. To meet special requirements such as compatibility requirements, you can configure insecure protocols, keys, and algorithms on the panel for risk details. Exercise caution when performing this operation. For service function security, you are advised to use secure protocols, keys, and algorithms.

### **Prerequisites**

You have logged in to the NetEco as a security administrator.

#### **Procedure**

- **Step 1** Choose **System > Security Configuration** from the main menu.
- **Step 2** On the **Configuration Check** page, check a single item or check items in batches as required.
  - Checking a single item
     Click Check in the Operation column of the row that contains the required
  - Checking items in batches

Click Check Now to check all items.

**Ⅲ** NOTE

Click **Set Check Time** and set the daily check time. The security configuration function automatically checks service configuration items every day based on the set time.

**Step 3** View the check results.

- After the check is complete, view the results in the **Check Result** column.
- In the upper part of the **Configuration Check** page, view the result distribution charts of all check items so that you can learn about the overall risk information.
- **Step 4** Click the name of a desired configuration item. On the panel that is displayed, view the details about the risk. You can rectify the risk based on the suggestions.
- **Step 5 Optional:** If **Configuration Item** can be set on the panel of risk details, set **Configuration Item** based on site requirements and click **Save**.

□ NOTE

If the modified value contains insecure protocols, keys, or algorithms, security risks may occur. Exercise caution when performing this operation. For service function security, you are advised to use secure protocols, keys, and algorithms.

----End

#### **Related Tasks**

- Adding an item to the whitelist: If a service configuration item does not have security risks or is not used, click Add to Whitelist in the Operation column of the row that contains the item to add it to the whitelist. The security configuration function will exclude items in the whitelist when performing the security check to improve the check efficiency.
- Removing an item from the whitelist: If the security check needs to include a
  whitelist item, click Remove from Whitelist in the Operation column of the
  row that contains the item.

# 4.3 About

# 4.3.1 Certificate Management

Certificate Management involves service certificate management, CA interconnection configuration, and certificate application. Service certificates can

be managed (including preconfiguration, import, deletion, and periodic validity check) in a centralized manner, and you can quickly apply for and use the certificates.

### 4.3.1.1 Managing Service Certificates

This section describes how to import certificates, including identity certificates, trust certificates, and certificate revocation lists (CRLs).

### **Prerequisites**

- The service that requires certificate management has been deployed.
- You have the following permissions: Query Certificate, Import Certificate, and Delete Certificate.
- You have obtained the certificate to be imported or updated and its information, including passwords, certificate type, public key, private key, private key password, and certificate chain of the identity certificate.

#### Context

If the page for configuring certificates of a service does not contain the **Identity Certificate**, **Trust Certificate**, or **Certificate Revocation List** tab page, the service does not have the corresponding type of certificate and the corresponding tab page does not need to be displayed.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, select **Service Certificate Management**.
- **Step 3** On the **Services** page, click the service with certificate to be imported.
- **Step 4** Configure the certificate information based on the certificate type. The identity certificate is used as an example.
  - 1. Click the **Identity Certificate** tab.

#### ∩ NOTE

- If the certificate type is trust certificate, click the **Trust Certificate** tab.
- If the certificate type is certificate revocation list, click the Certificate Revocation List tab.
- 2. Click Import.
- 3. Configure the certificate information.

#### Step 5 Click Submit.

----End

#### **Related Tasks**

Delete certificates

#### ☐ NOTE

Deleting certificates may cause the services that use the certificates to become interrupted. Exercise caution when deleting certificates.

Click in the Operation column of the row that contains the desired certificate to delete the certificate.

• View the certificate update status.

For an imported certificate, view the certificate update status in **Certificate Update Status**.

□ NOTE

If the **Certificate Update Status** tab page is not displayed for a service, the service does not need to use this function, which is normal.

### Follow-up Procedure

Restart the corresponding service for the imported certificate to take effect. For details, see "Uploading and Updating Certificates Using Certificate Management" in *Administrator Guide*.

### 4.3.1.2 Restoring Historical Certificates

If an identity certificate in use is overwritten by another identity certificate or is deleted by mistake, you can use the historical certificate function to restore the certificate to ensure that services are running properly.

### **Prerequisites**

You have the **Query Certificate** and **Import Certificate** permissions.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, select **Service Certificate Management**.
- **Step 3** On the **Services** page, click the service with certificates to be imported.
- Step 4 Click the Identity Certificate tab.
- **Step 5** Click **Historical Certificates**.
- **Step 6** On the **Historical Certificates** page, click on the **Operation** column of the row that contains the desired certificate.
- **Step 7** In the **High Risk** dialog box, read the information carefully and confirm whether to restore the certificate.
  - If yes, select I understand the risk and want to continue, click OK, and go to Step 8.
  - If no, click **Cancel** to end the operation.
- **Step 8** In the **Information** dialog box, read information carefully and click **OK**.

----End

#### **Related Tasks**

View certificate information.

In the historical certificate list, click in the row that contains the desired certificate to view the certificate details.

### 4.3.1.3 Importing Global Shared Certificates

This section describes how to import a certificate revocation list (CRL) to global shared certificates. Services can call interfaces to obtain the CRLs in the global shared certificate list and verify the validity of their certificates based on the obtained CRLs.

### **Prerequisites**

- You have the Query Global Shared Certificate, Import Global Shared Certificate, and Delete Global Shared Certificate permissions.
- You have obtained the CRL to be imported.

#### Context

The following certificates are displayed in the list of global shared certificates:

- CRLs imported by users
- CRLs obtained from the CRL server interconnected with HiSecCAProxy

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- Step 2 In the navigation pane, choose Global Shared Certificates.
- **Step 3** On the **Certificate Revocation List** tab page, click **Import**.
- **Step 4** Configure the certificate information as required.

	$\overline{}$		 
1 1	1	- NI	тс
		- 13	 

The certificate alias must be the same as the IP address of the MAE NMS to distinguish different NMSs.

----End

### **Related Tasks**

• View certificate information.

In the global shared certificate list, click in the row that contains the desired certificate to view the certificate details.

• Delete certificates.

□ NOTE

After a CRL file is deleted, the certificate revoked by this CRL will become valid again. Exercise caution when performing this operation.

To delete an existing global shared certificate, perform either of the following operations:

Method 1: Click in the **Operation** column of the row that contains the desired certificate to delete the certificate.

Method 2: Select the desired certificates, and click **Delete** in the upper right corner of the **Global Shared Certificates** page to delete the certificates.

### 4.3.1.4 Configuring CA Interconnection Parameters

This section describes how to configure parameters for interconnecting NetEco with the CA so that you can apply for certificates online using certificate management.

### **Prerequisites**

- You have the following permissions: Query CA Configuration, Manage CA Configuration, and Delete CA Configuration.
- You have obtained the information about the CA server, including the IP address, port number, and the address information.
- You have obtained the certificate information from the CA and have configured on the local system, including the public key, public key certificate chain, private key, private key password, certificate chain of the trusted CA, and CA certificate chain.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, choose **Online Certificate Update** > **CA Interconnection**.
- Step 3 Click Create.
- **Step 4** Configure the parameters for interconnecting with the CA as required.
- Step 5 Click OK.

----End

#### Related Tasks

• Check and view the connectivity of the CA.

Click in the **Operation** column of the row that contains the configured CA to check the connectivity of the CA, and view the result in the **Connection Status** column.

Modify the CA information.

□ NOTE

Modifying a configured CA may interrupt services between NetEco and the CA and cause a failure to apply for certificates. Therefore, exercise caution when performing this operation.

Click in the **Operation** column of the row that contains the configured CA to modify its information.

Delete the CA.

Deleting a configured CA will interrupt services between NetEco and the CA and cause a failure to apply for certificates. Therefore, exercise caution when performing this operation.

Click in the **Operation** column of the row that contains the configured CA to delete the CA

### 4.3.1.5 Configuring CRL Server Parameters

This section describes how to interconnect NetEco with a CRL server. After NetEco is interconnected with a CRL server, you can obtain certificate revocation lists (CRLs) from the server.

### **Prerequisites**

- You have the Query CRL Server Interconnection, Manage CRL Server Interconnection, and Delete CRL Server Interconnection permissions.
- You have obtained the following information about the CRL server to be interconnected:
  - IP address
  - Port number
  - Username
  - Password for the user
  - Trust certificates used to verify the CRL server

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, choose **Online Certificate Update** > **CRL Server Interconnection**.
- Step 3 Click Create.
- **Step 4** Configure the interconnection parameters as prompted.
- Step 5 Click OK.

----End

#### **Related Tasks**

Check and view the connectivity of the CRL server.

Click In the **Operation** column of the row that contains the configured CRL server to check the connectivity of the CRL server, and view the result in the **Connection Status** column.

• Modify the CRL server information.

#### 

Modifying a configured CRL server may interrupt services between NetEco and the CRL server and cause a failure to apply for certificates. Therefore, exercise caution when performing this operation.

Click in the **Operation** column of the row that contains the configured CRL server to modify the CRL server information.

• Delete the CRL server.

#### 

Deleting a configured CRL server will interrupt services between NetEco and the CRL server and cause a failure to apply for certificates. Therefore, exercise caution when performing this operation.

Click in the **Operation** column of the row that contains the configured CRL server to delete the CRL server.

### Follow-up Procedure

After NetEco is interconnected with the CRL server and the connectivity is verified normal, check whether the CRL on the server is displayed in the global shared certificate list.

- If yes, the CRL is obtained successfully from the server.
- If no, contact technical support.

### 4.3.1.6 Creating Certificate Application Templates

This section describes how to create a template for applying for certificates based on the information about the required certificate. By using a template, the repeated configurations of certificate update tasks are reduced, so that you can quickly apply for new certificates.

### **Prerequisites**

- You have the following permissions: Query Certificate Application Template,
   Manage Certificate Application Template, and Delete Certificate
   Application Template.
- You have obtained the certificate format, validity period, key algorithm, key length, certificate type, key usage, and extended key usage from the interconnected CA, ensuring that the planned certificate information is correct.
- You have planned the information about the certificate, such as the certificate format, common name (CN), country or region (C), province or state (ST), city (L), organization (O), department (OU), validity period, key algorithm, and key length, subject alternative name, certificate type, key usage, and extended key usage.

#### Context

• The validity period of a certificate applied from the CA is jointly determined by the customized validity period, validity period of the CA root certificate,

maximum validity period supported by the CA, and validity period of the application template supported by the CA. Generally, the validity period does not exceed the maximum validity period supported by the CA and the validity period of the application template supported by the CA. The actual validity period depends on the interconnected CA.

 Table 4-9 describes the certificate formats, key algorithms, key lengths, certificate types, key usages, and extended key usages supported by certificate management.

Table 4-9 Certificate information

Parameter	Description
Certificate Format	Format of the certificate.  • PEM • PKCS12
Key algorithm	<ul> <li>Key algorithm of the certificate.</li> <li>RSA</li> <li>ECDSA</li> <li>NOTE      RSA whose length is 2047 bits or shorter is insecure. You are advised to use the certificate encrypted by RSA whose length is 3072 bits or longer.</li> </ul>
Key length	<ul> <li>Length of the RSA certificate key: <ul> <li>2048</li> <li>3072</li> <li>4096</li> <li>6144</li> <li>8192</li> </ul> </li> <li>Length of the ECDSA certificate key: <ul> <li>256</li> <li>384</li> <li>521</li> </ul> </li> </ul>
Certificate type	<ul> <li>Type of the certificate.</li> <li>End Entity: Select this type if you do not need to use the key corresponding to the certificate to issue the certificate.</li> <li>CA: Select this type when you need to use the corresponding key to issue a certificate.</li> </ul>

Parameter	Description
Key usage	Usage of the certificate key.
	• Digital signature: Select this usage if the certificate requires identity authentication and data integrity authentication.
	• Non-repudiation: Select this usage if the certificate requires authentication on the digital signature of the public key to prevent the signing entity from denying its requests.
	Key encipherment: Select this usage if the certificate requires an encryption protocol.
	Data encipherment: Select this usage if the certificate encrypts its application data.
	Key agreement: Select this usage if the public key is used by the sender and receiver to encrypt data during communication through plaintext agreement.
	Certificate signing: Select this usage if the public key authenticates the certificate signature. It can only be used as a proxy certificate.
	CRL signing: Select this usage if the public key of the certificate is used to verify the signature on the revocation information.
	Encipher only: Select this usage if <b>Key agreement</b> is selected. The public key is used only for encrypting data during the agreement.
	Decipher only: Select this usage if <b>Key agreement</b> is selected. The public key is used only deciphering data during the key agreement.
Extended	Extended usage of the certificate key.
key usage	<ul> <li>Server authentication: TLS WWW server authentication.</li> <li>Select this usage when Digital signature, Key encipherment, or Key agreement in Key usage is selected.</li> </ul>
	<ul> <li>Client authentication: TLS WWW client authentication.</li> <li>Select this usage when <b>Digital signature</b> or <b>Key</b></li> <li>agreement in <b>Key usage</b> is selected.</li> </ul>
	<ul> <li>Email protection: Email protection. Select this usage when the Digital signature, Non-repudiation, Key encipherment, or Key agreement in Key usage is selected.</li> </ul>

### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, choose **Online Certificate Update > Certificate Application Templates**.

- Step 3 Click Create.
- **Step 4** Configure the template parameters as required.
- Step 5 Click OK.

----End

#### **Related Tasks**

- Modify the certificate template.
  - Click in the **Operation** column of the row that contains the desired certificate template to modify the template information.
- Delete the certificate template.
  - Click in the **Operation** column of the row that contains the desired certificate template to delete the template.

### 4.3.1.7 Certificate Update Tasks

This section describes how to apply for certificates by using an existing certificate template or manually configuring certificate information, and how to apply certificates to services. To prevent security issues caused by private key leakage, you need to periodically update the certificates to improve system security. If a certificate is about to expire or the private key of a certificate is leaked, update the certificate immediately.

### **Prerequisites**

- The parameters for interconnecting with the CA have been configured. For details, see 4.3.1.4 Configuring CA Interconnection Parameters.
- You have the following permissions: Query Certificate Application Task and Manage Certificate Application Task.
- You have obtained the certificate format, validity period, key algorithm, key length, certificate type, key usage, and extended key usage from the interconnected CA, ensuring that the planned certificate information is correct.
- You have obtained the information about the certificate, such as the
  certificate format, common name (CN), country or region (C), province or
  state (ST), city (L), organization (O), department (OU), validity period, key
  algorithm, and key length, subject alternative name, certificate type, key
  usage, and extended key usage.

#### Context

- The time difference between NetEco and the CA must be less than 5 minutes. Otherwise, the certificate application fails.
- For security purposes, the password must meet the following complexity requirements:
  - Contain 8 to 64 characters.

- Contain at least three of the following: lowercase letters, uppercase letters, digits, and special characters. Only the following special characters are allowed: ~@#^\*-\_+[{}]:./?
- The validity period of a certificate applied from the CA is jointly determined by the customized validity period, validity period of the CA root certificate, maximum validity period supported by the CA, and validity period of the application template supported by the CA. Generally, the validity period does not exceed the maximum validity period supported by the CA and the validity period of the application template supported by the CA. The actual validity period depends on the interconnected CA.
- Table 4-10 describes the certificate formats, key algorithms, key lengths, certificate types, key usages, and extended key usages supported by certificate management.

Table 4-10 Certificate information

Parameter	Description
Certificate format	Format of the certificate.  • PEM • PKCS12
Key algorithm	<ul> <li>Key algorithm of the certificate.</li> <li>RSA</li> <li>ECDSA</li> <li>NOTE  RSA whose length is 2047 bits or shorter is insecure. You are advised to use the certificate encrypted by RSA whose length is 3072 bits or longer.</li> </ul>
Key length	<ul> <li>Length of the RSA certificate key: <ul> <li>2048</li> <li>3072</li> <li>4096</li> <li>6144</li> <li>8192</li> </ul> </li> <li>Length of the ECDSA certificate key: <ul> <li>256</li> <li>384</li> <li>521</li> </ul> </li> </ul>
Certificate type	<ul> <li>Type of the certificate.</li> <li>End Entity: Select this type if you do not need to use the key corresponding to the certificate to issue the certificate.</li> <li>CA: Select this type when you need to use the corresponding key to issue a certificate.</li> </ul>

Parameter	Description
Key usage	Usage of the certificate key.
	• Digital signature: Select this usage if the certificate requires identity authentication and data integrity authentication.
	• Non-repudiation: Select this usage if the certificate requires authentication on the digital signature of the public key to prevent the signing entity from denying its requests.
	Key encipherment: Select this usage if the certificate requires an encryption protocol.
	Data encipherment: Select this usage if the certificate encrypts its application data.
	Key agreement: Select this usage if the public key is used by the sender and receiver to encrypt data during communication through plaintext agreement.
	Certificate signing: Select this usage if the public key authenticates the certificate signature. It can only be used as a proxy certificate.
	CRL signing: Select this usage if the public key of the certificate is used to verify the signature on the revocation information.
	Encipher only: Select this usage if <b>Key agreement</b> is selected. The public key is used only for encrypting data during the agreement.
	Decipher only: Select this usage if <b>Key agreement</b> is also selected. The public key is used only deciphering data during the key agreement.
Extended	Extended usage of the certificate key.
key usage	<ul> <li>Server authentication: TLS WWW server authentication.</li> <li>Select this usage when Digital signature, Key encipherment, or Key agreement in Key usage is selected.</li> </ul>
	<ul> <li>Client authentication: TLS WWW client authentication.</li> <li>Select this usage when Digital signature or Key agreement in Key usage is selected.</li> </ul>
	Email protection: Email protection. Select this usage when the Digital signature, Non-repudiation, Key encipherment, or Key agreement in Key usage is selected.

### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, choose **Online Certificate Update** > **Certificate Update** Tasks.

#### Step 3 Click Create.

- **Step 4** Select the update mode as required.
  - Updating using an existing template
    - a. (Optional) Create a certificate application template. For details, see
       4.3.1.6 Creating Certificate Application Templates.
    - b. Select a template from the **Template** drop-down list.
    - c. Configure the parameters as required.

#### □ NOTE

After a certificate application template is selected, you can change the values of some parameters as required. For example, the validity period set in the certificate application template is five years, but the required validity period of the new certificate is 10 years, you can set the validity period to 10 years when creating a certificate update task.

Updating without a template
 Configure the parameters as required.

#### Step 5 Click OK.

**Step 6** In the list of certificate update tasks, check **Task Status** of the created task.

- Pending: The certificate update task is applying for a new certificate. Refresh the page to view the latest task status.
- Success: The certificate update task is created successfully.
- Failed: The certificate update task fails to be created. Rectify the fault based on the failure causes. In the Operation column of the row, click Query Failure Causes. In the dialog box that is displayed, click Details and rectify the fault based on the details. If the problem persists, contact technical support.
- **Step 7** (Optional) To apply the obtained certificate to services, perform **Step 7.1** to **Step 7.3**.
  - 1. Click in the Operation column of the row that contains the certificate.
  - 2. Select the services to which you want to apply the certificates.
  - 3. Click OK.
  - 4. In the **High Risk** dialog box, read the information carefully and confirm whether to apply certificate to services.
    - If yes, select I understand the risk and want to continue, click OK, and go to Step 7.5.
    - If no, click Cancel.
  - 5. Check whether the certificate is successfully applied to the corresponding service.

If the message **Certificates applied to services successfully.** is displayed, the certificate is successfully applied to the service. Click **OK**. Otherwise, handle the problem according to the information in the dialog box.

#### 

The certificate of APIMLBService takes effect only after the service is restarted.

#### ----End

### 4.3.1.8 General Settings of Certificate Management

This section describes general settings of certificate management, including certificate alarm configurations and CRL check.

### **Prerequisites**

You have the **Query Certificate Settings** and **Manage Certificate Settings** permissions.

#### **Context**

- Certificate alarm configurations: If the remaining validity period of a certificate reaches the alarm generation threshold, certificate management reports an alarm. If the time unit is day, certificate management checks certificate validity every day, and the default alarm generation threshold is 90 days. If the time unit is hour, certificate management checks certificate validity every 24 hours, and the default alarm generation threshold is 2160 hours. You can change the certificate check interval and the alarm generation threshold as required to prevent frequent alarm reporting. To prevent services from becoming unavailable due to certificate expiration, you need to update the certificate periodically (for example, every three months).
- CRL check: The CRL check function specifies whether to enable the CRL check mechanism. After this function is enabled, the system checks whether any CRL is empty. It is recommended that this function be enabled to ensure security.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Management** from the main menu.
- **Step 2** In the navigation pane, choose **Settings** > **General Settings**.
- **Step 3** On the **General Settings** page, configure the function information based on site requirements.

Functio n	Troubleshooting Procedure
Certificat e alarm configur ations	<ol> <li>Click Modify.</li> <li>Select Time unit, and set Check interval and In advance alarm before certificate expires as required.</li> <li>Click Save.</li> </ol>
CRL check	Enable or disable the CRL check function as required.

----End

# 4.3.2 Certificate Authority Service

This chapter provides basic information about Certificate Authority Service and its usage scenarios.

### 4.3.2.1 Certificate Authority Service Overview

This section provides an overview of the Certificate Authority Service, including its definition, functions, and application scenarios.

#### 4.3.2.1.1 **Definition**

The Certificate Authority Service is used to issue and manage certificates, helping users quickly obtain and use certificates.

### **Concepts**

- Certificate Authority (CA): An authoritative and impartial third-party organization responsible for issuing, authenticating, and managing certificates. A CA is a tree structure consisting of a root CA and multiple subordinate CAs.
- Certificate Revocation List (CRL): A list of certificates that have been revoked by the issuing CA before their scheduled expiration date. It is a kind of certificate blacklist.
- Root CA: The top-level CA in the CA hierarchy. It is the start point of the entire CA chain of trust. The corresponding CA certificate is self-signed and does not need to be verified by other CAs.
- Subordinate CA: A certificate authority signed by the root CA or other subordinate CAs.
- Certificate chain: An ordered list of certificates from multiple levels of CAs. A
  certificate chain verifies the certificates issued by the lowest-level CA in the
  certificate chain.
- End-entity certificate: A certificate that does not use its key to issue other certificates
- One-way TLS: A secure communication protocol that uses digital certificates to encrypt communication packets. The client uses a trusted certificate to authenticate the server.
- Two-way TLS: The server and the client use a trusted certificate to authenticate each other.
- Endorsement Key (EK): A key generated by the vendor of a Trusted Platform Module (TPM) chip to uniquely identify the TPM chip. According to the Trusted Computing Group (TCG) specifications, the TPM stores the EK certificate issued by a trusted third party to verify the validity of the EK. The EK is important private information and cannot be used for signature.
- Attestation Key (AK): A key used in remote attestation to prevent EKs from being disclosed. It is used to sign measurement data (such as the PCR value) stored in the TPM. An AK certificate is a certificate obtained using the privacy CA protocol, containing information such as the public AK and CA issuer.
- Certificate Signing Request (CSR): Certificate signing request. In Public Key Infrastructure (PKI) systems, a certificate signing request is a message sent

from an applicant to a CA in order to apply for a digital certificate. PKCS#10 defines the syntax of a certificate request, which usually contains the public key for which the certificate should be issued, identifying information (such as a domain name) and integrity protection (such as a digital signature).

#### 4.3.2.1.2 Benefits

The Certificate Authority Service provides functions such as configuring and managing CAs, certificate profiles, and CRLs. It also supports the standard Certificate Management Protocol (CMP) and privacy CA protocol. With the Certificate Authority Service, you can quickly obtain and use certificates, reducing the costs of certificate application.

#### 4.3.2.1.3 Scenario

Based on the functions provided by the Certificate Authority Service, you can quickly obtain and use certificates by setting CA parameters.

#### □ NOTE


The Certificate Authority Service only issues identity certificates for network management software and devices. It does not issue personal certificates for authentication and signature for individual users.

### **NetEco CA Independent Networking**

As shown in the figure, in the CA independent networking scenario, after the Certificate Authority Service is deployed on the NetEco and a CA is created, end entity certificates can be issued to the NetEco and services or devices. The NetEco and services or devices can apply for certificates from the NetEco CA through CMP or privacy CA protocol, and other devices, such as security gateways, can apply for certificates in offline mode.

This networking applies to small-scale networks where the number of network devices does not exceed the NetEco CA specifications. It does not apply to networks where different devices need to be divided into multiple subdomains.

Figure 4-5 NetEco CA Independent Networking



Manual 4 System

### **NetEco CA and Operator PKI Co-Networking**

As shown in the figure, in the NetEco CA and operator PKI co-networking scenario, the NetEco subordinate CA issues end entity certificates to the NetEco and services or devices, and the operator subordinate CA issues end entity certificates to other devices such as security gateways. The operator PKI root CA certificate needs to be installed offline for services or devices, and the NetEco root CA certificate needs to be installed for other devices such as security gateways so that the mutual authentication can be successful.

This networking applies to the scenario where different subdomains are isolated from each other.




Figure 4-6 NetEco CA and Operator PKI Co-Networking


# NetEco CA and Operator PKI Co-Networking, with NetEco CA Serving as Operator CA's Subordinate CA

As shown in the figure, in the NetEco CA and operator PKI co-networking scenario where the NetEco CA functions as the operator CA's subordinate CA, the NetEco subordinate CA issues end entity certificates to the NetEco and services or devices; and the operator subordinate CA issues end entity certificates to other devices such as security gateways. The operator PKI root CA certificate needs to be installed offline for services or devices, and also need to be installed on other devices such as security gateways so that the mutual authentication can be successful.

This networking applies to the scenario where a single root CA is used on the entire network, the root CA and subordinate CAs are deployed separately, and subordinate CAs are used to divide subdomains.

User Manual 4 System

**Figure 4-7** NetEco CA and Operator PKI Co-Networking, with NetEco CA Serving as Operator CA's Subordinate CA



### NetEco CA and Operator PKI Co-Networking (Multi-Operator Scenario)

As shown in the figure, in the NetEco CA and operator PKI co-networking (multi-operator) scenario, the NetEco and services or devices can apply for certificates from multiple CAs, and different CAs can be deployed for different operators to isolate IPsec tunnels between operators. The NetEco and services or devices can automatically apply for certificates from the NetEco CA through CMP or privacy CA protocol. Other devices, such as security gateways, need to apply for certificates offline. The NetEco CA certificate chain and operator PKI certificate chain need to be installed on services or devices and security gateways. Services or devices support automatic application and manual import in offline mode during the application of end entity certificates through CMP or privacy CA protocol.

Product Operator PKI Root CA Root CA Manual import Sub CA Sub CA CMP/Privacy SSL CA protocol Offline CMP/Privacyapplication CA protocol Security Service/ IPSec Device gateway

Figure 4-8 NetEco CA and Operator PKI Co-Networking (Multi-Operator Scenario)

#### 4.3.2.1.4 Functions

This section describes the functions of the Certificate Authority Service from aspects of PKI management, protocol configuration and certificate application.

# **Certificate Authority Service Functions**

Compo nent	Function	Allows You To	
PKI Manage ment	CertProfile	Configure a certificate profile to avoid repeated configurations when you create a CA and apply for certificates.	
	CA	Create and manage CAs in certificate application scenarios.	
	Certificate Managem ent	Manage certificates, including certificate revocation, update, and download, and query of certificate details.	
	CRL	View the information and status of all CRLs, and download, update, and manually release CRLs.	
	Whitelist	Add, import, delete, and query a whitelist. A certificate can be successfully obtained only when the corresponding common name (CN) is whitelisted.	
Protocol Configu ration	СМР	Configure CMP. Integrity protection for request and response messages is required when you apply for a certificate using CMP.	
	Privacy CA Protocol	Configure the privacy CA protocol information and EK trust certificate when applying for a certificate using the privacy CA protocol.	
Certifica te Applicat ion	Certificate Applicatio n	On the <b>Certificate Application</b> page, you can apply for a certificate in different modes as required.	
	Applicatio n List	View the certificate application details.	
Global Configu ration	Port Managem ent	View the current port status and manually enable or disable the HTTP port, TLS one-way authentication por TLS two-way authentication port or privacy CA protocoport.  NOTE  HTTPS is more secure than HTTP. Therefore, you are advised to select HTTPS (One-way authentication or Two-way authentication) when configuring CMP.	
	TLS Configurat ion	Configure a TLS certificate to encrypt messages exchanged.	
HSM Management		By configuring the Hardware Security Module (HSM), the certificate key will not appear in plaintext outside the device at any time, implementing more secure key management.	


r Manual 4 System

#### **4.3.2.1.5 Principles**

This section describes the working mechanism of the Certificate Authority Service to help you learn how to apply for certificates.

Figure 4-9 shows the working mechanism of the Certificate Authority Service.

Figure 4-9 Working mechanism of the Certificate Authority Service



When applying for a certificate using the Certificate Authority Service, you need to configure the CA information, certificate profile, whitelist, and CRL as required.

Certificate application methods:

- Manual: You can apply for a certificate by entering basic information, uploading a CSR file, or using dual certificates.
- Automatic: You can apply for a certificate by configuring CMP or privacy CA protocol information.

### 4.3.2.2 Certificate Authority Service Configuration Procedure


Before using the Certificate Authority Service, you need to understand the configuration process so that you can quickly apply for and use certificates.

### **Root CA Directly Issuing End Entity Certificates**

As shown in the figure, the Certificate Authority Service is enabled on the NetEco and only one CA is deployed. Functioning as both the root CA and lowest-level CA, the CA issues end entity certificates to the NetEco and services/devices. As the lowest-level CA, the root CA can issue only end entity certificates and cannot issue lower-level CAs.

This method applies to small-scale networks where the number of network devices does not exceed the NetEco CA specifications. It does not apply to networks where different devices need to be divided into multiple subdomains.

Figure 4-10 Root CA directly issuing end entity certificates



The configuration procedure is as follows.

Ste p	Operation	Preparation	Description
1	Create a CA certificate profile.	Certificate profile name, subject information, key usage, and other required information	This step is optional. A root certificate profile is required only when the root CA is created by creating a self-signed certificate. For details, see 4.3.2.3 Configuring a Certificate Profile.  NOTE  When creating a root certificate profile, set Certificate level to Root CA and Path length constraint to 0. Set other parameters based on site requirements.
2	View root certificate profile details.	N/A	On the <b>Certificate Profile</b> page, click the name of a root certificate profile to view its details.

Ste p	Operation	Preparation	Description
3	Create a root CA.	<ul> <li>In New self-signed certificate mode: root CA name, certificate profile, subject, and other required informatio n</li> <li>In Upload certificate file mode: CA name, certificate file in .p12, .pf x, or .jks format, certificate password, and other required informatio n</li> </ul>	<ul> <li>You can create a root CA by creating a self-signed certificate or uploading a certificate file. For details, see 4.3.2.4 Configuring a CA.</li> <li>In New self-signed certificate mode, you need to select the root certificate profile created in step 1 and enter the information about the subject configured in the profile.</li> <li>NOTE         <ul> <li>When creating a root CA certificate by creating a self-signed certificate (New self-signed certificate), set Certificate profile to the root CA certificate profile created in step 1. Set other parameters based on site requirements.</li> </ul> </li> <li>In Upload certificate file mode, you need to upload the certificate prepared by yourself.         <ul> <li>NOTE</li> <li>When creating a root CA by uploading a certificate file (Upload certificate file), upload the certificate file in .p12, .pfx, or .jks format and enter the password that matches the certificate file. Set other parameters based on site requirements.</li> </ul></li></ul>
4	View root CA details.	N/A	On the <b>CA</b> page, click the name of a root CA to view its details. <b>NOTE</b> If the subject and issuer of the CA certificate are the same, the CA is a self-signed root CA.


Ste p	Operation	Preparation	Description
	Apply for a certificate.	Preparation N/A	You can apply for a certificate from the root CA in automatic application mode. The automatic application mode includes using CMP and using the privacy CA protocol.  • To apply for a certificate using CMP, you need to configure the port status, TLS certificate, CMP information, request, and responder, and use the CMP request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.8 Configuring CMP.  NOTE  • If the CMP port is an HTTP port, you do not need to configure the TLS certificate. If you select to use the CA to protect messages sent to terminals, you do not need to set response protection on the Responder Configuration tab page. Set other parameters based on site requirements.  • HTTPS is more secure than HTTP. Therefore, you are advised to select HTTPS (One-way authentication or Two-way authentication) when configuring CMP.  • To apply for a certificate using the privacy CA protocol, you need to
			privacy CA protocol, you need to configure the port status, TLS certificate, privacy CA protocol information, and EK trusted certificate, and use the privacy CA request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.9 Configuring the Privacy CA Protocol.

# Subordinate CA in a Single PKI System Issuing Certificates

As shown in the figure, after the Certificate Authority Service is enabled on the NetEco, both the root CA and subordinate CAs are deployed. The root CA can only issue subordinate CAs offline and cannot issue end entity certificates. The lowest-level subordinate CA can only issue end entity certificates and cannot issue lower-level subordinate CAs. Three methods are available:

Method 1: The root CA issues multi-level subordinate CAs. Only the lowest-level subordinate CA can issue end entity certificates. The number of subordinate CA levels depends on NetEco resources and specifications. This method applies to the scenario where the network is divided into multiple layers of subdomains.

**Figure 4-11** Subordinate CA in a single PKI system issuing certificates - method 1



The configuration procedure is as follows.

Ste p	Operatio n	Preparation	Description
1	Create a CA certificate profile.	Certificate profile name, subject information, key usage, and other required information	This step is optional. A root certificate profile is required only when the root CA is created by creating a self-signed certificate. For details, see 4.3.2.3  Configuring a Certificate Profile.  NOTE  When creating a root certificate profile, set Certificate level to Root CA. If multiple levels of subordinate CAs are constructed, the value of Path length constraint must be greater than 1. Set other parameters based on site requirements.
2	View root certificate profile details.	N/A	On the <b>Certificate Profile</b> page, click the name of a root certificate profile to view its details.


Ste p	Operatio n	Preparation	Description
3	Create a root CA.	<ul> <li>In New self-signed certificate mode: root CA name, certificate profile, subject, and other required informati on</li> <li>In Upload certificate file mode: CA name, certificate file in .p12, .p fx, or .jks format, certificate password, and other required informati on</li> </ul>	You can create a root CA by creating a self-signed certificate or uploading a certificate file. For details, see 4.3.2.4 Configuring a CA.  In New self-signed certificate mode, you need to select the root certificate profile created in step 1 and enter the information about the subject configured in the profile.  NOTE  When creating a root CA certificate by creating a self-signed certificate (New self-signed certificate), set Certificate profile to the root CA certificate profile created in step 1. Set other parameters based on site requirements.  In Upload certificate file mode, you need to upload the certificate prepared by yourself.  NOTE  When creating a root CA by uploading a certificate file (Upload certificate file), upload the certificate file in .p12, .pfx, or .jks format and enter the password that matches the certificate file. Set other parameters based on site requirements.
4	View root CA details.	N/A	On the <b>CA</b> page, click the name of a root CA to view its details.  NOTE  If the subject and issuer of the CA certificate
			If the subject and issuer of the CA certificate are the same, the CA is a self-signed root CA.

Ste p	Operatio n	Preparation	Description
5	Create a subordina te CA.	Subordinate CA name, certificate profile, subject, and other required information	<ul> <li>Method 1:</li> <li>On the CA page, click New, select</li> <li>Signed by internal CA, select a CA, and create a subCA for the CA.</li> <li>Method 2:</li> <li>1. On the CA page, create a CA in pending state and download the CSR file corresponding to the CA.</li> <li>2. On the Certificate Application page, apply for a certificate from the root CA by uploading the CSR file and download the certificate.</li> <li>3. On the CA page, upload the downloaded certificate file to the CA in pending state. The CA is activated and becomes the subordinate CA of the root CA.</li> <li>NOTE</li> <li>When constructing multiple levels of subordinate CAs, ensure that the certificate chain structure is correct and repeat the steps for creating a subordinate CA as required.</li> <li>The root CA and subordinate CAs are created on the same NetEco.</li> </ul>
6	View subordina te CA details.	N/A	On the <b>CA</b> page, click the name of a subordinate CA to view its details.

Ste p	Operatio n	Preparation	Description
		N/A	You can apply for a certificate from the root CA in automatic application mode. The automatic application mode includes using CMP and using the privacy CA protocol.  • To apply for a certificate using CMP, you need to configure the port status, TLS certificate, CMP information, request, and responder, and use the CMP request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.8 Configuring CMP.  NOTE  • If the CMP port is an HTTP port, you do not need to configure the TLS
			certificate. If you select to use the CA to protect messages sent to terminals, you do not need to set response protection on the <b>Responder</b> Configuration tab page. Set other parameters based on site requirements.  HTTPS is more secure than HTTP. Therefore, you are advised to select HTTPS (One-way authentication or Two-way authentication) when configuring CMP.
			To apply for a certificate using the privacy CA protocol, you need to configure the port status, TLS certificate, privacy CA protocol information, and EK trusted certificate, and use the privacy CA request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.9 Configuring the Privacy CA Protocol.

 Method 2: The root CA issues multiple subordinate CAs. Only the lowest-level subordinate CA can issue end entity certificates. The number of subordinate CAs depends on NetEco resources and specifications. This method applies to the scenario where the network is divided into multiple subdomains.

**Figure 4-12** Subordinate CA in a single PKI system issuing certificates - method 2



The configuration procedure is as follows.

Ste p	Operatio n	Preparation	Description
1	Create a CA certificate profile.	Certificate profile name, subject information, key usage, and other required information	This step is optional. A root certificate profile is required only when the root CA is created by creating a self-signed certificate. For details, see 4.3.2.3  Configuring a Certificate Profile.  NOTE  When creating a root certificate profile, set Certificate level to Root CA. If multiple levels of subordinate CAs are constructed, the value of Path length constraint must be greater than 1. Set other parameters based on site requirements.
2	View root certificate profile details.	N/A	On the <b>Certificate Profile</b> page, click the name of a root certificate profile to view its details.


Ste p	Operatio n	Preparation	Description
3	Create a root CA.	<ul> <li>In New self-signed certificate mode: root CA name, certificate profile, subject, and other required informati on</li> <li>In Upload certificate file mode: CA name, certificate file in .p12, .p fx, or .jks format, certificate password, and other required informati on</li> </ul>	You can create a root CA by creating a self-signed certificate or uploading a certificate file. For details, see 4.3.2.4 Configuring a CA.  In New self-signed certificate mode, you need to select the root certificate profile created in step 1 and enter the information about the subject configured in the profile.  NOTE  When creating a root CA certificate by creating a self-signed certificate (New self-signed certificate), set Certificate profile to the root CA certificate profile created in step 1. Set other parameters based on site requirements.  In Upload certificate file mode, you need to upload the certificate prepared by yourself.  NOTE  When creating a root CA by uploading a certificate file (Upload certificate file), upload the certificate file in .p12, .pfx, or .jks format and enter the password that matches the certificate file. Set other parameters based on site requirements.
4	View root CA details.	N/A	On the <b>CA</b> page, click the name of a root CA to view its details.  NOTE  If the subject and issuer of the CA certificate
			If the subject and issuer of the CA certificate are the same, the CA is a self-signed root CA.

Ste p	Operatio n	Preparation	Description
5	Create a subordina te CA.	Subordinate CA name, certificate profile, subject, and other required information	<ul> <li>Method 1:</li> <li>On the CA page, click New, select</li> <li>Signed by internal CA, select a CA, and create a subCA for the CA.</li> <li>Method 2:</li> <li>1. On the CA page, create a CA in pending state and download the CSR file corresponding to the CA.</li> <li>2. On the Certificate Application page, apply for a certificate from the root CA by uploading the CSR file and download the certificate.</li> <li>3. On the CA page, upload the downloaded certificate file to the CA in pending state. The CA is activated and becomes the subordinate CA of the root CA.</li> <li>NOTE</li> <li>When constructing multiple subordinate CAs are creating a subordinate CA as required.</li> <li>The root CA and subordinate CAs are created on the same NetEco.</li> </ul>
6	View subordina te CA details.	N/A	On the <b>CA</b> page, click the name of a subordinate CA to view its details.

Ste p	Operatio n	Preparation	Description
7	Apply for a certificate.	N/A	You can apply for a certificate from the root CA in automatic application mode. The automatic application mode includes using CMP and using the privacy CA protocol.  • To apply for a certificate using CMP,
			you need to configure the port status, TLS certificate, CMP information, request, and responder, and use the CMP request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.8 Configuring CMP.
			NOTE
			<ul> <li>If the CMP port is an HTTP port, you do not need to configure the TLS certificate. If you select to use the CA to protect messages sent to terminals, you do not need to set response protection on the Responder</li></ul>
			Therefore, you are advised to select HTTPS ( <b>One-way authentication</b> or <b>Two-way authentication</b> ) when configuring CMP.
			To apply for a certificate using the privacy CA protocol, you need to configure the port status, TLS certificate, privacy CA protocol information, and EK trusted certificate, and use the privacy CA request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.9 Configuring the Privacy CA Protocol.

 Method 3: The root CA issues multiple subordinate CAs that are deployed on different NetEcos. Only the lowest-level subordinate CA can issue end entity certificates. Services/devices that have certificates issued by different subordinate CAs must have the root CA certificate installed so that the mutual authentication can be successful. This method applies to the scenario where the NetEco and its services/devices are divided into a subdomain.

Figure 4-13 Subordinate CA in a single PKI system issuing certificates - method  ${\bf 3}$ 



The configuration procedure is as follows.

Ste p	Operation	Preparation	Description
1	Create a CA certificate profile.	Certificate profile name, subject information, key usage, and other required information	This step is optional. A root certificate profile is required only when the root CA is created by creating a self-signed certificate. For details, see 4.3.2.3 Configuring a Certificate Profile.  NOTE  When creating a root certificate profile, set Certificate level to Root CA. If multiple levels of subordinate CAs are constructed, the value of Path length constraint must be greater than 1. Set other parameters based on site requirements.
2	View root certificate profile details.	N/A	On the <b>Certificate Profile</b> page, click the name of a root certificate profile to view its details.

Ste p	Operation	Preparation	Description
3	Create a root CA.	<ul> <li>In New self-signed certificate mode: root CA name, certificate profile, subject, and other required informatio n</li> <li>In Upload certificate file mode: CA name, certificate file in .p12, .pf x, or .jks format, certificate password, and other required informatio n</li> </ul>	<ul> <li>You can create a root CA by creating a self-signed certificate or uploading a certificate file. For details, see 4.3.2.4 Configuring a CA.</li> <li>In New self-signed certificate mode, you need to select the root certificate profile created in step 1 and enter the information about the subject configured in the profile.</li> <li>NOTE         <ul> <li>When creating a root CA certificate by creating a self-signed certificate (New self-signed certificate), set Certificate profile to the root CA certificate profile created in step 1. Set other parameters based on site requirements.</li> </ul> </li> <li>In Upload certificate file mode, you need to upload the certificate prepared by yourself.         <ul> <li>NOTE</li> <li>When creating a root CA by uploading a certificate file (Upload certificate file), upload the certificate file in .p12, .pfx, or .jks format and enter the password that matches the certificate file. Set other parameters based on site requirements.</li> </ul></li></ul>
4	View root CA details.	N/A	On the <b>CA</b> page, click the name of a root CA to view its details. <b>NOTE</b> If the subject and issuer of the CA certificate are the same, the CA is a self-signed root CA.

Ste p	Operation	Preparation	Description
5	Create a subordinat e CA.	Subordinate CA name, certificate profile, subject, and other required information	<ul> <li>Method 1:</li> <li>On the CA page, click New, select Signed by internal CA, select a CA, and create a subCA for the CA.</li> <li>Method 2:</li> <li>1. On the CA page, create a CA in pending state and download the CSR file corresponding to the CA.</li> <li>2. On the Certificate Application page, apply for a certificate from the root CA by uploading the CSR file and download the certificate.</li> <li>3. On the CA page, upload the downloaded certificate file to the CA in pending state. The CA is activated and becomes the subordinate CA of the root CA.</li> <li>NOTE</li> <li>When constructing multiple subordinate CAs, repeat the steps for creating a subordinate CA as required.</li> <li>The root CA and subordinate CAs are created on different NetEcos.</li> </ul>
6	View subordinat e CA details.	N/A	On the <b>CA</b> page, click the name of a subordinate CA to view its details.

Ste p	Operation	Preparation	Description
7	Apply for a certificate.	N/A	You can apply for a certificate from the root CA in automatic application mode. The automatic application mode includes using CMP and using the privacy CA protocol.
			<ul> <li>To apply for a certificate using CMP, you need to configure the port status, TLS certificate, CMP information, request, and responder, and use the CMP request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.8 Configuring CMP.</li> </ul>
			• If the CMP port is an HTTP port, you do not need to configure the TLS certificate. If you select to use the CA to protect messages sent to terminals, you do not need to set response protection on the Responder Configuration tab page. Set other parameters based on site requirements.
			<ul> <li>HTTPS is more secure than HTTP.         Therefore, you are advised to select         HTTPS (One-way authentication or Two-way authentication) when configuring CMP.     </li> </ul>
			To apply for a certificate using the privacy CA protocol, you need to configure the port status, TLS certificate, privacy CA protocol information, and EK trusted certificate, and use the privacy CA request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.9 Configuring the Privacy CA Protocol.

# Subordinate CA in a Multi-PKI System Issuing Certificates

As shown in the figure, different root CAs are deployed on different NetEcos. The peer root CA certificate needs to be installed on services/devices in different subdomains so that the mutual authentication can be successful. On NetEco-1, the Certificate Authority Service is enabled and root CA-1 is deployed. On NetEco-2, the Certificate Authority Service is enabled and root CA-2 (different from root CA-1) is deployed. The two root CAs are independent of each other. The certificates of root CA-1 and root CA-2 need to be installed on service/device-1 and service/device-2 so that the mutual authentication can be successful.

This method applies to the networking scenario where different subdomains are completely isolated. More subdomains require more root CAs, complicating management.

Product-1 Product-n Root CA-n Root CA-1 Manual Manual import import Sub CA-1 Sub CA-n CMP/Privacy CMP/Privacy CA protocol CA protocol Service/ Service/ Device-1 Device-n

Figure 4-14 Subordinate CA in a multi-PKI system issuing certificates

The configuration procedure is as follows.

Ste p	Operation	Preparation	Description
1	Create a CA certificate profile.	Certificate profile name, subject information, key usage, and other required information	This step is optional. A root certificate profile is required only when the root CA is created by creating a self-signed certificate. For details, see 4.3.2.3 Configuring a Certificate Profile.  NOTE  When creating a root certificate profile, set Certificate level to Root CA. If multiple levels of subordinate CAs are constructed, the value of Path length constraint must be greater than 1. Set other parameters based on site requirements.
2	View root certificate profile details.	N/A	On the <b>Certificate Profile</b> page, click the name of a root certificate profile to view its details.

Ste p	Operation	Preparation	Description
3	Create a root CA.	<ul> <li>In New self-signed certificate mode: root CA name, certificate profile, subject, and other required informatio n</li> <li>In Upload certificate file mode: CA name, certificate file in .p12, .pf x, or .jks format, certificate password, and other required informatio n</li> </ul>	<ul> <li>You can create a root CA by creating a self-signed certificate or uploading a certificate file. For details, see 4.3.2.4 Configuring a CA.</li> <li>In New self-signed certificate mode, you need to select the root certificate profile created in step 1 and enter the information about the subject configured in the profile.</li> <li>NOTE         <ul> <li>When creating a root CA certificate by creating a self-signed certificate (New self-signed certificate), set Certificate profile to the root CA certificate profile created in step 1. Set other parameters based on site requirements.</li> </ul> </li> <li>In Upload certificate file mode, you need to upload the certificate prepared by yourself.         <ul> <li>NOTE</li> <li>When creating a root CA by uploading a certificate file (Upload certificate file), upload the certificate file in .p12, .pfx, or .jks format and enter the password that matches the certificate file. Set other parameters based on site requirements.</li> </ul></li></ul>
4	View root CA details.	N/A	On the <b>CA</b> page, click the name of a root CA to view its details. <b>NOTE</b> If the subject and issuer of the CA certificate are the same, the CA is a self-signed root CA.

Ste p	Operation	Preparation	Description
5	Create a subordinat e CA.	Subordinate CA name, certificate profile, subject, and other required information	<ul> <li>Method 1:</li> <li>On the CA page, click New, select Signed by internal CA, select a CA, and create a subCA for the CA.</li> <li>Method 2:</li> <li>1. On the CA page, create a CA in pending state and download the CSR file corresponding to the CA.</li> <li>2. On the Certificate Application page, apply for a certificate from the root CA by uploading the CSR file and download the certificate.</li> <li>3. On the CA page, upload the downloaded certificate file to the CA in pending state. The CA is activated and becomes the subordinate CA of the root CA.</li> <li>NOTE</li> <li>When constructing multiple subordinate CAs, repeat the steps for creating a subordinate CA as required.</li> <li>The root CA and subordinate CAs are created on different NetEcos. Pay attention to the matching relationship.</li> </ul>
6	View subordinat e CA details.	N/A	On the <b>CA</b> page, click the name of a subordinate CA to view its details.

Ste p	Operation	Preparation	Description
7	Apply for a certificate.	N/A	You can apply for a certificate from the root CA in automatic application mode. The automatic application mode includes using CMP and using the privacy CA protocol.
			<ul> <li>To apply for a certificate using CMP, you need to configure the port status, TLS certificate, CMP information, request, and responder, and use the CMP request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.8 Configuring CMP.</li> <li>NOTE</li> </ul>
			If the CMP port is an HTTP port, you do not need to configure the TLS certificate. If you select to use the CA to protect messages sent to terminals, you do not need to set response protection on the Responder Configuration tab page. Set other parameters based on site requirements.
			<ul> <li>HTTPS is more secure than HTTP.         Therefore, you are advised to select         HTTPS (One-way authentication or Two-way authentication) when configuring CMP.     </li> </ul>
			To apply for a certificate using the privacy CA protocol, you need to configure the port status, TLS certificate, privacy CA protocol information, and EK trusted certificate, and use the privacy CA request URI to apply for a certificate. For details, see Global Configuration and 4.3.2.9 Configuring the Privacy CA Protocol.

# 4.3.2.3 Configuring a Certificate Profile

When creating a CA and applying for certificates, you can configure a certificate profile to avoid repeated configurations and meet certificate application and usage requirements in different scenarios.

# Context

- A certificate profile is a set of rules and settings used for certificate application and management. These rules and settings can be simple or complex to meet your varying requirements.
- Predefined profiles are default profiles provided by the system and cannot be deleted or modified. For detailed parameter descriptions, see **Table 4-11**. The

2022-02-25

following table describes some parameters in the preset profile. The actual configuration varies according to the information on the page.

**Table 4-11** Predefined profile parameters

Ce rtif ica te lev el	Label	Desc ripti on	Ke y alg ori th m	Ke y le ng th	EC DS A ke y ty pe	Val idit y	Basic constrai nts	Key usag e	Cert ifica te poli cy OID	Subjec t
Ro ot CA	ROOT _CA_P REDE FINE D_RS A409 6	OOT The RS 40 N/ 40 • Critic al rs Type: CA RS t	<ul><li>al</li><li>Type: CA</li><li>Path lengt</li></ul>	Digit 2.5. al 29.3 signa ture, CRL signa ture,	29.3	Comm on name( CN), Countr y name(				
	ROOT _CA_P REDE FINE D_EC DSA3 84	and trust ed. To creat e a root CA certif icate , use this profi le.	EC DS A	38 4	EC sec p3 84r 1		h const raint: None	Certif icate signa ture		C), Organi zation( O), Organi zation al unit(O U)
Su bo rdi na te CA	SUB_ CA_P REDE FINE D_RS A409 6	This profile is used to apply for a sub-CA certificate from the root CA or a subo	RS A	40 96	N/ A	25 yea rs	<ul> <li>Critic al</li> <li>Type: CA</li> <li>Path lengt h const raint: 0</li> </ul>			

Ce rtif ica te lev el	Label	Desc ripti on	Ke y alg ori th m	Ke y le ng th	EC DS A ke y ty pe	Val idit y	Basic constrai nts	Key usag e	Cert ifica te poli cy OID	Subjec t
	SUB_ CA_P REDE FINE D_EC DSA3 84	rdin ate CA. To cons truct a mult i- level CA certificate chai n, use this profile.	EC DS A	38 4	EC sec p3 84r 1					
En d ent ity	END_ ENTIT Y_PRE DEFI NED_ RSA2 048	This profile is used to apply for	RS A	20 48	N/ A	yea rs	<ul><li>Type: End entit y</li><li>Path lengt h</li></ul>	Digit al signa ture, Cont ent com		
	END_ ENTIT Y_PRE DEFI NED_ RSA3 072	an end entit y certif icate from the root CA or a subo rdin ate CA. To appl y for	RS A	30 72	N/ h const	mitm ent (non- repu diati on), Key encip herm ent, Data encip herm ent, Key agree ment				

Ce rtif ica te lev el	Label	Desc ripti on	Ke y alg ori th m	Ke y le ng th	EC DS A ke y ty	Val idit y	Basic constrai nts	Key usag e	Cert ifica te poli cy OID	Subjec t
	END_ ENTIT Y_PRE DEFI NED_ ECDS A256	an end entit y certificate, use this profile.	EC DS A	25 6	EC pri me 25 6v 1					

# Procedure

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **PKI Management** > **Certificate Profile** from the navigation tree on the left.
- **Step 3** Click **New** and set required parameters.

For detailed parameter descriptions, see Table 4-12.

Table 4-12 Certificate profile parameters

Parameter	Description	Value
Label	Name of a certificate profile.	The name is a string of 1 to 45 characters containing letters, digits, underscores (_), and hyphens (-).  The name cannot be null or all (case insensitive).
		miscrisitive).
Certificate level	Certificate level, which can be root CA, subordinate CA, or end-entity CA.	N/A

Parameter	Description	Value
Description	Description of a certificate profile.	The description is a string of 0 to 128 characters containing digits, uppercase letters, lowercase letters, spaces, and special characters: ( , . ! : ; ? ).
Subject	Identifiable alias of the certificate user, including Common name(CN), Country name(C), Email address (E), Organization(O), Organizational unit(OU), State(ST), Locality(L), Domain component (DC), and User identifier (UID).	By default, Common name is mandatory and cannot be deselected. When you need to fill in the profile subject information, the common name is a string of 1 to 127 characters containing uppercase letters, lowercase letters, digits, spaces, hyphens (-), colons (:), and dots (.). If Domain component is selected, a maximum of 4 domain components can be configured at a time when Domain component information needs to be set in the profile.
Validity period	Validity period of a certificate profile.	You can set the certificate profile's validity period in units of day, month, or year. The maximum validity period is 18250 days.
Key algorithm	Key algorithm, which can be RSA or ECDSA.	N/A

Parameter		Description	Value
Key length		If RSA is used, the available options are 2048, 3072, 4096, and 8192.	N/A
		If ECDSA is selected, the available options are 256, 384, and 521.	
ECDSA key	type	Available options: ECprime256v1, ECsecp256r1, ECsecp384r1, ECsecp521r1.	N/A
		NOTE Set this parameter when you select the ECDSA algorithm.	
Subject key	identifier	Unique identifier of the subject.	N/A
Authority Include issuer and identifier SN		Unique identifier of the key contained in a certificate. It is used to identify multiple pairs of keys of the same issuer.	N/A
Basic const	raints	Used to ensure that certificates are used only in certain applications.	N/A

Parameter		Description	Value
Path length	constraint	When the value of the path length constraint extension is 0, it indicates that the CA certificate can only issue end entity certificates in the valid certificate path. When the value of the path length constraint extension is greater than 0, it indicates the maximum number of intermediate subordinate CA certificates that may exist in the path from the CA certificates. If a CA system has n layers, the path length constraint of the top-layer CA certificate is n - 2, and those of the lower-layer certificates is n - 3, n - 4, and so on. The result is greater than or equal to 0.  For example, if n is 4, the four-layer structure of the CA is root CA > subordinate CA1 > subordinate CA1 > subordinate CA1 issues the subordinate CA2, and subordinate CA2, and subordinate CA2 issues the end entity certificate. In this case, the path length of the root CA is 2, the path length of subordinate CA1 is 1, and the path length of subordinate CA1 is 1, and the path length of subordinate CA2 is 0.  NOTE  The path length constraint can be set only when Certificate level is set to Root CA or Subordinate CA.	The path length constraint must range from 0 to 9.
Subject alternativ e name	tiv name the alias of the certificate		If Subject alternative name is selected, a maximum of 16 domain names and IP addresses in total can be configured at a time when Subject

Parameter		Description	Value
	IP address	IP address contained in the alias of the certificate issuing object.	alternative name information needs to be set in the profile.
Certificate p	policy	A certificate policy defines the policy for issuing certificates and the application scenarios of certificates. A certificate policy ID is in the format of object identifier (OID).  2.5.29.32.0 indicates any policy. If you need to customize your own certificate policy, you must create a certificate policy ID, which must be constructed based on the enterprise ID allocated by the IANA. You can obtain the enterprise ID from the IANA free of charge.  A certificate policy consists of a certificate policy ID and a qualifier. The certificate policy ID and a qualifier in the certificate policy extensions of a certificate. The qualifier is used to express the detailed information that depends on the policy. The qualifier includes the following three types:  No policy qualifier: Indicates that the certificate policy does not contain additional information.  CPS URI: The CPS qualifier indicates the URI of the certificate practice statement issued by the CA.  User notice text: Displays certificate information to certificate users.	A maximum of four certificate policies can be created for each certificate profile.  The certificate policy ID must be a string of 3 to 256 characters prefixed with 0./1./2. If the period (.) is followed by 0, 0 cannot be followed by other digits. For example, 2.5.29.32.0 is in correct format, but 2.02 is in incorrect format.  The CPS URI must contain 1 to 256 characters.  The user notice text must contain 1 to 200 characters, including digits, uppercase letters, lowercase letters, spaces, and special characters: (,.!:;?).

Parameter		Description	Value
Key usage	Digital signature	A signature generated using the private key of the issuer. It is used for entity authentication and data source integrity authentication.	If the certificate level of the profile is End entity, Digital signature is selected by default for Key usage and can be deselected.
	Content commitme nt (non- repudiation )	Verifies digital signature denial services used to provide non-digital signatures, preventing the signing entity from incorrectly denying certain operations. In the case of subsequent conflicts, a reliable third party can determine the authenticity of the signature data.	N/A
	Key encipherme nt	Encrypts private keys or keys during key transmission.	N/A
	CRL signature	Required when the subject public key is used to verify the signature in the revocation information (such as CRL).	If the certificate level of the profile is Root CA or Subordinate CA, CRL signature is selected by default for Key usage and can be deselected.
	Data encipherme nt	Used to encrypt important user data instead of encoding keys.	N/A
	Certificate signature	Used to verify the signature in the public key certificate.	If the certificate level of the profile is Root CA or Subordinate CA, Certificate signature is selected by default for Key usage and can be deselected.
	Key agreement	Key agreement protocol. For example, when the Diffie-Hellman key is used for key management, select this option.	If the certificate level of the profile is End entity, Key agreement is selected by default for Key usage and can be deselected.

Parameter		Description	Value
	Encipher only	Uses a key to encrypt data only when the key protocol agreement is run.	N/A
	Decipher only	Uses a key to decrypt data only when the key protocol agreement is run.	N/A
Extended key usage	TLS web server identity authenticati on	Authenticates the TLS www server. Digital signature, Key encipherment, or Key agreement may also provide the same function.	N/A
	TLS web client identity authenticati on	Authenticates the TLS www client. <b>Digital signature</b> and/or <b>Key agreement</b> may also provide the same function.	N/A
	Sign executable code	Signs the executable code that can be downloaded. <b>Digital signature</b> may also provide the same function.	N/A
	Timestampi ng	Binds the hash of the object to the time. <b>Digital signature</b> and/or <b>Content commitment</b> may also provide the same function.	N/A
	Email protection	Protects emails. Digital signature, Content commitment, and/or Key encipherment or Key agreement may also provide the same function.	N/A
	IPSec end system	IP security terminal system.	N/A
	IPSec user	IP security user.	N/A
	IPSec tunnel	IP security tunnel.	N/A
CRL distribution point		A location where CRLs are published. You can obtain the CRL corresponding to the certificate based on this parameter.	This parameter cannot be set when <b>Certificate level</b> is set to <b>Root CA</b> .

#### □ NOTE

- Critical: The certificate user performs strong verification on the extensions that are marked as critical.
- Required: During certificate request, the packet must contain this extension.
- Permitted in request: During certificate issuing, the value of this extension in the request packet is used.

### Step 4 Click Submit.

You can click **Reset** to clear parameter settings.

----End

### **Related Tasks**

• Viewing a certificate profile

On the **Certificate Profile** page, click the name of a certificate profile. Then you can view the detailed information about this certificate profile.

Modifying a certificate profile

On the **Certificate Profile** page, click **Modify** in the **Operation** column of a certificate profile. Then you can modify the configuration of this certificate profile.

#### □ NOTE

- The certificate profile name cannot be changed when you modify the certification profile configuration.
- The predefined certificate profile cannot be modified.
- If the certificate level of a profile is Subordinate CA or End-entity and the profile
  has been associated with a CA, the certificate level of the profile cannot be
  changed to Root CA.
- Copying a certificate profile

On the **Certificate Profile** page, click **Copy** in the **Operation** column of a certificate profile. Then you can copy this certificate profile and rename it.

• Deleting a certificate profile

On the **Certificate Profile** page, click **Delete** in the **Operation** column of a certificate profile.

□ NOTE

The predefined certificate profile cannot be deleted.

Searching for a certificate profile

On the **Certificate Profile** page, enter a certificate profile name in the search box and click  $\bigcirc$ . The Certificate Authority Service supports fuzzy search by certificate profile name.

# 4.3.2.4 Configuring a CA

If you do not have a CA or have a CA that does not meet the requirements for issuing certificates, you can configure one on the CA management page to facilitate your subsequent certificate application and use.

### Context

The Certificate Authority Service provides a certificate issuance solution to address the problems arising from the unavailability of a CA or an existing CA that does not meet the requirements.

### NOTICE

When importing a third-party certificate, ensure that the certificate is issued by a trusted CA. Otherwise, security risks exist.

# **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **PKI Management** > **CA** from the navigation tree on the left.
- **Step 3** Click **New** and set required parameters.

For detailed parameter descriptions, see Table 4-13.

**Table 4-13** CA parameters

Parameter	Description	Value
Label	Name of a CA.	<ul> <li>The name is a string of 1 to 45 characters containing letters, digits, underscores (_), and hyphens (-).</li> <li>The name cannot be null or all (case insensitive).</li> </ul>
Status	You can create an activated, inactive, or pending CA.  NOTE  Before uploading a CA certificate, you cannot apply for a certificate from a CA in the pending state.	By default, the CA created is activated.
Signature algorithm	Signature algorithm used for a CA to issue certificates.  NOTE  RSASSA-PSS is more secure than RSA. Currently, only TLS1.3 supports the certificate signed by RSASSA-PSS. TLS1.2 and earlier versions do not support the certificate signed by RSASSA-PSS. If the certificate issued by the user is used for TLS communication, confirm the TLS version before configuring the CA signature algorithm. Otherwise, the TLS communication may fail.	N/A

Para	ameter	Description	Value
	ificate ength	Length of the unique number assigned by a CA to a certificate.	The value is an integer ranging from 18 to 40, in characters.
Max peri	validity od	Maximum validity period of a certificate.	You can set the certificate validity period in units of day, month, or year. The maximum validity period is 18250 days.
sign	v self- ed ificate	A certificate issued by a signing entity to itself, not by an authoritative CA.  When creating a CA in self-signed mode, you need to select a certificate profile whose certificate level is <b>Root CA</b> and enter the user information configured in the profile.	N/A
Up lo ad ce rtif ica te fil e	Certifica te file	You can create a CA by uploading a local certificate file. In this mode, you will create a subordinate CA of the organization that issues the certificate file. This subordinate CA is used to issue certificates to lower-level organizations.	<ul> <li>The certificate file must be in .p12, .pfx, or .jks format.</li> <li>Only one certificate can be uploaded, and the size of a single file cannot exceed 20 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> </ul>
	Certifica te passwor d	Password set for a certificate during certificate application. The password is contained in the .p12 file. You need to enter this password when uploading the certificate file.	N/A

Para	ameter	Description	Value
	Upload certifica te chain	Upload the corresponding certificate chain. You can select multiple files. For example, if a level-3 CA certificate is imported, upload the corresponding level-1 and level-2 CA certificates.	<ul> <li>The certificate chain file must be in .cer, .crt, or .pem format.</li> <li>A maximum of 10 files can be upload at a time. And the size of the file to be uploaded at a time cannot exceed 100 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> </ul>
Nev	v CSR file	When the CA status is <b>Pending</b> , <b>New CSR file</b> is automatically selected for certificate configuration mode.	N/A
Si gn ed by int er	Internal CA	In <b>Signed by internal CA</b> mode, a sub-CA is created for a CA.  When creating a sub-CA using the internal CA signature, you need to select a CA as the parent CA.	N/A
na l CA	Certifica te profile	When creating a sub-CA in Signed by internal CA mode, you need to select a certificate profile whose certificate level is Subordinate CA and enter the user information configured in the profile.	N/A
Key gen mod	eration	You can use <b>Software</b> or <b>HSM</b> to generate keys.	N/A
CRL gene	eration	Interval for generating a CRL.	The value is an integer ranging from 1 to 60, in days.
CRL gene	eration	Time when the CRL is generated.	N/A

Parameter	Description	Value
CRL overlap time	Period during which a user can obtain a new CRL before the old CRL is considered unavailable.	The value is an integer ranging from 1 to 60, in minutes.
Include revocation reasons	Whether to include the revocation reason.	The default value is <b>Yes</b> .
CRL server	Server to which a CRL is published.	N/A
Publication mode	Whether a CRL is published manually or automatically.  If you select <b>Automatic</b> , you must configure the CRL server and the publication period.	<ul> <li>By default, Automatic is not selected, indicating that manual publishing is used.</li> <li>If you select Automatic, the default publishing interval is 60 minutes.</li> <li>The unit of the publishing interval can be minute, hour, or day. The maximum interval is 180 days.</li> </ul>
CRL distribution point	A location where CRLs are published, for example, http://IP address:Port number/caname.crl. You can obtain the CRL corresponding to the certificate based on this parameter.  NOTE  The CRL obtained from the CRL distribution point can be used to verify the validity of the certificate issued by the CA. The Certificate Authority Service does not automatically release the CRL to the CRL distribution point. You need to maintain the validity of the CRL file at the distribution point.	Each CA can be configured with a maximum of four CRL distribution points.

# Step 4 Click Next.

**Step 5** In the profile association list, select the profile to be associated.

# □ NOTE

- Configure an associated profile for the CA to issue certificates. The associated profile must be a sub-CA profile or an end-entity profile.
- A CA must be associated with at least one profile, and a maximum of 16 profiles can be associated.

Manual 4 System

**Step 6** In the default profile list, select an associated profile as the default profile.

### □ NOTE

- During certificate application using CMP or privacy CA protocol, if the request carries the profile name parameter, the specified profile is used; if the request does not carry the profile name parameter, the default profile of the CA is used.
- Only one default profile can be set for a CA.

### Step 7 Click Submit.

#### 

- You can click **Reset** to clear parameter settings.
- You can also click **Back** to return to the previous page.

#### ----End

# Follow-up Procedure

Deactivating a CA

For a created and activated CA, you can access the **CA** page and click **Deactivate CA** in the **Operation** column of the CA to deactivate it.

Activating a CA

For a created but inactivated CA, you can access the **CA** page and click **Active CA** in the **Operation** column of the CA to activate it.

Downloading CSR

For a created but pending CA, you can download the CSR file directly after creating a CA or click **Download CSR** on the **CA** page to download the CSR file of the CA.

Uploading a CA certificate

For a created but pending CA, you can access the **CA** page and click **Upload CA certificate** in the **Operation** column of the CA to upload a CA certificate.

## □ NOTE

- The certificate file or certificate chain must be in .cer, .crt, or .pem format. Only one certificate can be uploaded, and the size of a single file cannot exceed 100 KB. The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (\_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.
- If the certificate issued by the current CA is used to sign the CMP request packet, the CA uses the current CA and CA certificate chain to verify the signature certificate of the request packet.
- For a CA that has been created and is in the pending state, if the CA certificate is not uploaded within 15 days, the CA will be deleted.
- Updating a Key

Choose **PKI Management** > **CA**. Click **Rekeying** in the **Operation** column of a CA to update the key. After the key is updated, a new root CA is created and the OldWithNew and NewWithOld certificates are automatically created. You can view or download the associated certificates by referring to **Related Tasks**.

Downloading a CA certificate

Choose **PKI Management** > **CA**. Click **Download CA Certificate** in the **Operation** column of a CA to download the CA certificate to the local computer.

Choose **PKI Management** > **CA**. Click a CA name. On the page that is displayed, click **Download CA Certificate** to download the CA certificate to the local computer.

If the CA status is pending, the CA certificate cannot be downloaded.

### **Related Tasks**

Querying a CA

Choose **PKI Management** > **CA**. Click a CA name to view the CA details on the **CA Information** tab page, including the status, Certificate SN length, signature algorithm, associated profile, and default profile.

• Querying a CA certificate

Choose **PKI Management** > **CA**. Click a CA name to view the CA details on the **CA Certificate** tab page, including the version, SN, subject, and validity period.

□ NOTE

If the CA status is pending, you cannot view the CA certificate information.

• Querying an associate certificate

Choose **PKI Management** > **CA**. Click a CA name to view the CA details on the **Associate Certificate** tab page, including the version, SN, subject, and validity period.

- OldWithNew: Certificate generated when the CA key is updated. The certificate contains the public key of the old key. The validity period of the certificate is the same as that of the old CA. For the entity that uses the new certificate of the root CA as the trust root, if such an entity is not verified, you need to obtain the OldWithNew certificate of the root CA. The verification process is to use the root CA's new key to verify the old key, and then use the old key to verify the end entities that are originally subordinated to the old root CA.
- NewWithOld: Certificate generated when the CA key is updated, including the public key of the new key. The effective date of the certificate is that of the new CA, and the expiration date is that of the old CA. For entities that use the old certificate of the root CA as the trust root, apply for a new certificate as soon as possible. During this period, if entities that use the new certificate of the root CA as the trust root need to be verified, obtain the NewWithOld certificate of the root CA first. The verification process is to use the root CA's old key to verify the new key, and then use the new key to verify the end entities that are originally subordinated to the new root CA.
- Downloading an associate certificate

Choose **PKI Management** > **CA**. Click a CA name, and click **Download** on the **Associated Certificate** tab page to download the CA certificate to the local computer. If you select download multiple certificates, the selected certificates are combined and downloaded to a .pem certificate file.

Modifying a CA

Choose **PKI Management** > **CA**. Click **Modify** in the **Operation** column of a CA to modify its configuration.

### ■ NOTE

- When modifying the CA configuration, you can only modify the Max validity period, Certificate SN length, CRL generation interval, CRL generation time, CRL overlap time, Include revocation reasons, CRL server, Publication mode, CRL distribution point, associated profile, and default profile of the CA.
- When you create a CA by uploading a file, if a certificate chain file has been uploaded, the **Upload Certificate Chain** option is not displayed when you configure the CA.
- When you create a CA by uploading a file, if the certificate chain file is not uploaded or fails to be uploaded, the **Upload Certificate Chain** option is displayed when you configure the CA.
- If the CA status is pending, the CA configuration information cannot be modified.
- Searching for a CA

Choose **PKI Management** > **CA**. Enter a CA name in the search box and click

- to find the specified CA and view its details. The Certificate Authority Service supports fuzzy search by CA name.
- Searching for an associated profile
  - When creating or modifying a CA on the **PKI Management** > **CA** page, enter the name of an associated profile in the search box on the page for setting
  - associated profiles, and click to find the specified associated profile. The Certificate Authority Service supports fuzzy search by associated profile name.
- Searching for a default profile
  - When creating or modifying a CA on the **PKI Management** > **CA** page, enter the name of a default profile in the search box on the page for setting default
  - profiles, and click to find the specified default profile. The Certificate Authority Service supports fuzzy search by default profile name.

# 4.3.2.5 Applying for a Certificate

On the **Certificate Application** page, you can apply for a certificate in different modes as required.

# 4.3.2.5.1 Application Method 1: Entering Basic Information

To meet different requirements for certificate application, the Certificate Authority Service allows you to apply for a certificate by entering basic information.

### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Certificate Application** > **Certificate Application** from the navigation tree on the left.
- **Step 3** On the **Apply by Basic Info** tab page, enter certificate application information.

#### □ NOTE

- The subject information in the certificate application request must be different from that of the associated CA. Otherwise, certificate application fails.
- When applying for a certificate by configuring basic information, you can select only a profile whose certificate level is **End entity**.
- The validity period of a certificate is the intersection of the following four validity periods: validity period of the CA associated with the certificate, validity period set in the certificate profile, validity period set in the associated CA, and validity period set during certificate application.
- You can click **Reset** to clear parameter settings.

### Step 4 Click Submit.

----End

### **Related Tasks**

• Viewing a certificate

On the **PKI Management** > **Certificate** page, click the SN of a certificate to view the certificate details.

#### 

A certificate will be automatically deleted 30 days after it expires. If the number of certificates issued by the Certificate Authority Service exceeds 80% of the maximum number supported by the Certificate Authority Service, all expired certificates are automatically deleted.

• Updating a certificate

On the **PKI Management** > **Certificate** page, click **Update** in the **Operation** column of a certificate to update it. After the certificate is updated, you can choose whether to download the certificate to the local computer.

#### 

The certificate obtained by using CMP, privacy CA protocol or uploading the CSR file cannot be updated.

Searching for a certificate

On the **PKI Management** > **Certificate** page, enter the subject name of the certificate in the search box for a search. You can also specify the SN, validity period, revocation reason, issuer or status of the certificate in **Advanced Search**. The Certificate Authority Service supports fuzzy search by subject name, SN, validity period or issuer.

On the **Certificate Application** > **Application List** page, enter the applicant, CA name, subject or submitted time of the certificate in the search box for a search. The Certificate Authority Service supports fuzzy search by applicant, CA name, subject or submitted time.

Revoking a certificate

On the **PKI Management** > **Certificate** page, click **Revoke** in the **Operation** column of a certificate to revoke it.

### **NOTICE**

Only certificates whose revocation reason is "Certificate is on hold" can have their revocation canceled. Certificates revoked for other reasons can no longer be trusted.

Canceling certificate revocation

On the **PKI Management** > **Certificate** page, click **Undo Revoke** in the **Operation** column of a certificate to cancel the certificate revocation.

- Downloading a certificate
  - On the Certificate Application > Application List page, click Download Certificate in the Operation column of a certificate to download it to the local computer.

#### □ NOTE

- When downloading a certificate that is requested by entering basic
  information, you need to enter a password. The password is a string of 8 to
  32 characters containing at least three of the following: digits, uppercase
  letters, lowercase letters, and special characters. In addition, the password
  cannot contain two or more of the same characters consecutively.
- Only successfully obtained certificates can be downloaded.
- On the PKI Management > Certificate page, click Download in the Operation column of a certificate, enter the file name and password, and download the certificate to the local computer.

### ∩ NOTE

- The file name is a string of 1 to 20 characters containing uppercase letters, lowercase letters, digits, hyphens (-), and underscores (\_).
- When downloading a certificate that is requested by entering basic information, you need to enter a password. The password is a string of 8 to 32 characters containing at least three of the following: digits, uppercase letters, lowercase letters, and special characters. In addition, the password cannot contain two or more of the same characters consecutively.

# 4.3.2.5.2 Application Method 2: Uploading a File

To meet different requirements for certificate application, the Certificate Authority Service allows you to apply for a certificate by uploading a CSR file.

### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Certificate Application** > **Certificate Application** from the navigation tree on the left.
- **Step 3** On the **Apply by File Upload** tab page, enter certificate application information.
- **Step 4** Click **Select** next to **CSR file**.
- **Step 5** Select a local CSR file and click **Submit**.

#### □ NOTE

- The subject information in the CSR file must be different from that of the associated CA. Otherwise, certificate application fails.
- The certificate chain file to be uploaded must be in .csr, .txt, or .req format, and the size of a single file cannot exceed 100 KB. The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (\_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.
- You can click **Reset** to clear parameter settings.

#### ----End

#### Related Tasks

Viewing a certificate

On the **PKI Management** > **Certificate** page, click the SN of a certificate to view the certificate details.

#### ∩ NOTE

A certificate will be automatically deleted 30 days after it expires. If the number of certificates issued by the Certificate Authority Service exceeds 80% of the maximum number supported by the Certificate Authority Service, all expired certificates are automatically deleted.

Updating a certificate

On the **PKI Management** > **Certificate** page, click **Update** in the **Operation** column of a certificate to update it. After the certificate is updated, you can choose whether to download the certificate to the local computer.

#### □ NOTE

The certificate obtained by using CMP, privacy CA protocol or uploading the CSR file cannot be updated.

Searching for a certificate

On the **PKI Management** > **Certificate** page, enter the subject name of the certificate in the search box for a search. You can also specify the SN, validity period, revocation reason, issuer or status of the certificate in **Advanced Search**. The Certificate Authority Service supports fuzzy search by subject name, SN, validity period or issuer.

On the **Certificate Application** > **Application List** page, enter the applicant, CA name, subject or submitted time of the certificate in the search box for a search. The Certificate Authority Service supports fuzzy search by applicant, CA name, subject or submitted time.

Revoking a certificate

On the **PKI Management** > **Certificate** page, click **Revoke** in the **Operation** column of a certificate to revoke it.

#### **NOTICE**

Only certificates whose revocation reason is "Certificate is on hold" can have their revocation canceled. Certificates revoked for other reasons can no longer be trusted.

- Canceling certificate revocation
  - On the **PKI Management** > **Certificate** page, click **Undo Revoke** in the **Operation** column of a certificate to cancel its revocation.
- Downloading a certificate
  - On the Certificate Application > Application List page, click Download Certificate in the Operation column of a certificate to download it to the local computer.

#### □ NOTE

- When downloading a certificate that is requested by entering basic
  information, you need to enter a password. The password is a string of 8 to
  32 characters containing at least three of the following: digits, uppercase
  letters, lowercase letters, and special characters. In addition, the password
  cannot contain two or more of the same characters consecutively.
- Only successfully obtained certificates can be downloaded.
- On the PKI Management > Certificate page, click Download in the Operation column of a certificate, enter the file name and password, and download the certificate to the local computer.

#### 

- The file name is a string of 1 to 20 characters containing uppercase letters, lowercase letters, digits, hyphens (-), and underscores (\_).
- When downloading a certificate that is requested by entering basic information, you need to enter a password. The password is a string of 8 to 32 characters containing at least three of the following: digits, uppercase letters, lowercase letters, and special characters. In addition, the password cannot contain two or more of the same characters consecutively.

#### 4.3.2.5.3 Application Method 3: Applying Through Dual Certificates

Certificate Authority Service supports dual-certificate certificate application.

#### Context

Dual certificates refer to the signature certificate and encryption certificate, which are used to establish TLS connections.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Certificate Application** > **Certificate Application** from the navigation tree on the left.
- **Step 3** On the **Apply by Dual-Certificate** tab page, enter certificate application information.

For detailed parameter descriptions, see **Table 4-14**.

**Table 4-14** Dual-certificate parameters

	meter	<b>Description</b>	Value
Associated CA		Associated CA used to apply for a certificate from the CA.	N/A
Appli	cant	You can customize the name of a applicant to distinguish different applicants.	N/A
Sig nat ure	Signature certificate profile	Signature certificate profile, which is used to issue the signature certificate.	N/A
cert ific ate	CSR file	Certificate signing request.	<ul> <li>The certificate chain file to be uploaded must be in .csr, .txt, or .req format.</li> <li>Only one file can be uploaded and the file size cannot exceed 100 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> <li>The subject information in the CSR file must be different from that of the associated CA. Otherwise, certificate application fails.</li> </ul>
Enc rypt ion cert ific ate	Subject info is consisten t with signature certificate 's info	<ul> <li>If this option is selected, the subject information is the same as that of the signature certificate.</li> <li>If this option is not selected, you need to enter the subject information configured in the profile after selecting an encryption certificate profile.</li> </ul>	N/A
	Encryptio n certificate profile	Encryption certificate profile used to issue the encryption certification.	Only the profile of a certificate with the <b>End entity</b> level can be selected.

#### Step 4 Click Submit.

----End

#### **Related Tasks**

Viewing a certificate

On the **PKI Management** > **Certificate** page, click the SN of a certificate to view the certificate details.

A certificate will be automatically deleted 30 days after it expires. If the number of certificates issued by the Certificate Authority Service exceeds 80% of the maximum number supported by the Certificate Authority Service, all expired certificates are automatically deleted.

• Updating a certificate

On the **PKI Management** > **Certificate** page, click **Update** in the **Operation** column of a certificate to update it. After the certificate is updated, you can choose whether to download the certificate to the local computer.

The certificate obtained by using CMP, privacy CA protocol or uploading the CSR file cannot be updated.

• Searching for a certificate

On the **PKI Management** > **Certificate** page, enter the subject name of the certificate in the search box for a search. You can also specify the SN, validity period, revocation reason, issuer or status of the certificate in **Advanced Search**. The Certificate Authority Service supports fuzzy search by subject name, SN, validity period or issuer.

On the **Certificate Application** > **Application List** page, enter the applicant, CA name, subject or submitted time of the certificate in the search box for a search. The Certificate Authority Service supports fuzzy search by applicant, CA name, subject or submitted time.

Revoking a certificate

On the **PKI Management** > **Certificate** page, click **Revoke** in the **Operation** column of a certificate to revoke it.

#### **NOTICE**

Only certificates whose revocation reason is "Certificate is on hold" can have their revocation canceled. Certificates revoked for other reasons can no longer be trusted.

Canceling certificate revocation

On the **PKI Management** > **Certificate** page, click **Undo Revoke** in the **Operation** column of a certificate to cancel its revocation.

- Downloading a certificate
  - On the Certificate Application > Application List page, click Download Certificate in the Operation column of a certificate to download it to the local computer.

#### 

- When downloading a certificate that is requested by entering basic information or using dual certificates, you need to enter a password. The password is a string of 8 to 32 characters containing at least three of the following: digits, uppercase letters, lowercase letters, and special characters. In addition, the password cannot contain two or more of the same characters consecutively.
- Only successfully obtained certificates can be downloaded.
- On the PKI Management > Certificate page, click Download in the Operation column of a certificate, enter the file name and password, and download the certificate to the local computer.

#### 

- The file name is a string of 1 to 20 characters containing uppercase letters, lowercase letters, digits, hyphens (-), and underscores (\_).
- When downloading a certificate that is requested by entering basic
  information or using dual certificates, you need to enter a password. The
  password is a string of 8 to 32 characters containing at least three of the
  following: digits, uppercase letters, lowercase letters, and special characters. In
  addition, the password cannot contain two or more of the same characters
  consecutively.

# 4.3.2.6 Configuring a CRL Server

If you want to publish the CRL corresponding to a CA to a specified CRL server, you can configure information about the CRL server on the CRL management page.

#### Context

The Certificate Authority Service supports manual and automatic CRL publishing.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **PKI Management** > **CRL** from the navigation tree on the left.
- **Step 3** On the **CRL Server** tab page, click **New** and set parameters.

For detailed parameter descriptions, see Table 4-15.

**Table 4-15** CRL server parameters

Parameter	Description	Value
Label	Name of a CRL server.	The name is a string of 1 to 45 characters containing letters, digits, underscores (_), and hyphens (-).
		The name cannot be <b>null</b> or <b>all</b> (case insensitive).

Parameter	Description	Value
IP address	IP address of the server.	N/A
Protocol	Type of the CRL server, which can be LDAP or FTP.  A maximum of five servers can be added regardless of the server type.  NOTICE  LDAP is recommended because of its higher security than FTP.	N/A
Use TLS	Whether to publish the CRL to the LDAP server or FTP server using TLS.  NOTE  If you select Yes, you can import the CRL corresponding to the trusted certificate chain on the CRL Server tab page to check whether the peer server certificate has been revoked.  If you select No, you cannot import the CRL on the CRL Server tab page.  NOTICE  If you do not use the TLS protocol, a security risk may exist.	The default value is <b>Yes</b> .
Port	Port number of the server.	<ul> <li>The port number is an integer ranging from 1 to 65535.</li> <li>If the LDAP is selected and the TLS protocol is not used, the default port number is 389.</li> <li>If the LDAP is selected and the TLS protocol is used, the default port number is 636.</li> <li>When the FTP is selected, the default port number is 21.</li> <li>NOTICE         <ul> <li>LDAP is recommended because of its higher security than FTP.</li> </ul> </li> </ul>

Parameter	Description	Value
Login name	User name for logging in to the server.	The login name is a string 1 to 128 characters and cannot contain the following special characters: (/\: *?" <> ).
Login password	Password for logging in to the server.	It is recommended that the password contain 6 to 64 characters, including at least three types of the following: digits, uppercase letters, lowercase letters, and special characters. The password cannot be the same as the login name or the reverse of the login name.

Parameter	Description	Value
Publication directory	Directory of the server to which the CRL is published. You can use parameters such as File path or  Distinguished name generated by the system to interconnect with the CRL server of the Certificate Authority Service.  • The publication directory of the FTP server is userdefined, for example, a/b. After a CRL server is created, the system generates a file path in format of FTP root directory/ Publication directory/ Publication directory/ CA name associated with the server/ CRL file name, where the CRL file name is the CA name and the file name extension is .crl. For example, the file path can be /home/ftpuser/a/b/caname/caname.crl.	N/A
	• The publication directory of the LDAP server is the LDAP path name, for example, CN=common name, O=organization, OU=organization unit.  After a CRL server is created, the system generates a distinguished name in format of CN=CA name associated with the server, Publishing directory. For example, the distinguished name can be CN=caname, CN=common name, O=organization, OU=organization unit.	

Parameter	Description	Value
Trust certificate chain	Local certificate chain file.  NOTICE  If the RSA key length is 1024 or the uploaded trust certificate uses the SHA1withRSA algorithm, security risks exist.	<ul> <li>The certificate file must be in .pem, .cer, or .crt format.</li> <li>The certificate to be uploaded must be a complete certificate chain. A maximum of 10 files can be uploaded, and the size of a single file cannot exceed 100 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing</li> </ul>
		Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.

#### Step 4 Click Submit.

----End

#### **Related Tasks**

Viewing a CRL server

On the **CRL Server** tab page under **PKI Management** > **CRL**, click the name of a CRL server to view detailed information about this CRL server.

Modifying a CRL server

On the **CRL Server** tab page under **PKI Management** > **CRL**, click **Modify** in the **Operation** column of a CRL server to modify the configuration of this CRL server.

Deleting a CRL server

On the **CRL Server** tab page under **PKI Management** > **CRL**, click **Delete** in the **Operation** column of a CRL server to delete this CRL server.

• Importing a CRL

On the **CRL Server** tab page under **PKI Management** > **CRL**, click **Import CRL** in the **Operation** column of a CRL server to upload the CRL of the trusted certificate chain for checking whether the peer server certificate is revoked.

■ NOTE

The CRL file to be uploaded must be in .crl or .pem format and the file size cannot exceed 2 MB.

Updating a CRL

On the **CRL** tab page under **PKI Management** > **CRL**, click **Update** in the **Operation** column of a CRL to manually update the CRL.

Manually publishing a CRL

On the **CRL** tab page under **PKI Management** > **CRL**, click **Publish** in the **Operation** column of a CRL to manually publish the CRL.

Automatically publishing a CRL

When configuring a CA on the **PKI Management** > **CA** page, you can set an interval for automatically publishing CRLs. Then the system automatically publishes CRLs at the specified interval.

Searching for a CRL

On the CRL tab page under PKI Management > CRL, enter a CR name, click

, and view CRL information of the CA that is searched out. The Certificate Authority Service supports fuzzy search by CA name.

Downloading a CRL

On the **CRL** tab page under **PKI Management** > **CRL**, click **Download** in the **Operation** column of a CRL to download the CRL in DER or PEM format to the local computer.

# 4.3.2.7 Configuring a Whitelist

You can configure a whitelist to verify certificate requests. If the common name is in the whitelist, the requests are allowed. Otherwise, the requests are rejected.

#### Context

If the whitelist verification function is enabled, a certificate can be successfully obtained only when the common name is in the whitelist after a user submits a certificate request.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **PKI Management** > **Whitelist** from the navigation tree on the left.
- **Step 3** Click **New**. The **Create Whitelist** dialog box is displayed.
- **Step 4** Enter the whitelist information.

#### ■ NOTE

- Common name: Mandatory. The common name is a string of 1 to 127 characters containing uppercase letters, lowercase letters, digits, spaces, hyphens (-), colons (:), and dots (.).
- Description: optional. The description is a string of 0 to 128 characters containing digits, uppercase letters, lowercase letters, spaces, and special characters (,.?!:;).
- You can click **Reset** to clear parameter settings.

#### Step 5 Click Submit.

----End

#### **Related Tasks**

Enabling whitelist verification

Choose **Protocol Configuration** > **CMP**. On the **Protocol Configuration** tab page, click **Modify** corresponding to a CA. On the page that is displayed, set **Verify Whitelist** to **Yes**.

#### 

- By default, the whitelist verification function is disabled.
- The whitelist verification function takes effect only when you apply for a certificate using CMP.
- Modifying a whitelist

Choose **PKI Management** > **Whitelist**. Click **Modify** corresponding to the desired whitelist and modify it.

Importing a whitelist

Choose **PKI Management** > **Whitelist**. Click **Import** to manually import a whitelist.

#### ∩ NOTE

- You can download the template file, set parameters following the instructions, and upload the file.
- The file to be uploaded must be in .csv format and the size of a single file cannot exceed 20 MB. The file can contain a maximum of 4 million data records, but a maximum of 50,000 records can be imported at a time.
- Deleting a whitelist

Choose **PKI Management** > **Whitelist**. Select the whitelist to be deleted and click **Delete** or click **Delete** corresponding to the whitelist.

Searching for a whitelist

Choose **PKI Management** > **Whitelist**. In the search box, enter a common name and click to search for a specific whitelist. The Certificate Authority Service supports fuzzy search by whitelist name.

# 4.3.2.8 Configuring CMP

When applying for a certificate using CMP, you need to configure CMP information, request verification, and response protection for data encryption.

# 4.3.2.8.1 Configuring CMP Information

To apply for a certificate using CMP, you need to first configure CMP information.

#### **Prerequisites**

- In the non-multi-tenant deployment scenarios, if the port used by the CMP is not enabled, you need to enable the port on the Certificate Authority
   Service > Global Configuration > Port Management page.
- In the multi-tenant deployment scenarios, if the port used by the CMP is not enabled, the system administrator needs to enable the port on the **Certificate Authority Service** > **Global Configuration** > **Port Management** page.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Protocol Configuration** > **CMP** from the navigation tree on the left.
- **Step 3** On the **Protocol Configuration** tab page, click **Modify** corresponding to a CA. On the page that is displayed, set required parameters.

For detailed parameter descriptions, see **Table 4-16**.

**Table 4-16** CMP parameters

Parameter	Description	Value
CA	Name of a CA.	The CA name cannot be changed.
Protocol	You can select HTTP, one-way authentication, or two-way authentication.  NOTE  HTTPS is more secure than HTTP. Therefore, you are advised to select HTTPS (One-way authentication or Two-way authentication) when configuring CMP.	The default value is <b>two-way</b> authentication.
Port	Port number.  If the selected port is disabled, the message "The port is disabled." is displayed. You cannot apply for a certificate using this port.	<ul> <li>When HTTP is selected, the default port number is 26801 and cannot be changed.</li> <li>When one-way authentication is selected, the default port number is 26802 and cannot be changed.</li> <li>When two-way authentication is selected, the default port number is 26803 and cannot be changed.</li> </ul>
Version	TLS version corresponding to one-way authentication and two-way authentication.	By default, <b>TLSv1.2</b> and <b>TLSv1.3</b> are selected and cannot be modified.
Send CA certificate	Whether to send the CA certificate to the terminal.	The default value is <b>Yes</b> .
Send responder certificate	Whether to send the response protection certificate to the terminal.	The default value is <b>Yes</b> .

Parameter	Description	Value
Return certificate chain	Whether to return the certificate chain to the terminal.	The default value is <b>Yes</b> .
Verify whitelist	Whether to enable the whitelist verification function.  NOTE  If this parameter is set to Yes, the Certificate Authority Service enables the whitelist verification function. When you apply for a certificate from the Certificate Authority Service using CMP, the certificate can be successfully applied only when the common name is in the whitelist.  If this parameter is set to No, the Certificate Authority Service does not enable the whitelist verification function.	The default value is <b>No</b> .
Request time required	Checks whether the time in the certificate application request is the same as the current time.  NOTE  If this parameter is set to Yes, the certificate application request must contain this parameter. The Certificate Authority Service checks whether the value of this parameter is within the Allowed message time deviation range.  If this parameter is set to No, the certificate application request does not need to contain this parameter. If the certificate application request contains this parameter, the Certificate Authority Service checks whether the value of this parameter is within the Allowed message time deviation range.	The default value is <b>No</b> .

Parameter	Description	Value
Use the validity period from CMP request	Whether to use the validity period in the CMP request packet when applying for a certificate.  NOTE  If you select Yes, the validity period of a certificate is the intersection of the following four validity periods: validity period of the CA associated with the certificate, validity period set in the certificate profile, validity period set in the associated CA, and validity period set in the CMP request.  If you select No, the validity period of a certificate is the intersection of the following three validity periods: validity period of the CA associated with the certificate, validity	The default value is <b>No</b> .
	period set in the certificate profile, and validity period set in the associated CA.	
Use CA for responder	Whether to use the CA to protect messages sent to terminals.  NOTE  If this parameter is set to Yes, the CA is used for response protection. You do not need to set response protection on the Responder Configuration tab page.	The default value is <b>Yes</b> .
Allowed message time deviation	The Certificate Authority Service checks whether the deviation between the time in the certificate application request and the current time is within the allowed time deviation range.	The value is an integer ranging from 1 to 3600, in seconds.
Use asynchronous polling	After a terminal sends a certificate application request to the CA, the CA generates a certificate in asynchronous mode. The terminal must periodically and continuously send polling messages to check whether the CA has issued the certificate.	The default value is <b>No</b> .

Parameter	Description	Value
Polling interval	Polling interval of the terminal.	The value is an integer ranging from 1 to 3600, in seconds.
Certificate confirmation waiting time	Time after which the CA revokes the certificate if the end entity receiving the certificate does not send a certificate confirmation packet to the CA, when the certificate application request is explicitly acknowledged.	The value is an integer ranging from 1 to 3600, in seconds.
Message protection signature algorithm	Signature algorithm to be used. If the signature algorithm used by the terminal is not selected, the CA rejects the request sent by the terminal.	N/A
POP signature algorithm	Required signature algorithm. It is used to check whether the public key submitted by the terminal has a corresponding private key.	N/A

Parameter	Description	Value
Parameter  CMP request URI	A user applies for a certificate from the Certificate Authority Service using CMP. The CMP request URI has the following two formats:  • The request URI contains the name of the CA that issues the certificate and the name of the used certificate profile, for example, https://{IP}:  26802/cmp/caname?  certprofile=profilename, where caname is the name of the CA that issues the certificate, and profilename is the name of the used certificate profile.  • The request URI contains only the name of a CA that issues the certificate and does not contain the profile name parameter. The default profile of the CA is used for certificate	The CMP request URI cannot be modified.
	application. An example of this request is https://{IP}: 26802/cmp/caname, where caname is the name of the CA that issues the certificate.	

#### Step 4 Click Submit.

----End

# Follow-up Procedure

Applying for a certificate based on the CMP request URI

On the **Protocol Configuration** > **CMP** page, click the **Protocol Configuration** 

tab. On this tab page, click on the left of a CA name, and copy the CMP request URI corresponding to the CA for use. The CMP request URIs include the following types:

HTTP

- http://*IP address*:26801/cmp/*CA name* 

- http://IP address.26801/cmp/CA name?certprofile=Certificate profile name
- One-way authentication
  - https://IP address.26802/cmp/CA name
  - https://IP address.26802/cmp/CA name?certprofile=Certificate profile name
- Two-way authentication
  - https://IP address.26803/cmp/CA name
  - https://IP address.26803/cmp/CA name?certprofile=Certificate profile name

For example, http://IP address:26801/cmp/caname?certprofile=profilename indicates that a CMP request for applying for a certificate is sent to the Certificate Authority Service through HTTP. In the URL, the IP address indicates the IP address of the Certificate Authority Service.

#### 

- The certprofile parameter specifies the end entity profile used for issuing certificates.
   This parameter is optional. If this parameter is not specified, the default CA profile is used for certificate application.
- A CA may be associated with multiple profiles. Therefore, the CMP request URI may have multiple values. Select a value based on the site requirements.
- The subject information in the certificate application request must be different from that of the associated CA. Otherwise, certificate application fails.

#### **Related Tasks**

- Viewing CMP configuration
   Choose Protocol Configuration > CMP. On the Protocol Configuration tab
   page, click on the left of a CA name to access the details page, where you can check the CMP configuration.
- Searching for CMP configuration
   Choose Protocol Configuration > CMP. On the Protocol Configuration tab
   page, enter a CA name in the search box, and click to find the specified
   CA and view the detailed protocol configuration of the CA. The Certificate
   Authority Service supports fuzzy search by CA name.

#### 4.3.2.8.2 Configuring Request Verification

Request verification protects request messages send by terminals to a CA.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Protocol Configuration** > **CMP** from the navigation tree on the left.
- **Step 3** On the **Requestor Configuration** tab page, click **Add**. On the **Add Requestor Configuration** page, set required parameters.

For detailed parameter descriptions, see **Table 4-17**.

**Table 4-17** Request verification parameters

Parameter	Description	Value
Label	Name of a request verification certificate.	The value can contain only digits, letters, underscores (_), and hyphens (-), but cannot be <b>null</b> or <b>all</b> (caseinsensitive).

Parameter			Description	Value
Aut he nti cat ion mo de	Cert ifica te	Certificate configuration mode	<ul> <li>Upload vendor root CA certificate: Uses the vendor root CA certificate to verify the validity of the signature certificate and certificate chain in the CMP packet. In this mode, you need to upload the vendor certificate and select the associated CA. Obtain the vendor root CA certificate by referring to the method provided by the supplier.</li> <li>New self-signed certificate: If the identity certificate and private key are not available, you can use this method to generate a self-signed certificate using the Certificate Authority Service. Once downloaded, this certificate can be used to sign the CMP request packet. The Certificate Authority Service uses the certificate to verify the validity of the request. In this mode, you need to select the root CA certificate profile, signature algorithm, and associated CA.</li> <li>Upload obtained identity certificate: If an identity certificate is obtained and the private key of this certificate is used to sign the CMP request packet, you can use this method to upload the identity certificate to the CA server to verify the validity of the request. In this mode, you need to upload the identity</li> </ul>	<ul> <li>The vendor root certificate to be uploaded must be in .cer, .crt, .p7b, or .pem format. Only one file can be uploaded and the file size cannot exceed 100 KB. The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> <li>The obtained identity certificate to be uploaded must be in .cer or .crt format. Only one file can be uploaded and the file size cannot exceed 10 KB. The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> <li>One request verification can be associated with a maximum of 32 CAs.</li> </ul>

Para	Parameter		Description	Value
			certificate and select the associated CA.	
	Pre- shar ed key	Pre- share d key	When a user uses a preshared key to protect CMP request messages, the same pre-shared key must be configured on the CA. The CA uses the pre-shared key to authenticate request messages and protect response messages.	The password must be a string of 8 to 128 characters that contain at least three types of the following: digits, uppercase letters, lowercase letters, and special characters. In addition, the password cannot contain three or more of the same characters consecutively.
		Associ ated CA	Select an associated CA and configure the request verification to verify the validity of the certificate request of the CA.	One request verification can be associated with a maximum of 32 CAs.

#### Step 4 Click Submit.

----End

#### **Related Tasks**

Viewing request verification information

Choose **Protocol Configuration** > **CMP**. On the **Requestor Configuration** tab page, click a request verification name. On the page that is displayed, you can view the detailed information.

Searching for request verification information

Choose Protocol Configuration > CMP. On the Requestor Configuration tab

page, enter a request verification name in the name search box and click to find the specified request verification and view the details. The Certificate Authority Service supports fuzzy search by request verification name.

Modification request verification

Choose **Protocol Configuration** > **CMP**. On the **Requestor Configuration** tab page, click **Modify** corresponding to the desired request verification. On the page that is displayed, modify request verification information.

□ NOTE

The request verification name cannot be changed.

Deleting request verification

Choose **Protocol Configuration** > **CMP**. On the **Requestor Configuration** tab page, click **Delete** corresponding to the desired request verification.

Downloading a request verification certificate

Choose **Protocol Configuration** > **CMP**. On the **Requestor Configuration** tab page, click **Download** corresponding to the desired request verification to download the request verification certificate.

#### **Ⅲ** NOTE

- The password is a string of 8 to 32 characters containing at least three of the following: digits, uppercase letters, lowercase letters, and special characters. In addition, the password cannot contain two or more of the same characters consecutively.
- The downloaded request verification certificate is in .p12 format. The password is contained in the .p12 file. Enter the password for verification when using a certificate file in .p12 format.
- You can download the request verification certificate only when the signature type is self-signed.

#### 4.3.2.8.3 Configuring Response Protection

Response protection protects response messages sent by a CA to terminals.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Protocol Configuration** > **CMP** from the navigation tree on the left.
- **Step 3** On the **Responder Configuration** tab page, click **Add**. On the **Add Responder Configuration** page, set required parameters.

For detailed parameter descriptions, see Table 4-18.

**Table 4-18** Response protection parameters

Parameter	Description	Value
Label	Name of a response protection certificate.	The value can contain only digits, letters, underscores (_), and hyphens (-), but cannot be <b>null</b> or <b>all</b> (caseinsensitive).

Parame	eter	Description	Value
Certifi cate config uratio n mode	New self- signed certificate	If no response verification certificate is available, you can use this method to generate a self-signed certificate using the Certificate Authority Service, and the private key of this certificate is used to sign the response. Once downloaded, this certificate can be used to verify the integrity of the CMP response.  In this mode, you need to select the root CA certificate profile, signature algorithm, and associated CA.	N/A
	Upload certificate file	If a response signature certificate is obtained, you can use this method to import the certificate and private key to the Certificate Authority Service. The Certificate Authority Service uses the private key to sign the response, and you can use the certificate to verify the integrity of the response.  In this mode, you need to upload a certificate file, enter the password of the matching certificate, and select the signature algorithm and associated CA.	<ul> <li>The certificate file to be uploaded must be in .p12 format. Only one file can be uploaded and the file size cannot exceed 20 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> </ul>

Step 4 Click Submit.

----End

# **Related Tasks**

• Viewing response protection information

Choose **Protocol Configuration** > **CMP**. On the **Responder Configuration** tab page, click a response protection name. On the page that is displayed, you can view the detailed information.

• Searching for response protection information

Choose **Protocol Configuration** > **CMP**. On the **Responder Configuration** tab page, enter a response protection name in the name search box and click

to find the specified response protection and view the details. The Certificate Authority Service supports fuzzy search by response protection name

• Modifying response protection information

Choose **Protocol Configuration** > **CMP**. On the **Responder Configuration** tab page, click **Modify** corresponding to the desired response protection. On the page that is displayed, modify response protection information.

The response protection name cannot be changed.

Deleting response protection

Choose **Protocol Configuration** > **CMP**. On the **Responder Configuration** tab page, click **Delete** corresponding to the desired response protection.

Downloading a response protection certificate

Choose **Protocol Configuration** > **CMP**. On the **Responder Configuration** tab page, click **Download** corresponding to the desired response protection to download the response protection certificate.

∩ NOTE

The downloaded response protection certificate file is in .pem format.

# 4.3.2.9 Configuring the Privacy CA Protocol

Before applying for a certificate using the Privacy CA protocol, you need to configure the EK trust certificate or pre-shared password in advance.

# 4.3.2.9.1 Configuring Privacy CA Protocol Information

To apply for a certificate using the privacy CA protocol, you need to first configure privacy CA protocol information.

# **Prerequisites**

- In the non-multi-tenant deployment scenarios, if the port used by the privacy CA protocol is not enabled, you need to enable the port on the Certificate Authority Service > Global Configuration > Port Management page.
- In the multi-tenant deployment scenarios, if the port used by the privacy CA protocol is not enabled, the system administrator needs to enable the port on the Certificate Authority Service > Global Configuration > Port Management page.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Protocol Configuration > Privacy CA Protocol** from the navigation tree on the left.

**Step 3** On the **Protocol Configuration** tab page, click **Modify** corresponding to a CA. On the page that is displayed, set required parameters. For detailed parameter descriptions, see **Table 4-19**.

**Table 4-19** Privacy CA protocol parameters

Parameter	Description	Value
CA	Name of a CA.	The CA name cannot be changed.
Port	Port number corresponding to the privacy CA protocol.	The default value is 26805 and cannot be changed.
Use the validity period in the privacy CA request	Whether to use the validity period in the privacy CA request when applying for a certificate.  NOTE  If you select Yes, the validity period of a certificate is the intersection of the following four validity periods: validity period of the CA associated with the certificate, validity period set in the certificate profile, validity period set in the associated CA, and validity period set in the CMP request.  If you select No, the validity period of a certificate is the intersection of the following three validity periods: validity	The default value is Yes.
	period of the CA associated with the certificate, validity period set in the certificate profile, and validity period set in the associated CA.	
Challenge value expiration time	A user sends a challenge value request to the Certificate Authority Service through the privacy CA protocol. If the Certificate Authority Service does not receive the certificate application request within the specified time, the challenge value expires and the verification fails. As a result, the Certificate Authority Service cannot issue the AK certificate.	The default value is 60 and cannot be changed. The unit is minute.

Parameter	Description	Value
Privacy CA protocol request URI	A user applies for a certificate from the Certificate Authority Service using the privacy CA protocol. The privacy CA protocol request URI has the following two formats:  • The request URI contains the name of the CA that issues the certificate and the name of the used certificate profile, for example, https://{IP}: 26805/pca/v1/caname? certprofile=profilename, where v1 is the API version, caname is the name of the CA that issues the certificate, and profilename is the name of the used certificate profile.  • The request URI contains only the name of a CA that issues the certificate and does not contain the profile name parameter. The default profile of the CA is used for certificate application. An example of this request is https://{IP}: 26805/pca/v1/caname, where v1 is the API version and caname is the name of the CA that issues the certificate.	The privacy CA protocol request URI cannot be changed.

#### **Step 4** Click Submit.

----End

# Follow-up Procedure

Applying for a certificate based on the privacy CA request URI

Choose Protocol Configuration > Privacy CA Protocol. On the Protocol

**Configuration** tab page, click on the left of a CA name, and copy the privacy CA request protocol URI of the CA for use.

One-way authentication

- https://*IP address*.26805/pca/v1/*CA name*
- https://IP address:26805/pca/v1/CA name?certprofile=Certificate profile name

For example, https://IP address.26805/pca/v1/caname?certprofile=profilename indicates that a privacy CA request for certificate application is sent to the Certificate Authority Service through the one-way TLS authentication protocol. In the URL, the IP address indicates the IP address of the Certificate Authority Service.

#### 

- The **certprofile** parameter specifies the end entity profile used for issuing certificates. This parameter is optional. If this parameter is not specified, the default CA profile is used for certificate application.
- A CA may be associated with multiple profiles. Therefore, the privacy CA protocol request URI may have multiple values. Select a value based on the site requirements.
- The subject information in the certificate application request must be different from that of the associated CA. Otherwise, certificate application fails.

#### **Related Tasks**

- Viewing privacy CA protocol configuration
   Choose Protocol Configuration > Privacy CA Protocol. On the Protocol
   Configuration tab page, click on the left of a CA name to view the privacy CA protocol details.
- Searching for privacy CA protocol configuration
   Choose Protocol Configuration > Privacy CA Protocol. On the Protocol
   Configuration tab page, enter a CA name in the search box, and click to find the specified CA and view the detailed protocol configuration of the CA. The Certificate Authority Service supports fuzzy search by CA name.

# 4.3.2.9.2 Configuring the EK Trust Certificate

You need to configure the EK trust certificate when applying for an AK certificate.

#### Context

If the EK certificate is preinstalled on the device, a user uses the RA client to send a challenge value request to the Certificate Authority Service using the privacy CA protocol and import the EK trust certificate chain. The request contains the public AK and EK certificate. After receiving the request, the Certificate Authority Service verifies the public AK information and uses the imported EK trust certificate chain to verify the EK certificate. If the verification is successful, the Certificate Authority Service returns the encrypted challenge value. The user then uses the RA client to send a certificate application request to the Certificate Authority Service using the privacy CA protocol. The request contains the CA name, certificate profile name, subject information, and challenge value. After receiving the request, the Certificate Authority Service checks whether the challenge value has expired and verifies the public AK information. If the verification is successful, the Certificate Authority Service issues the AK certificate.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Protocol Configuration** > **Privacy CA Protocol** from the navigation tree on the left.
- **Step 3** On the **EK Trust Certificate Configuration** tab page, click **Add** and set the parameters required for the EK trust certificate.

For detailed parameter descriptions, see Table 4-20.

Table 4-20 EK trust certificate parameters

Parameter	Description	Value
Label	You can customize the name of the EK trust certificate to distinguish different certificate files.	The value must be a string of 1 to 45 characters, including digits, letters, underscores (_), and hyphens (-). The value cannot be <b>null</b> or <b>all</b> (caseinsensitive).
EK trust certificate	Select the local EK trust certificate file and upload it to verify the request of certificate application through the privacy CA protocol.	The EK trust certificate file to be uploaded must be in .cer, .crt, or .pem format. A maximum of 10 files can be uploaded at a time, and the total file size cannot exceed 100 KB.
		• The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.

**Step 4** After the configuration is complete, click **Submit**. On the **EK Trust Certificate Configuration** tab page, you can view the configured EK trust certificate file.

----End

#### **Related Tasks**

Viewing an EK trust certificate
 Choose Protocol Configuration > Privacy CA Protocol. On the EK Trust
 Certificate Configuration tab page, click on the left of an EK trust certificate name to view its details.

Searching for an EK trust certificate

Choose **Protocol Configuration** > **Privacy CA Protocol**. On the **EK Trust Certificate Configuration** tab page, enter the name of an EK trust certificate

in the search box, and click \( \bigcirc\) to find the specified certificate and view its details. The Certificate Authority Service supports fuzzy search by the name of the EK trust certificate.

Deleting an EK trust certificate

Choose **Protocol Configuration** > **Privacy CA Protocol**. On the **EK Trust Certificate Configuration** tab page, click **Delete** on the right of an EK trust certificate to delete it.

#### 4.3.2.9.3 Configuring a Pre-Shared Password

You need to set a pre-shared password when applying for the EK certificate.

#### Context

If the EK certificate is not preinstalled on the device before delivery, the user uses the privacy CA protocol to send a challenge value request to the Certificate Authority Service through the remote attestation client, and sets a pre-shared password on the Certificate Authority Service and remote attestation client for message authentication. A user logs in to the remote attestation client, and uses the privacy CA protocol to send a certificate application request to the Certificate Authority Service. The request contains information, such as the CA name, certificate profile name, subject information, and challenge value. After obtaining the request, the Certificate Authority Service checks whether the challenge value has expired and verifies the AK public key information. If the verification is successful, the Certificate Authority Service issues the EK certificate.

A user uses the RA client to send a challenge value request to the Certificate Authority Service using the privacy CA protocol and import the EK trust certificate chain. The request contains the public AK and EK certificate. After receiving the request, the Certificate Authority Service verifies the public AK information and uses the imported EK trust certificate chain to verify the EK certificate. If the verification is successful, the Certificate Authority Service returns the encrypted challenge value. The user then uses the RA client to send a certificate application request to the Certificate Authority Service using the privacy CA protocol. The request contains the CA name, certificate profile name, subject information, and challenge value. After receiving the request, the Certificate Authority Service checks whether the challenge value has expired and verifies the public AK information. If the verification is successful, the Certificate Authority Service issues the AK certificate.

#### Procedure

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Protocol Configuration** > **Privacy CA Protocol** from the navigation tree on the left.
- **Step 3** On the **Pre-Shared Password Configuration** tab page, click **Add** and set the parameters required for the pre-shared password.

For detailed parameter descriptions, see Table 4-21.

cannot contain three or more of the same

characters consecutively.

• A maximum of 16 preshared passwords can be

configured.

N/A

**Parameter** Description Value Label You can customize the name The name is a string of 1 to of a pre-shared password to 45 characters containing distinguish different letters, digits, underscores (), passwords. and hyphens (-). The name cannot be null or all (case insensitive). Pre-shared Customize a pre-shared • The password must be a password password for message string of 12 to 128 integrity protection and characters that contain at identity authentication during least three types of the message authentication. following: digits, uppercase letters, lowercase letters, and special characters. In addition, the password

**Table 4-21** Pre-shared password parameters

**Step 4** After the configuration is complete, click **Submit**.

Select an associated CA and

configure the pre-shared password for verifying the

challenge request.

----End

Associated CA

#### **Related Tasks**

• Searching for the pre-shared password

Choose **Protocol Configuration** > **Privacy CA Protocol**. On the **Pre-Shared Password Configuration** tab page, enter a pre-shared password name in the

search box and click to find the pre-shared password. The Certificate Authority Service supports fuzzy search by pre-shared password name.

Modifying the pre-shared password

Choose **Protocol Configuration** > **Privacy CA Protocol**. On the **Pre-Shared Password Configuration** tab page, click **Modify** on the right of the pre-shared password to change the pre-shared password.

Deleting the pre-shared password

Choose **Protocol Configuration** > **Privacy CA Protocol**. On the **Pre-Shared Password Configuration** tab page, click **Delete** on the right of the pre-shared password to delete the pre-shared password.

# 4.3.2.10 Global Configuration

On the **Global Configuration** page, you can configure the CMP port status or privacy CA protocol port status and TLS certificate.

## 4.3.2.10.1 Configuring a Port

On the **Port Management** page, you can view the current port status and manually enable or disable the HTTP port, TLS one-way authentication port, TLS two-way authentication port or privacy CA protocol port.

#### **Context**

- In the multi-tenant deployment scenario, you need to contact the administrator to configure a port.
- For details about the port description, see **Table 4-22**.

Table 4-22 Port parameters

Protocol	Port	Description
CMP 26801 HTTP port. After the port is enabled, you can the CMP to apply for a certificate.		HTTP port. After the port is enabled, you can use the CMP to apply for a certificate.
		NOTE HTTPS is more secure than HTTP. Therefore, you are advised to select HTTPS (One-way authentication or Two-way authentication) when configuring CMP.
	26802	One-way TLS authentication port. When the CMP is used to apply for a certificate, the client needs to authenticate the CA server.
	26803	Two-way TLS authentication port. When the CMP is used to apply for a certificate, the client and CA server must authenticate each other.
Privacy CA protocol	26805	One-way TLS authentication port. When the privacy CA protocol is used to apply for a certificate through this port, the client needs to authenticate the CA server.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Global Configuration** > **Port Management** from the navigation tree on the left.
- **Step 3** Enable or disable a port as required.
  - Click Enable to enable the port.
  - Click **Disable** to disable the port.

#### □ NOTE

- After the port is disabled and the HiSecLiteCA service is restarted, the certificate cannot be applied for through the port. Exercise caution when performing this operation.
- Actual status indicates the real status of the port on the CA server. If **Enable** is displayed, the port is enabled and can be used to apply for a certificate. If **Disable** is displayed, the port is disabled and cannot be used to apply for a certificate.
- Configured status indicates the required status of the port. If **Enable** is displayed, the port needs to be enabled. If **Disable** is displayed, the port needs to be disabled. After the service is restarted, the system port of the CA server is enabled or disabled based on the port's configured status and TLS certificate configuration.

#### ----End

# Follow-up Procedure

Restarting the Certificate Authority Service

After enabling or disabling a port, you need to restart the HiSecLiteCA service on the PowerEcho for the port configuration to take effect. For detailed operations, see "Stopping Product Services" and "Starting Product Services" in the *Administrator Guide*.

#### □ NOTE

After enabling the TLS one-way or two-way authentication port, you need to configure the corresponding TLS certificate and restart the HiSecLiteCA service on the PowerEcho for the port configuration to take effect.

#### **Related Tasks**

Querying the port status

On the **Global Configuration** > **Port Management** page, you can view the current status of a port in the **Actual Status** column.

#### 4.3.2.10.2 Configuring TLS

When applying for a certificate using CMP or Privacy CA protocol, you can configure a TLS certificate to encrypt messages exchanged.

#### **Context**

- TLS is designed to ensure data confidentiality and integrity between two communication application programs.
- In the multi-tenant deployment scenario, you need to contact the system administrator to configure the TLS certificate.

#### **Procedure**

- **Step 1** Choose **System > About > Certificate Authority Service** from the main menu.
- **Step 2** Choose **Global Configuration** > **TLS Configuration** from the navigation tree on the left.
- **Step 3** Click **Certificate Configuration**. On the page that is displayed, set required parameters.

For detailed parameter descriptions, see **Table 4-23**.

 Table 4-23 TLS certificate parameters

Parameter		Description	Value
Trust certificate chain	Trust certificat e chain	Used by the server to check whether the client certificate is trusted during communication.	<ul> <li>The trust certificate chain file to be uploaded must be in .pem, .cer, or .crt format.</li> <li>The certificate to be uploaded must be a complete certificate chain. A maximum of 16 files can be uploaded, and the size of the file to be uploaded at a time cannot exceed 100 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> </ul>
Identity certificate	Applicati on protocol	The CMP or privacy CA protocol can be used for the identity certificate. Each application protocol corresponds to only one identity certificate.	N/A
	Identity certificat e	Identity certificate of the server, which is verified by the client to determine whether the server is trusted during communication.	<ul> <li>The identity certificate file to be uploaded must be in .p12 format. Only one file can be uploaded and the file size cannot exceed 20 KB.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> </ul>

Parameter		Description	Value
	Certificat e password	Password set for a certificate during certificate application. The password is contained in the .p12 file. You need to enter this password when uploading the certificate file.	N/A
	Upload certificat e chain	Upload the corresponding certificate chain. You can select multiple files. For example, if a level-3 CA certificate is imported, upload the corresponding level-1 and level-2 CA certificates.	<ul> <li>The identity certificate chain file to be uploaded must be a .cer, .crt, or .pem file smaller than 100 KB. A maximum of 10 files can be uploaded.</li> <li>The certificate file name is a string of 1 to 256 characters containing Chinese characters, digits, letters, underscores (_), and hyphens (-), spaces, dots (.) and round brackets. It cannot start with a dots (.) or space.</li> </ul>

#### □ NOTE

If the TLS identity certificate exists, a dialog box is displayed when you select **Identity Certificate** or change the application protocol.

- If you click OK, the current identity certificate will be replaced. If an identity certificate
  issued by another CA is uploaded, the trust certificate of the device must be updated
  accordingly. Otherwise, the TLS connection between the device and the Certificate
  Authority Service fails to be established.
- If you click **Cancel**, the identity certificate will not be replaced.

**Step 4** Upload the trust certificate chain or identity certificate and click **Submit**.

#### □ NOTE

When one-way TLS is selected, you only need to upload the identity certificate. When two-way TLS is selected, you need to upload both the trust certificate chain and identity certificate.

----End

# Follow-up Procedure

Restarting the Certificate Authority Service

After the TLS certificate is uploaded or deleted, restart HiSecLiteCA on the PowerEcho for the TLS configuration to take effect. For detailed operations, see

"Stopping Product Services" and "Starting Product Services" in the *Administrator Guide*.

#### **Related Tasks**

Viewing a TLS certificate

On the **Global Configuration** > **TLS Configuration** page, click the SN of the TLS certificate to view the certificate details.

• Deleting a TLS certificate

On the **Global Configuration** > **TLS Configuration** page, click **Delete** on the right of the TLS certificate to delete the TLS certificate.

Importing a CRL

On the **Global Configuration** > **TLS Configuration** page, click **Import CRL** on the right of the TLS certificate to upload the CRL of the trusted certificate chain for checking whether the peer server certificate is revoked.

#### □ NOTE

The CRL file to be uploaded must be in .crl or .pem format and the file size cannot exceed 2 MB.

• Uploading a TLS certificate chain

On the **Global Configuration** > **TLS Configuration** page, click **Upload Certificate Chain** on the right of the TLS certificate to upload the certificate chain file. You can perform this operation only for TLS identity certificates that are not configured with a certificate chain.

# **5** Operations on the App Client

This section describes the operations on the NetEco app.

#### 5.1 Viewing Device Alarms

You can view the current alarms, historical alarms, and alarm details.

#### 5.2 Viewing Site Monitoring Details

You can view the environment, key devices, alarms, and security protection monitoring details of each site.

# 5.3 Custom Settings

You can set the **Push notifications** function or upgrade the app version as required.

# **5.1 Viewing Device Alarms**

You can view the current alarms, historical alarms, and alarm details.

# **Prerequisites**

You have logged in to the NetEco app.

#### **Procedure**

If You Need To	Then
View current alarms	In the lower part of the home screen, tap <b>Alarm</b> .     By default, all alarms reported by NEs and systems are displayed.
	2. On the <b>Current Alarms</b> tab, view details about the current alarm.
	<ul> <li>In the Alarms area, the total number of current alarms and the number of alarms of each severity are displayed.</li> </ul>
	Click an alarm to view alarm details.
	NOTE  If the Push notifications function is enabled, you can tap an alarm in the message push area on the mobile phone to view the alarm details. For details about how to enable the Push notifications function, see 6.6 How Do I Enable or Disable the Message Push Function.
View historical alarms	In the lower part of the home screen, tap <b>Alarm</b> and select <b>Historical Alarms</b> .
	2. On the <b>Historical Alarms</b> tab, tap an alarm to view the alarm details.
Viewing the pushed alarm list	Tap on a screen.

# **5.2 Viewing Site Monitoring Details**

You can view the environment, key devices, alarms, and security protection monitoring details of each site.

# **Prerequisites**

You have logged in to the NetEco app.

## **Procedure**

**Step 1** On the home screen, tap a site icon.

□ NOTE

to view the site list. To return to the home screen, tap On the home screen, tap on the **Site List** screen.

2022-02-25 282




Figure 5-1 Site monitoring details

**Step 2** On the site screen, perform the following operations as required.

**Table 5-1** Viewing site monitoring details

Task	Operation
Viewing site overview	On the <b>Overview</b> tab, view the basic information about the site and the temperature, humidity, water, and smoke status of the devices in the <b>Environment</b> area.
Viewing device monitoring details	In the <b>Device</b> area, tap a device model to view the real-time monitoring data of the device.

Task	Operation	
Viewing alarm monitoring details	In the lower area, tap the <b>Alarm</b> tab to view the alarm details of the site.	
Viewing security monitoring details	In the lower part of the screen, tap the <b>Security</b> tab to view the door status and video surveillance information of the cabinets in the site.  NOTE	
	<ul> <li>To play a video, tap</li> <li>To play a video in full screen mode, tap</li> </ul>	

----End

## **5.3 Custom Settings**

You can set the **Push notifications** function or upgrade the app version as required.

## **Prerequisites**

You have logged in to the NetEco app.

### **Procedure**

- **Step 1** On the home screen of the NetEco app, tap **Me**.
- **Step 2** On the **Me** screen, perform the following operations as required.

**Table 5-2** Custom settings

Operation	Description	Procedure
Setting the Push notifications function	You can enable or disable the <b>Push notifications</b> function as required.	For details, see 6.6 How Do I Enable or Disable the Message Push Function.
Upgrading the app version	If a new version is detected, you can determine whether to upgrade the app to the new version based on the site requirements.	<ul> <li>Automatic upgrade: If a new version is available, the app displays a dialog box to remind you to upgrade the app.</li> <li>Manual upgrade: Tap <b>Update check</b> to check whether an upgrade is required.</li> </ul>

----End

6 FAQS

This section describes the common faults of the NetEco client, analyzes the possible causes, and provides the solutions.

6.1 How Do I Handle the Problem of Certificate Error or Security Alarm Displayed in the Web Browser

6.2 How Do I Rectify a NetEco-NE Intermittent Disconnection Alarm?

This section describes how to rectify an intermittent disconnection alarm between the NetEco and an NE.

6.3 How Do I Install the Video Surveillance Subsystem Client?

This section describes how to install the video surveillance subsystem client.

6.4 How Do I Add a Camera on the Video Surveillance Subsystem?

Before creating a camera on the NetEco, you need to add the camera to the video surveillance subsystem.

6.5 How Do I Set Video Playback Parameters on the Video Surveillance Subsystem?

A camera can play videos only after video playback parameters are set on the video surveillance subsystem.

6.6 How Do I Enable or Disable the Message Push Function

You can enable or disable the real-time alarm notification function as required.

## 6.1 How Do I Handle the Problem of Certificate Error or Security Alarm Displayed in the Web Browser

## **Symptom**

- When the Google Chrome is used to log in to NetEco the system displays a connection error message as shown in Figure 6-1.
- When the Mozilla Firefox is used to log in to NetEco, the system displays a connection error message as shown in **Figure 6-2**.

Figure 6-1 A connection error prompted by the Chrome





Figure 6-2 A connection error prompted by the Firefox



### **Procedure**


## **MOTE**

Operations on the browser may vary depending on browser versions but are similar to the examples in the following steps. You are advised to perform the operations based on actual situations.

- Install the security certificate in Google Chrome.
  - Please select whether to execute the subsequent operations according to the following scenarios.
  - a. Obtaining the Trust Certificate from the NetEco Server.
    Use FileZilla to download the trust.cer certificate file from the /opt/oss/ NetEco/etc/ssl/er directory on the NetEco server as user ossuser to the local PC.
  - b. Installing the Trust Certificate on the Browser:


- i. Open Google Chrome and click in the upper right corner of the browser Icon Go to **Customise and control Google Chrome** Interface.
- ii. Click Settings.
- iii. Click Show advanced settings, Click again Manage certificates.
- iv. Importing Steps in a Trusted Root Certification Authorities a
   Certificates that have been saved to the local computer, click Import.
- v. Click **Next step** Browse **Selecting a certificate**.
- vi. Click Next step.
- vii. Click Next step.
- viii. Click Completed.
- ix. The **Security Warning** dialog box is displayed. Select **Yes(Y)**.
- Click Yes Restart the browser.
- Add the exception in Mozilla Firefox.
  - a. Click I Understand the Risks as shown in Figure 6-3.

Figure 6-3 Clicking I Understand the Risks



b. In the expanded area, click **Add Exception** as shown in **Figure 6-4**.

Figure 6-4 Adding exception.



c. Click Confirm Security Exception as shown in Figure 6-5.



Figure 6-5 Confirming security exception

## 6.2 How Do I Rectify a NetEco-NE Intermittent Disconnection Alarm?

This section describes how to rectify an intermittent disconnection alarm between the NetEco and an NE.

## **Symptom**

Intermittent disconnection occurs due to unstable links between the NetEco and NEs, triggering disconnection alarms.

### Possible Cause

The preset duration for alarm masking rules is too short, leading to the fact that lots of disconnection alarms are reported.

### **Procedure**

- Choose Device Management > Alarm Management > Alarm Settings.
- 2. In the navigation tree on the left, choose **Masking Rule**.
- 3. Create an alarm masking rule, set the alarm retention time, and mask intermittent disconnection alarms.
  - a. Click + to create a masking rule for intermittent disconnection alarms.
  - b. Select **Custom alarm sources** in the alarm source area and add communication alarms to be masked in **Add Alarm Sources**.

c. Set **Duration** (s) to  $\leq$  600 in **Advanced Setting**.

This is to mask disconnection alarms that are automatically cleared within 10 min after their generation.

d. Click **OK** to save the alarm masking rule.

## 6.3 How Do I Install the Video Surveillance Subsystem Client?

This section describes how to install the video surveillance subsystem client.

## **Prerequisites**

The network communication between the VCN/IVS1800 and the camera is normal.

#### **Procedure**

- If the video surveillance subsystem is VCN
  - a. Download the VCN Client.
    - Log in to Huawei technical support website and download the following software package. The download method is as follows:
      - For enterprise users:
        - 1) Log in to Huawei enterprise technical support website <a href="https://support.huawei.com/enterprise">https://support.huawei.com/enterprise</a>.
        - Browse or search for VCN and select a product from the drop-down list box.
      - For carriers:
        - Log in to Huawei technical support website https:// support.huawei.com.
        - 2) Browse or search for **VCN** and select a product from the drop-down list box.
    - ii. On the **Software** or **Product Software** tab page, download the software package as required.
  - b. Decompress the software package, double-click the installation program, and complete the installation as prompted.
- If the video surveillance subsystem is IVS1800
  - a. Download the iClient.

You can obtain the iClient in either of the following ways:

Method 1:	Obtain the iClient installation program from the OMU portal. Log in to the OMU portal, click <b>Client</b>	
	<b>Download</b> in the upper right corner, and save the installation program to a local directory.	

## Method 2:

- Log in to the OMU portal, choose Local Configuration > Basic Configuration, and view Current version.
- 2. Log in to Huawei technical support website and download the following software package. The download method is as follows:
  - For enterprise users:
    - a. Log in to Huawei enterprise technical support website https:// support.huawei.com/enterprise.
    - b. Browse or search for iClient.
  - For carriers:
    - a. Log in to Huawei technical support website https://support.huawei.com.
    - b. Browse or search for **iClient** and select a product from the drop-down list box.
- 3. On the **Software** or **Product Software** tab page, click the version and patch number corresponding to the current version, and download the software package as required.
- b. Decompress the software package, double-click the installation program, and complete the installation as prompted.

----End

# 6.4 How Do I Add a Camera on the Video Surveillance Subsystem?

Before creating a camera on the NetEco, you need to add the camera to the video surveillance subsystem.

## **Prerequisites**

- The video surveillance subsystem and camera are powered on and connected through a switch.
- The IP addresses of the video surveillance subsystem and camera are in the same network segment.
- The video surveillance subsystem client has been installed. For details, see 6.3 How Do I Install the Video Surveillance Subsystem Client?
- You have obtained the user name and password of a camera.

### **Procedure**

- Adding a camera on the VCN
  - a. Log in to the VCN IVS client as the **Admin** user.

#### 

- The default **User name** is **Admin**, and **Password** is **Change\_Me**. When a user logs in to the VCN IVS client for the first time, a password change dialog box is displayed, requiring the user to change the password.
- Set Server IP address to the IP address of the VCN.
- The default value of **Port** is **9900**. The default value is recommended.
- b. In the **Quick Setup** area, double-click **Add Camera**.
- c. Set search criteria.
  - i. Set the value of the **Drive**.

#### ∩ NOTE


- The default **Drive** is **ONVIF**. If an IPC6325 camera is added, select **HWSKD** for **Drive**.
- If there are multiple VCNs, set **Access server** to the VCN which the camera needs to be connected.
- ii. Click at the lower left corner, and enter **Start IP Addresses** and **End IP Addresses** for the camera, then click **Next**.

Set **Start IP Addresses** and **End IP Addresses** to an appropriate IP address range. If the range is too large, the search process may take a long time.

#### 

In the scenario where smart ETH gateways are networked, the camera has an internal IP address and an external IP address, ECC800-Pro searches for the internal IP address of camera.

Figure 6-6 Setting the start and end IP addresses




- d. Search for and verify the camera.
  - i. Click Search.

The system displays the IP address of the camera that is found.

ii. In the **Verify** area, enter user name and password of a camera, click **Verify**.

If the verification succeeds, the camera icon color changes to green.

Figure 6-7 Verifying the camera user name and password



#### NOTICE

- Cameras already added to the VCN will not be displayed on the search result page.
- Please confirm that the user name and password are correct. If you enter the incorrect password, and click **Verify** for three times, the user account will be locked.
- e. Select the camera to be added, and click Next.
  - The camera preview page appears.
- f. Preview the monitored area, and modify parameters such as **Camera** name, **Location**, and **Brightness** as necessary, click **Next**.
  - The camera grouping page appears.
- g. Click **Next**.
  - If the **Status** bar displays •, the camera is successfully added.
- h. Click **Finish**.
- Adding a camera on the IVS1800
  - a. Log in to the iClient client as the **administrator** user.

English

Welcome to
Huawei HoloSens iClient

Product

Local Mode

Platform Mode

Lock Screen
Lock Screen Password

Extreme
Confirm Password

Extreme

Figure 6-8 Logging in to the iClient

- b. On the home page of the iClient, choose **System Management > DeviceManagement > Device Management > Micro Edge**.
- c. Right-click an IVS1800 and choose Camera Access.
- d. Select Auto Batch Access and click Start.
- e. Set the IP address segment.

Figure 6-9 Setting an IP network segment



### 

- The driver protocol of IPC6325 and C3220 cameras is HWSDK.
- The IP address segment indicates the start and end IP addresses of cameras.
- f. You can use **IP Address** and **Vendor** to filter the required cameras in thecamera search result and select the required cameras. Alternatively,

you can directly select the required cameras in the camera list. Then verify accounts. The default password of the HWSDK protocol is **HuaWei123**.

Figure 6-10 Verifying accounts



### **Ⅲ** NOTE

If there are multiple IVS1800s for multiple smart modules, you are advised to evenly distribute the cameras to each IVS1800.

- g. Select the cameras to be added and click **Next**.
- h. Click Finish.
- Preview live video. On the iClient home page, click **Live** and drag a camera to the live video pane. If the live video can be properly played, the camera is successfully connected.

----End

# 6.5 How Do I Set Video Playback Parameters on the Video Surveillance Subsystem?

A camera can play videos only after video playback parameters are set on the video surveillance subsystem.

## **Prerequisites**

You have installed and logged in to the video surveillance subsystem client.

### **Procedure**

- If the video surveillance subsystem is VCN
  - a. On the home page, choose **Maintenance** > **Unified Configuration**.
  - b. In the **System Domain List** area, select an object, set **Module Name** to **MU**, and click **Query**.
  - c. In the **Parameters** area, click **Edit** next to **IsConstantUrl** and set the parameter value to **1**.
- If the video surveillance subsystem is IVS1800

- a. On the home page, choose Maintenance.
- b. In the navigation pane on the left, choose **Unified Configuration**, set **Module Name** to **MU**, and click **Search**.
- c. In the **Parameters** area, click **Edit** next to **IsConstantUrl** and set the parameter value to **1**.

----End

## 6.6 How Do I Enable or Disable the Message Push Function

You can enable or disable the real-time alarm notification function as required.

## **Prerequisites**

You have logged in to the NetEco app.

### **Procedure**

**Step 1** Enable or disable the **Push notifications** function as required.

Table 6-1 Setting the Push notifications function

Operation	Description	Procedure
Enabling the Push notificatio ns function	If the <b>Push notifications</b> function is disabled and you need to view the real-time alarm information pushed by the NetEco app on the mobile phone, perform this operation.	<ul> <li>Method 1         <ol> <li>When the system displays a message asking you whether to enable the Push notifications function, tap OK.</li> <li>Follow the onscreen instructions to enable the Push notifications function.</li> </ol> </li> <li>Method 2         <ol> <li>On the home screen of the NetEco app, tap Me.</li> <li>On the Me screen, tap Push notifications.</li> <li>Follow the onscreen instructions to enable the Push notifications function.</li> </ol> </li> <li>NOTE         <ol> <li>If a Huawei mobile phone is used, the Push notifications function is enabled for the NetEco app by default.</li> </ol> </li> </ul>

Operation	Description	Procedure
Disabling the Push notificatio ns function	If you do not need to view the real-time alarms pushed by the NetEco app on a mobile phone, perform this operation.	<ul> <li>Method 1         When the system displays a         message asking you whether to         enable the <b>Push notifications</b>         function, tap <b>Cancel</b>.</li> <li>Method 2         <ol> <li>On the home screen of the</li> </ol> </li> </ul>
		NetEco app, tap <b>Me</b> .
		<ol><li>On the Me screen, tap Push notifications.</li></ol>
		<ol><li>Follow the onscreen instructions to disable the <b>Push notifications</b> function.</li></ol>

Table 6-2 Obtaining addresses involved in the Push notifications function online

Address	Description
https://oauth-login.cloud.huawei.com	Huawei access token address
https://push-api.cloud.huawei.com	Push message address

----End