## **Direct Connect**

## **Troubleshooting**

**Issue** 01

**Date** 2022-09-30





### Copyright © Huawei Technologies Co., Ltd. 2022. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

#### **Trademarks and Permissions**

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

#### **Notice**

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

## **Contents**

| 1 Network and Connectivity | 1 | ı |
|----------------------------|---|---|
| 2 Routing                  |   | ) |

# Network and Connectivity

### Network

If the connection fails to work properly after you have created a virtual interface and used it to connect your environment to Huawei Cloud, perform the following steps to locate the fault:

- 1. Verify that the local gateway can be pinged from the remote gateway and that the VLAN of the intermediate device on the physical network configured correctly.
- 2. Verify that IP addresses of the local and remote gateways are in the same CIDR block and configured on the VLAN sub-interfaces.
- 3. If static routing is used, verify that the next hop or outbound interface of the static route is configured correctly.
- 4. If BGP routing is used, verify that the BGP ASN, BGP MD5 authentication key, and BGP peer IP address are correctly configured. BGP ASNs on both gateways must be different.
- 5. If BGP routing is used, verify there are not more than 100 BGP routes advertised through the virtual interface. If there are more than 100, excess BGP routes will not be received.
- 6. If BGP routing is used, verify that the rule for prohibiting TCP port 179 or large digital temporary TCP port connection is not configured.

## Connectivity

If the network connectivity is abnormal after you have connected the leased line to the endpoint device, perform the following steps to locate the fault:

- 1. Verify that the network device is connected correctly, auto-negotiation is disabled for the optical port, and the port speed and full-duplex mode are configured manually.
- 2. Verify that optical signals can be normally transmitted and received.

# **2** Routing

If a static route has been delivered to a virtual interface or a BGP peer relationship has been established, perform the following steps to locate the fault:

- 1. Verify that the route from your gateway to your network is reachable.
- 2. Verify that the route of your network is correctly advertised and configured in the remote subnet of the virtual interface, and that BGP is used for routing in your network.
- Verify that the VPC network segment is correctly configured on the virtual gateway.
- 4. Verify that your security group and network ACL rules allow inbound and outbound traffic.